

# SH8000 Training Manual





---

## Welcome

Congratulations on your appointment to operate the Stripe Hog / Bull. You are joining a team of about 150 operators represented in more than 20 countries across 5 different continents around the globe. We are a proud team and for good reason. We are a team dedicated to improving the way road marking Removal is done. We are the best trained, operate the best equipment, and are sincerely committed to the highest quality of workmanship. The results of our dedication and commitment are safer roads, a greener environment, less costly job sites, and higher profits for the companies we represent.

We are the best trained because Waterblasting Technologies offers the most comprehensive training in marking removal available anywhere in the world. Industry standard is one day of has been awarded the Gold Medal in the traffic industry for quality and design for the last 5 years in a row.

Actually since the very first Stripe Hog was offered to the marketplace. The Stripe Hog / Bull has become the standard for Stripe Removal Equipment using Ultra High Pressure Water just about everywhere on the planet. There are now more Stripe Hogs operating on our planet than the other top two selling brands combined. It's not that our competition is poor, it's just that the design and ingenuity of the Stripe Hog is remarkably better. The best part is that we are just scratching the surface in making improvements.

Until now road marking removal has been just another job that has to be done in order to put down new markings or reconfigure traffic patterns. The result was deep gouges in the road surface which meant that the road owners must resurface, standing water that presents a road hazard, and huge volumes of dust. The Stripe Hog and its team of operators is quickly making these scenarios a memory of bygone days. That's why we're proud!

In just a few days you'll join this team as a certified Stripe Hog / Bull Operator and we are all anxious to welcome you.

Thank you in advance for the contributions you bring.

Curtis J Crocker  
Training Coordinator  
Waterblasting Technologies

THIS PAGE WAS LEFT BLANK  
INTENTIONALLY



---

## **Waterblasting Technologies Training Schedule**

### ***Day 1***

7:30 – 10:00 Classroom – PowerPoint Class One

Introduction to Waterblasting Technologies and the Stripe Hog – PowerPoint

10:00 – 10:15 Break

10:15 – 12:00 Truck

Truck and System Orientation

12:00 – 1:00 Lunch

1:00 – 4:30 Truck

Start up Pre-Inspection – Filling Water Tanks and Activating Systems - Installing Spray Bars and Nozzles – Purging the System - Start up (instructor) – shutdown (instructor)

Repair Through Shaft (Instructor - Hands on)

### ***Day 2***

7:30 – 9:00 Classroom – PowerPoint Class 2

Review of UHP and Vacuum System, day 2 & Summary of SH8000 Overview Notes  
Dwell Time – Spray Bars - Nozzles Sizes – Spray Bar Configuration – Blasting Theory and Operation

9:00 – 9:15 Break

9:15 – 11:00 Classroom – PowerPoint Class 3

Start Up and Shut Down Procedures and Check Lists – Lubrication Points – Maintenance, Suggested Inventory – Part Ordering and Customer Service

11:00 – 12:00 Truck

Pre-start Inspection and Lubrication

12:00 – 1:00 Lunch

1:00 – 4:30 Truck

Student Operator Start Up with check list

Student Operator basic operation

Student Operator shutdown with check list

## **Waterblasting Technologies Training Schedule**

### ***Day 3***

7:30 – 9:00 Truck

Rebuild UHP Pump (Instructor hands on)  
Changing Spray Bars and purging system

9:00 – 9:15 Break

9:15 – 11:30 Truck

Startup and Students Operate Truck (Instructor support and coaching)

11:30 – 12:30 Lunch

12:30 – 4:30 Truck

Students operate the truck on their own (Instructor support and coaching)

### ***Day 4***

7:30 – 3:00 Truck

Students operate the truck on their own (Instructor support and coaching)

#### **Notes:**

Day 4 is reserved as a makeup day and provides the opportunity for additional hands on training and coaching.

## Operator Information Form

Date \_\_\_\_\_

Company Name \_\_\_\_\_

Training Level

Basic ☐

Advanced ☐

Master ☐

### OPERATOR INFORMATION

Operator Name \_\_\_\_\_  
(as it will appear on certificate)

Title \_\_\_\_\_

Address \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Shirt Size \_\_\_\_\_

Phone \_\_\_\_\_

Cell Phone \_\_\_\_\_

E-Mail \_\_\_\_\_

THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

## Operator Required Knowledge

- The UHP Pump produces up to 12 gallons per minute according to its RPM's
- PSI is controlled by the quantity of nozzles, their sizes, and supplied GPM
- The Stripe Hog functions best between 34 k and 38 k psi / 2,344 - 2,620 bar
- A loss of pressure is because of oversized, worn, or damaged Nozzles, Leaking Seals or Dirty Filters
- Excellent Removal is dependent on excellent nozzles
- Damage to the surface is because of improper DWELL TIME
- Debris Removal is dependent on proper Airflow at the Blast Head (ABH)
- ABH is limited by a dirty filter, leaking seals, damaged or blocked lines
- A properly maintained machine is the best antidote to downtime
- Cleanliness is always imperative

### I Will:

- Maintain my machine according to the Maintenance Matrix and Lubrication Chart
- Always work with appropriate nozzles, configurations and nozzle conditions
- Seek to Master Dwell Time principles to affect 95% removal & no damage
- Call Waterblasting Technologies Support with any questions or problems
- Waterblasting Technologies Support is available 24/7 at: 011 – 772-223-7393



THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

# SH8000 Systems Overview

LESSON	Notes
1) Water and Recovery Tanks a. Clean Water - <b>CLEAN ENOUGH TO DRINK</b> b. Debris - Solids and liquids Drain water each time you stop blasting Drain Water when more than ¾ full Empty all water storage before dumping – <b>CLEAN &amp; DIRTY</b>	<ul style="list-style-type: none"> <li>Clean Water</li> <li>Never Empty all _____ Before _____</li> </ul>
2) Water System a. Ultra High Pressure (UHP) Pump - Piston type < 40 k psi Cannot draw its own water b. Charge Pump - Centrifugal type < 60 psi Serves water to UHP Pump – Driven by hydraulic motor c. Dump Valve – Releases pressure back to the Clean Water Tank d. Manual Bypass Valve – Provides for setting High psi at set engine rpm's with flows lower than 10 gpm. e. Filters – Usually the cause of Low Charge psi 10 micron <b>"NOMINAL"</b> 1 micron <b>"ABSOLUTE"</b>	<ul style="list-style-type: none"> <li>High Pressure Pump Needs</li> <li>Charge Pump</li> <li>Dump Valve and Manual Bypass Valve</li> <li>Filters</li> </ul>
3) Hog Head a. Arm – "HOG ARM" b. Blast Heads c. Spray Bar – <b>"The Goose that Lays The Golden Egg"</b>	<ul style="list-style-type: none"> <li>Hog Arm</li> <li>Blast Heads</li> <li>Spray Bar</li> </ul>
4) Vacuum System a. Vacuum Blower – Casted Steel – <b>CLOSE TOLERANCES</b> – no <b>FOD</b> b. Filter Canister – Houses filter / dries the air - <b>DRAIN OFTEN</b> c. Kunkle Valves - Operates at -7 PSI	<ul style="list-style-type: none"> <li>Remember that vacuum</li> <li>Vacuum Blower is a positive Displacement air pump vulnerable to:</li> <li>Filter Canister</li> <li>If the system:</li> <li>All operations</li> <li>Electric switches</li> </ul>
5) Control System – All controls are electric over a. Air – Switches Gearbox between Drive and Operate Modes b. Hydraulic – 3 pumps power the Drive Train, Implements & Circulation	<ul style="list-style-type: none"> <li>All Operations</li> <li>Transmission</li> <li>Gearbox Allows</li> </ul>
6) Power System a. Truck Engine – 415 hp b. Transmission – Allison c. Gear Box – allows two modes of operation Drive Mode – Transport to and from worksite Work Mode – Hydra Static – Hydraulic Operations – UHP pump – Vac	<ul style="list-style-type: none"> <li>All Operations</li> <li>Transmission</li> <li>Gearbox Allows</li> </ul>

THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

# SH8000 Features & Functions

## I General Overview

### A General Functions and Characteristics

1. Stores clean and dirty water (Tank)
2. Pressurizes clean water to 60 psi (Charge Pump)
3. Boosts Pressure to 40K psi (High Pressure Pump)
4. Removes road markings (Hog Head)
5. Vacuums waste into debris tank (Vacuum System)
6. Operations controlled in the cab (Electrical System)
7. One engine powers all functions (Hydraulic System)



### B Main Components - Builds on General functions

1. Tank
  - (a) Clean Water – must clean enough for your baby girl to drink
  - (b) Dirty Water – filtered to 100 microns

## SH8000 Features & Functions

### 2. Water System

- (a) Charge Pump – pre-charges the system with 40 – 60 psi
- (b) High Pressure Pump – boosts pressure to 40 K psi
- (c) Dump Valve – normally open reduces psi. Close to increase psi.
- (d) Manual Bypass Valve – adjust psi manually under low flow conditions
- (e) Filters – **MUST BE CHANGED OFTEN**
  - (i) 10 Micron – Bag type, catches larger particles
  - (ii) 1 Micron – clogs much faster than 10 micron

### 3. Hog Head

- (a) Hog Arm – Use Float mode on the ground. Do not run over Reflective Markers
- (b) Blast Heads
  - 1. Through Shaft – The world leader in Swivel Shaft Technology
    - a. Swivel Nut – never more than finger tight. **DO NOT USE TOOLS**
    - b. Swivel Seal Adapter – notice weep holes if 3/8" x 7/8" is not sealed
    - c. Swivel Seal – note weep holes to indicate Seal needs replaced
    - d. Brass Backup Ring – Install onto Swivel Tip first. Clean well
    - e. Thrust Assembly Cover – clean well when changing Swivel Seal
    - f. Upper Swivel Shaft Seal – Install cup side up
    - g. Water Seal – Apply even pressure when installing
    - h. Silicone Seal – normal to appear smashed. Change when cut.
    - i. 25 mm Screws – only buy from WT. Special processes used to produce
    - j. Gland Nut – hold down while removing. Torqued to 50 ft lbs.
    - k. Swivel Tip – Replace if Swivel Seals wear quickly. Never allow to leak. Check sealing surface for cuts, abrasion, or wear.
    - l. Swivel Shaft – Check Swivel Tip Seat for cuts, abrasion, or wear. Can be lapped using special tool from WT. Do Not Use Swivel Tip to Lap.
    - m. Viton Seal – installs onto Swivel Shaft in groove provided. Replace if cut
    - n. Jam Nut – Torque to 50' lbs. Install and remove using Spanner Tool
    - o. Counter Washer – for future use
    - p. Spanner Nut – Set Torque with Spanner Tool by Hand tightening then backing off one hole. Anchor tool in place with two 25mm screws.
    - q. Screws (4)
    - r. Thrust Assembly Housing – remove and install carefully to protect seals
    - s. Seal – should be 3/16" below line. Apply pressure to outside ring only.
    - t. Shim – appears to float. Very important piece, do not lose.
    - u. Thrust bearing – moves thrust from center of assembly to the housing.
    - v. Grease Seal – no good after removing. Removal bends it.
    - w. Hydraulic Motor – New motors have a break-in period of an hour +/-
- (c) Spray Bar – Choose the right one for the job at hand. WT carries 7 types



## SH8000 Features & Functions

### 4. Vacuum System

- (a) Blower – vulnerable to damage by foreign material, i.e. dirty water and debris
- (b) Filter Canister – Drain often. Change filter when vac pressure is over -7
- (c) Kunkle Valves – Never cover the opening. This valve protects the system

### 5. Electrical System

- (a) Console – energized by the PTO switch. Controls all functions of the SH
- (b) Control Panel – junction for all wires from Console to their components.
- (c) Circuit Breaker – 50 amps, mounted on the Battery compartment

### 6. Hydraulic System

- (a) Gearbox
- (b) Hydrostatic Pump
- (c) Hydrostatic Motor
- (d) Implement Pump
- (e) Manifold
- (f) Circulation Pump

# SH8000 Features & Functions

## II Specific Functions of Main Components

### A Tank

#### (a) Clean Tank

- i. Stows 2700 US gallons of clean water
- ii. Provides auxiliary cooling reservoir

#### (b) Debris Tank

- i. 1700 US gallons capacity
- ii. Removes water and debris from the air on its way from the Blast Head to the Vacuum Blower and stores it for disposal
- iii. Separates water from the debris, provides for easy discharge of the filtered water and conveniently dumps the relatively dry debris

## 2. Water System

a. **Charge Pump** - powered by hydraulics it draws clean water from the storage tank and serves it at 60 psi to the High Pressure Pump and the Heat Exchanger. Its controls are both manual and electric. The manual controls are ball valves externally mounted on the Truck chassis and the electrical controls are on the Console. Its performance is adjusted by a needle valve located on the Tree.

b. **High Pressure Pump** - belt driven by the Gear Box it accepts 12gpm of clean water from the Charge Pump at 60 psi, boosts it to 40K psi and provides it to the Dump Valve, Manual Bypass Valve and the Hog Head. It is electrically controlled from the console simultaneously with the Vacuum Blower by the 40k Clutch switch.

c. **Dump Valve** – a normally open valve that controls the water pressure to the Blast Head by either allowing or disallowing water to be diverted back to the Clean Water Storage Tank. It is controlled on the console by the Start/Stop switch and is operated by a valve located on the Tree. It is either full on or full off.

d. **Manual Bypass Valve** – Provides a method for bypassing varying amounts of water back to the Storage Tank. Very useful when the engine's rpm needs to be set higher and water demand is lower which causes an overpressure situation.

e. **Filters** – located in the supply line 10 Micron and 1 Micron filters clear the water of undesired contaminants immediately before the High Pressure Pump.

f. **Optional Heat Exchanger** - transfers the heat from the trucks cooling system into the Clean Water Storage Tank

## SH8000 Features & Functions

### 3. Hog Head

a. **Hog Arm** – Anchors the Hog Head to the Stripe Hog and provides for positioning it. It must be in the Float Mode when it is on the ground during operation.

b. **Hog Head** - Hydraulically powered it utilizes the 12gpm @ 40K psi to remove road markings. It also holds the vacuum lines so that the debris can be collected. Its functions are individually controlled from inside the truck cab.

c. **Spray Bar** – Perhaps the most important piece on the Stripe Hog it holds the nozzles and “does the work” of removal. The entire Stripe Hog System has been developed to support the work of this invaluable tool. Great care should be taken when handling it especially when it is removed from the Blast Head.

### 4. Vacuum System

a. **Blower** - provides the air movement necessary to collect the debris at the Blast Head and deposit it into the Debris Tank. Made of casted steel it is very strong but vulnerable to debris.

b. **Filter Canister** – much more than a simple housing for the Vacuum Filter it uses cyclonic action to preclean the air and keeps the filter operating at optimum performance for a longer period of time thus lengthening its service life.

c. **Kunkle Valves** – Set to open at -7 psi the Kunkle Valves protect the Debris Tank from collapsing and ensure that the Blower maintains sufficient airflow.

### 5. Electrical System

a. **Console** – houses the electrical components that control the functions of the Stripe Hog equipment i.e. fuses, switches, terminal strips, and computer chips. It is protected by a 50amp circuit breaker mounted on the side of the battery compartment.

b. **Control Panel** – A junction box that provides for weather proof connections to relays and terminal strips. Wires come directly to it from the Console and from there are distributed to individual solenoids and relays. Generally speaking power comes into the Panel on the left side of the terminal strips and out on the right. The wires are each numbered for easy identification.

c. **Circuit Breaker** – Mounted on the side of the Chassis Battery Compartment it provides protection to the Stripe Hog Electrical System.

## SH8000 Features & Functions

### 6. Hydraulic System

a. **Gearbox** – installed in the drive line it distributes power from the transmission by way of the drive shaft to either the differential (In Drive Mode) or to 3 Hydraulic Pumps and the 40 K clutch (In Operate Mode)

b. **Hydrostatic Pump** – provides minute adjustments to control forward and reverse speeds of up to 4 mph and is capable of changing directions instantly without damaging itself or the driveline.

c. **Hydrostatic motor** – installed on the back of the gearbox it accepts flow from the Hydrostatic pump and turns the differential while in Operate Mode.

d. **40 K Clutch** – Controlled by air pressure it is located inside the Gearbox and drives the output shaft to the High Pressure Pump and Blower. It is controlled by an on/off switch on the Console.

e. **Tree** - Provides centralized mounting of hydraulic, and air operated equipment and controls on the exterior of the cab.

## SH8000 Features & Functions

### B The parts breakdown of Main Components

#### 1. Water Storage Tank

##### a. Clean Tank – do not over pressurize

1. **Manhole**- convenient access to interior, Keep locked
2. **Inlet ports** - for Dump Valve and Heat Exchanger
3. **Pressure Relief Port** - helps alleviate excessive pressure during filling, never close
4. **Fill Valve** - provides convenient access for filling
5. **Sight Tube** - shows water level at all times
6. **Discharge Ball Valves** – allows for releasing unwanted water
7. **Fill Hose**- connects to Clean Water source
8. **Hoses** for diffusing hot water from Heat Exchanger
9. **Baffles** – help prevent surges while driving or stopping

##### b. Debris Tank – do not over vacuum

1. **Door**- Always follow specific procedure to seal
2. **Inlet port** – 4” for debris to enter. Uses a “T” not an elbow to increase service life.
3. **Kunkle Valve** – Never seal it closed. Opens to relieve excess vacuum and protect tank from collapse.
4. **Glass Bubble** – Use to check debris level
5. **Sight Tube** - shows water level at all times
6. **Discharge Valve** – for releasing unwanted water
7. **Cage** – Provides larger surface area for bag to drain
8. **Binders** – pull door against seal. NEVER OVERTIGHTEN
9. **Inlet for Bilge Pump**
10. **Ball and Basket** – emergency air flow control
11. **Debris Bag** – Biodegradable filters to 100 Micron
12. **Remote Control** – operates hydraulic valve to power up and down. Holding the up or down control button too long can damage the hoist.
13. **Vacuum Gauge** – gives an external vacuum reading inside the tank

#### 2. Water System

##### a. Charge Pump – (Never run with less than 10 psi or more than 70psi)

1. Hydraulic motor
2. Pump Housing
3. Impeller
4. Misc seals



## SH8000 Features & Functions

- b. High Pressure Pump – rebuild every 100 hrs
  - 1. Drive Pulley and Belt – Poly Chain 7 – 10 yrs
  - 2. Crankcase – Gear Oil reservoir-oil should be clear not white
  - 3. Frame / Head
  - 4. Stub Shafts (3)
  - 5. Splash Guards (3) helps protect seals from water intrusion
  - 6. Plungers (3 carbide) Do not drop or hit with hard objects
  - 7. Connector Clamps (3) never separate the halves
  - 8. Stuffing Box (3)
    - a. Gland Nut – Clean all orifices
    - b. Packing – Change 75 – 150 hrs as needed
    - c. Brass Sleeve
    - d. Guide Bushing (carbide) do not drop or hit with hard object
    - e. Gland Nut o-ring
    - f. Brass Sleeve o-ring
  - 9. Stuffing Box (Face) Seal (3)
  - 10. Manifold – adjust the hinge to hold its weight
  - 11. Univalve (3) – needs seal surfaces lapped every 100 hrs
    - a. High Pressure valve
    - b. Low Pressure Valve
    - c. Spring
    - d. Spring Retainer
    - e. Retaining Ring (Split)
    - f. Low Pressure o-rings (2)
    - g. White Back-up Ring
    - h. High Pressure seal – more reliable without the small o-ring
    - i. Retaining Ring
  - 12. High Pressure Gauge
  - 13. Anti Vibration Gland Nut
  - 14. Rupture Disc Holder (2) Use sticker supplied with Rupture disc to ID which disc is installed inside.
  - 15. Port Adapter
  - 16. Water Lube Harness
    - a. Needle Valve (3)
    - b. Lube Hose (3) – ¼” airline.
  - 17. Trunion
  - 18. Pump Wrench (Jetstream Tool)
- c. Dump Valve - check for leakage under high psi by disconnecting the hose
  - a. Shut-off cartridge – check for cuts, check spring


## SH8000 Features & Functions

3. **Blast Head**
  - a. Shroud 8/10 or 14" – replace brushes often, brush should touch the ground
  - b. Spray Bar (multiple sizes) – most important piece on the Stripe Hog
  - c. Hydraulic motor / s – turn the Swivel Shaft
  - d. Swivel Shaft – transitions from a non moving hose to a spinning Spray Bar.
  - e. Swivel (Shaft) Seal – change between 8 & 20 hrs
  - f. Block – holds the Hog Head components together
  - g. Dirt Shield Gasket – Grease impregnated felt gasket. Change as necessary.
  - h. Deflector Ring – Only finger tighten
  - i. Swivel Shaft Timing Pulley – removes and installs easily. Watch keyway
  - j. Hydraulic Timing Pulley – Taper Lock bushing type.
  - k. Wheels – grease daily
4. **Vacuum Blower** – No serviceable Parts, NEVER ALLOW WATER INSIDE
5. **Electrical System** – separate from chassis system
  - a. Console - Power supplied direct from truck batteries. A relay allows the ignition system to override the electrical circuit by way of the PTO Switch.
  - b. PTO Switch - energized by ignition system, initiates all functions of SH
  - c. All wires terminate only in cabinet mounted on Tree and are numbered on each end.
  - d. Components are all numbered same as the wire leading to them.
  - e. 50 amp Breaker – protects the electrical system, located on side of battery
6. **Hydraulic System**
  - a. **Gear Box**
    1. Air activated pistons
    2. Hydra Static Pump
    3. Hydraulic Motor
    4. Hydraulic Implement Pump
    5. Gear Box Lubrication Pump
    6. 40K Clutch
  - b. **Tree**
    1. Hydraulic Fluid cooler
    2. Hydraulic Manifold
  - c. **Manifold** – ports are stamped and solenoids marked


THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

## Clean Water and Vacuum Systems

### SH8000 Clean Water System




### SH8000 Vacuum System




# Electrical and Hydraulic Systems



## SH8000 Electrical System



## SH8000 Hydraulic System



## PTO Engaged and Disengaged





THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

# Foreman's Parts Box #2

SH8000 Order Form - 2008

## Foreman's Parts Box #2

QTY	List \$	Price Each	Line Totals	Part #	Description
	\$ -		\$ -	MP4024-005	Nozzles, High Cohesive, .005"
	\$ -		\$ -	MP4024-007	Nozzles, High Cohesive, .007"
	\$ -		\$ -	MP4024-009	Nozzles, High Cohesive, .009"
	\$ -		\$ -	MP4024-011	Nozzles, High Cohesive, .011"
	\$ -		\$ -	MP4024-013	Nozzles, High Cohesive, .013"
	\$ -		\$ -	MP4024-015	Nozzles, High Cohesive, .015"
	\$ -		\$ -	MP4034	Plug Assy, Recessed Allen Key
	\$ -		\$ -	MP4024-000	Plug, High Cohesive
	\$ -		\$ -	MP4024-000B	Plug, High Cohesive 7/16"
	\$ -		\$ -	MP2253	Seal, Swivel Shaft
	\$ -		\$ -	MP1008	Seal, Brass Button
	\$ -		\$ -	FT38hpx5mm	3/8" HP x 5 mm Adapter(for Hog Head)
	\$ -		\$ -	FT38hpx78	3/8" HP x 7/8 Type M Adapter ( or hog head)
	\$ -		\$ -	FT916hpx78	9/16" HP x 7/8 Type M Adapter(dump valve)
	\$ -		\$ -	FT916hpx5mm	9/16" HP x 5mm Type M Adapter(dump valve)
	\$ -		\$ -	FT78hpx78c	7/8" HP Type M Connector(for tractor hose)
	\$ -		\$ -	FT916hpxPLUG	Plug Stub, 9/16" HP
	\$ -		\$ -	FT916hpxGLNDNUT	Gland Nut, 9/16" HP
	\$ -		\$ -	MP1020-06-14	6" 14 Nozzle Spray Bar
	\$ -		\$ -	MP1020-08	8" 8 Nozzle Spray Bar
	\$ -		\$ -	MP1020-0816	8" 16 Nozzle Spray Bar
	\$ -		\$ -	MP1020-1016	10" 16 Nozzle Spray Bar
	\$ -		\$ -	MP1020-14	14" Spray Bar
	\$ -		\$ -	MP1020-1430	14" 30 Nozzle Spray Bar
	\$ -		\$ -	MP1025-06-14 Assy	6" 14 Nozzle Spray Bar Protector
	\$ -		\$ -	MP1025-08 Assy.	8" 8 Nozzle Spray Bar Protector
	\$ -		\$ -	MP1025-0816 Assy.	8" 16 Nozzle Spray Bar Protector
	\$ -		\$ -	MP1025-1016 Assy	10" 16 Nozzle Spray Bar Protector
	\$ -		\$ -	MP1025-14 Assy	14" Spray Bar Protector (Set of 2, Left & Right)
	\$ -		\$ -	MP1025-1430Assy	14" 30 Nozzle Spray Bar Protector (set of 2)

## Stripe Hog Spare Parts Package Parts Box # 1

				Part #	Description
	\$ 25.00		\$ -	T-8810	3/8-24 standard tap
	\$ -		\$ -	1128846	6/32 x 2" screw
	\$ -		\$ -	HD4025-200	2" Cotter Pin
	\$ -		\$ -	62518	4 oz. Anti-seize Lubricant
	\$ -		\$ -	HD4000-12WH	Wheel, Rubber w/Steel Inner 4"
	\$ -		\$ -	HD4000-12-STEEL	Wheel, Steel 4"
	\$ -		\$ -	HD4000-06WHRB	Wheel, Rubber 6"
	\$ -		\$ -	HD4000-12WHRB	Wheel, Rubber w/Steel Inner 4"
	\$ -		\$ -	HD6000-12-STEEL	Wheel, Steel 6"
	\$ -		\$ -	STY1025C	Seal, Raceway for 10" Caster
	\$ -		\$ -	STY1025C-1-8-4	Caster, 10" Assy, w/ seal
	\$ -		\$ -	HD4000-12-10	Wheel, 10" with mold on rubber
	\$ -		\$ -	MP4000-11	Plate, Caster, Front
	\$ -		\$ -	MP4000-09	Plate, Caster, Rear
	\$ -		\$ -	MP4000-DBL	Plate, Caster, Double
	\$ -		\$ -	Brush 10" Assy.	Brush Assy. 10" Shroud



## Foreman's Parts Box #2

\$	-	\$	-	Brush 14" Assy	Brush Assy. 14" Shroud
\$	-	\$	-	SM9001-10	Shroud, 8-10"
\$	-	\$	-	SM9001-14	Shroud, 14"
\$	-	\$	-	T-6452	Tool, Swivel Seal Removal
\$	-	\$	-	MP6504	Nut, Swivel
\$	-	\$	-	MP6524	Adapter, Swivel Seal
\$	-	\$	-	MP2752	Ring, Brass Backup
\$	-	\$	-	MP2010	Assembly, Swivel Shaft (w/bearings)
\$	-	\$	-	MP10025S	Housing, Swivel
\$	-	\$	-	BR1001	Seal, Upper Swivel Shaft Water
\$	-	\$	-	BR1002	Bearing, Upper Swivel Shaft
\$	-	\$	-	MP1001	Shaft, Swivel
\$	-	\$	-	50105-001	Tip, Thru Shaft, Swivel, Hoghead
\$	-	\$	-	283807ADL-VITON	Seal, 28 x 38 x 7mm
\$	-	\$	-	9396K113	O-ring, 2" x 21/8 x 1/16 width, silicone
\$	-	\$	-	9396K21	O-ring, 9/16 x 11/16 x 1/16 width, Viton
\$	-	\$	-	5154T69	Seal, 25 x 52 x 8mm
\$	-	\$	-	203800ADL	Seal, 20 x 38 x 5mm
\$	-	\$	-	315207 ADL	Seal, 31 x 52 x 7mm
\$	-	\$	-	SH-GR	Swivel Shaft Grease - Mobil PolyRex EM
\$	-	\$	-	SHBL-GR	Roots Blower Bearing Grease - Shell Darina SD 2
\$	-	\$	-	BR1003	Bearing, Lower Swivel Shaft (thrust)
\$	-	\$	-	BR1003R	Bearing, Lower Swivel Shaft (radial)
\$	-	\$	-	BR4000-11	Seal, Cover Top, (Hog Head)
\$	-	\$	-	MP4000-1T	Cover, Top
\$	-	\$	-	HD4000-07	Bolt, Cover Top to Swivel Housing
\$	-	\$	-	HD4000-04	Bolt, Cover Top to Housing Block
\$	-	\$	-	BR1007	Ring, Snap, 1"
\$	-	\$	-	BR1006-A	Key, Shaft, 1/4" x 3/4" Mod.
\$	-	\$	-	MP4000-1A	Housing, Block
\$	-	\$	-	BR1008	Pulley, Timing (Swivel Shaft)
\$	-	\$	-	BR4000-12R1	Seal, Cover Bottom, (Hog Head)
\$	-	\$	-	MP4000-1B	Cover, Bottom
\$	-	\$	-	HD4000-06	Bolt, Cover Bottom to Housing Block
\$	-	\$	-	MP1006	Ring, Deflector (dirt shield)
\$	-	\$	-	MP1006FG-1	Gasket, Dirt Shield
\$	-	\$	-	HD4000-08	Bolt, Hydraulic Motor to Housing Block
\$	-	\$	-	HD4000-09	Washer, Lock, Hydraulic Motor to Housing Block
\$	-	\$	-	HY113	Motor, Hog Head Rotation
\$	-	\$	-	MP4000-18	Extender, Motor Shaft
\$	-	\$	-	BR1006-A	Key, Motor Shaft Extender
\$	-	\$	-	BR1004	Bushing, Taper Lock
\$	-	\$	-	BR1005	Pulley, Timing (Hyd. Motor Shaft)
\$	-	\$	-	BR4000-10K	Belt, Timing, 18" x 3/4"
\$	-	\$	-	SH6008-P	Lube, Silicone (1 oz)
\$	-	\$	-	T-8125	Tool, O-ring & Seal
\$	-	\$	-	MP4046	Seat, Dump Valve
\$	-	\$	-	MP4042	Pin, Dump Valve
\$	-	\$	-	MP4049	Piston, Dump Valve
\$	-	\$	-	MP4048	Tube, Dump
\$	-	\$	-	HD4043	Spring, Dump Valve
\$	-	\$	-	BR4045	O-ring, Dump Valve Pin
\$	-	\$	-	BR4050	O-ring, seat
\$	-	\$	-	K53476	Cartridge, Shut-off Valve (New tractor dump valve)
\$	-	\$	-	K51865	Tube, Diffuser (New tractor dump valve)

### JetStream Spare Parts Package

Qty

Part #

Description

## Foreman's Parts Box #2

\$ -	\$ -	K27485	Disc, Rupture, 50K
\$ -	\$ -	K28616	Disc, Rupture 45K
\$ -	\$ -	K54099	Sleeve, Brass Spacer, Stuffing Box #8
\$ -	\$ -	K27482	Bushing, Carbide, Stuffing Box #8
\$ -	\$ -	K26482	Seal, Stub Shaft Oil (Pony Rod)
\$ -	\$ -	K26480	O-ring, Stub Shaft Seal Plate
\$ -	\$ -	K53564	Plunger #8 Clamp Style
\$ -	\$ -	K51737	Coupling, Plunger (brass)
\$ -	\$ -	K54119	Packing #8 4240
\$ -	\$ -	K53496	Valve, Uni
\$ -	\$ -	K54144	Seal Kit, Univalve, 40K
\$ -	\$ -	K54102	Nut, Gland
\$ -	\$ -	K26465	O-ring, Gland Nut
\$ -	\$ -	K53610	Cartridge, Hydro-Throttle
\$ -	\$ -	K53609	Seal, Hydro-Throttle Ring (White)
\$ -	\$ -	K27533	Seal, Hydro-Throttle Ring (Black)
\$ -	\$ -	K54100	Box, Stuffing
\$ -	\$ -	K54126	Seal, Stuffing Box Face
\$ -	\$ -	K53574	Plug, 40K Top Conn
\$ -	\$ -	K27503	O-ring, Male Port
\$ -	\$ -	K53726	Cartridge AY, 40K Bypass
\$ -	\$ -	K25127	O-ring, Bypass Cartridge Large
\$ -	\$ -	K53729	Ring, Bypass Cartridge Large Buna (white)
\$ -	\$ -	K53593	Seal Ring (White), Fitting
\$ -	\$ -	K27537	Seal Ring (Black), Fitting
\$ -	\$ -	K27538	Retaining Ring, Fitting Seal
\$ -	\$ -	K26523	O-ring, #8 Brass Spacer Sleeve
\$ -	\$ -	K27505-2	Filter, Cartridge, 1 Micron
\$ -	\$ -	K26767-1M	Filter Bag, 1 Micron Nominal
\$ -	\$ -	K53476	Cartridge, Shut-off Valve
\$ -	\$ -	K25194	O-ring, Shut-off Valve Cartridge Large
\$ -	\$ -	K53468	Ring, Shut-off Valve Cartridge Large Buna (white)
\$ -	\$ -	K25190	O-ring, Shut-off Valve Cartridge Small
\$ -	\$ -	K53730	Ring, Shut-off Valve Cartridge Small Buna (white)
\$ -	\$ -	K27522	Spring, Shut-off Valve Cartridge
\$ -	\$ -	K51865	Tube, Diffuser
\$ -	\$ -	K27489	Gauge, 40K Pressure
\$ -	\$ -	BC00M25P125	Fitting, Connector, 1/4" tube x 1/8" pipe thread

### Spare Hoses

		Part #	Description
\$ -	\$ -	HS-40K5mm-9	Hose, 5mm Type M x 9' No Cover
\$ -	\$ -	HS-40K-5mm-11.5	Hose, 5mm Type M x 11.5' No Cover
\$ -	\$ -	HS-40K-7/8-5C	Hose, 7/8" Type M x 5' 40K w/cover
\$ -	\$ -	HS-40K-7/8-11C	Hose, 7/8" Type M x 11' 40K w/cover
\$ -	\$ -	HS-40K-7/8-21C	Hose, 7/8" Type M x 21' 40K w/cover
\$ -	\$ -	HS-40K-7/8-47-C	Hose, 7/8" Type M x 47' 40K w/cover

### Vac/Tank Spare Parts Package

		Part #	Description
\$ -	\$ -	P-120818	Filter, Pleated Polyester, Large, Single, Washable
\$ -	\$ -	ST3000-Bag100	Bag, Dump/Filter, 100 micron for ST4100
\$ -	\$ -		

### Operations Manual

\$ -	\$ -	SHMANUAL	Manual, Stripe Hog Operations/Maintenance
------	------	----------	---

THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

# SH8000 Maintenance Check Lists

Date \_\_\_\_\_

Mileage \_\_\_\_\_

PTO Hours \_\_\_\_\_

Technician \_\_\_\_\_

## Fluids

\_\_\_ **Engine Oil** – 15w/40 Synthetic

\_\_\_ Checked / added

\_\_\_ Changed oil / filter

\_\_\_ **Rear Drive Axle Differential**

\_\_\_ Checked / added

\_\_\_ Changed - 80 / 90 Gear Oil

\_\_\_ **Automatic Transmission**

\_\_\_ Checked / added

\_\_\_ Changed oil / filter

\_\_\_ **Front Drive Axle Differential**

\_\_\_ Checked / added

\_\_\_ Changed - 80 / 90 Gear Oil

\_\_\_ **Hydraulic Fluid** - Type AV 68

\_\_\_ Checked / added

\_\_\_ Changed

\_\_\_ **Power Steering**

\_\_\_ Checked / added

\_\_\_ Changed oil / filter

\_\_\_ **High PSI Pump** Oil-80/90 Gear Oil

\_\_\_ Checked / added

\_\_\_ Changed

\_\_\_ **Blower**

\_\_\_ Changed Oil

\_\_\_ Grease

\_\_\_ **Engine Coolant**

\_\_\_ Checked / added

\_\_\_ Changed oil / filter

\_\_\_ **Gearbox**

\_\_\_ Dexron III fluid / filter

\_\_\_ 80 / 90 Gear Oil Left Side

\_\_\_ 80 / 90 Gear Oil Right Side

Page 1 of 3

# SH8000 Maintenance Check Lists

## Mechanical

### ☐ Hog Head

#### ☐ Belts

☐ Checked

☐ Changed

#### ☐ Hydraulic Motors

☐ Checked

☐ Changed

#### ☐ Spray Bars

☐ Checked

### ☐ Drive Shafts – check for play

☐ Main to Gearbox

☐ Secondary to Differential

☐ Third to Rearmost Axle

☐ Output to Pump / Blower

☐ PTO to Hydrostatic Pump

### ☐ Lights – check for proper function

☐ Head Lamps

☐ Directionals

☐ Strokes and Work lamps

### ☐ Swivel Shafts

☐ Checked

☐ Changed

### ☐ Charge Pump

☐ Builds pressure

☐ Water Leaks

☐ Oil Leaks

### ☐ Gearbox

☐ Shifts to Drive/Work Mode

☐ Clutch Disengages/Engages

☐ Filings on magnetic plug

☐ Leaks

### ☐ Dump Bed

☐ Hydraulics Strong / Weak

☐ Action Fast / Slow

### ☐ High Pressure Hoses

☐ Check for leaks

# SH8000 Maintenance Check Lists

## Mechanical (Cont'd)

### ☐ High Pressure Pump

- ☐ Uni Valve wear
- ☐ Stuffing Boxes
- ☐ Splash Guards in place
- ☐ Belt Tension
- ☐ Oil Seals
- ☐ Plunger wear

### ☐ Air System

- ☐ Compressor building psi
- ☐ Lines (Leaks)
- ☐ Holding Tanks - Bleed
- ☐ Parking Brake Holding
- ☐ Psi holding while braking

### ☐ Blower

- ☐ Belt Tension
- ☐ Filter
- ☐ Kunkle Valves
- ☐ Vacuum Hose
- ☐ Wok Seal

### ☐ Electrical

- ☐ Panels sealing
- ☐ All switches functioning
- ☐ All circuits functioning

### ☐ Debris Tank

- ☐ Door Seal
- ☐ Shut Off Ball / Basket
- ☐ Cage

### ☐ Hydraulics

- ☐ Hoses - chafing / leaking
- ☐ Flows adjusted properly
- ☐ Cooling Fan

### ☐ Clean Water Tank

- ☐ Man Way
- ☐ Fill Valves

## Recommended Tools and Supplies

LOCATION	Number	Item
Truck	1	Metal Clip Board
Tool Box	1	4" Needle Nose Pliers
Tool Box	1	Screw Drive Set – All Sizes – Phillips and Flat Blade
Tool Box	1	Medium Vise Grip Pliers
Tool Box	1	¼ & 3/8 Drive SAE / Metric Socket Set
Tool Box	1	12" Channel Lock Pliers
Tool Box	1	12" Crescent Wrench
Tool Box	1	14" Crescent Wrench
Tool Box	1	2 lb Rubber Hammer
Tool Box	2	¾" Combination Wrench
Tool Box	1	Metric Allen Wrench Set
Tool Box	1	SAE Allen Wrench Set
Tool Box	1	Ball Peen Hammer
Storage	1	Bottle Hand Cleaner
Truck	2	Duck Tape
Truck	1	Fire Extinguisher
Truck	1	First Aid Kit
Storage	1	Funnel
Storage	1	Gallon Engine Coolant
Storage	1	Gallon Motor Oil
Storage	1	Gallon Transmission Fluid
Storage	2	Grease Guns (each loaded with different grease)
Storage	1	Shell Darina Micro Gel Grease
Storage	1	Ultra Duty EP NLFI 2 – Multi-Purpose Grease
Storage	1	Hydrant Wrench
Storage	1	Jet Stream Tool
Storage	1	Jumper Cables
Storage	1	Measuring Wheel
Tool Box	1	25' Measuring Tape
Truck	1	Paper Towels
Truck	1	Leather Gloves
Truck		Rain Coats for Crew
Truck	1	Road Atlas
Truck	20	Safety Ear Plugs
Truck	2	Pair Safety Glasses
Truck	2	Hard Hats
Truck	2	Safety Triangles
Truck	2	Safety Vests – DOT Class
Truck	1	Skip Counter
Truck	1	Tire Pressure Gauge
Truck	1	Window Cleaner
Storage	10	Zip Ties Large
Truck	2	Cans of Brake Cleaner

## Technical Support

### 24 / 7 CUSTOMER SERVICE

- Waterblasting Technologies Customer Service Department stands ready to answer your questions and provide technical assistance 24 hours a day, 7 days a week.
- Customer Service can also assist you with part orders.
- Always contact Waterblasting Technologies Customer Service Department for assistance and cross reference specifications for parts you intend to purchase locally.

### PARTS

- All replacement parts are available directly through Waterblasting Technologies, Inc.
- Get the parts you need when you need them
- Next day delivery is available in most locations.
- Same day delivery available in some areas for parts ordered before 10AM Eastern Standard Time

**CUSTOMER SERVICE HOT LINE - 772-223-7393**  
**[www.waterblastingtechnologies.com](http://www.waterblastingtechnologies.com)**  
**[www.stripehogsupport.com](http://www.stripehogsupport.com)**

**Waterblasting Technologies, INC will not be responsible for damages or loss caused by substituted parts purchased locally or from another vendor or manufacturer.**



## WARNING



**NEVER ATTEMPT TO USE COMMONLY AVAILABLE PLUMBING PARTS, FITTINGS, AND HOSES IN HIGH PRESSURE SYSTEMS! ALL FITTINGS TO BE USED WITH HIGH PRESSURE OPERATIONS MUST BE PROPERLY DESIGNED, STAMPED, RATED AND APPROVED BY WATERBLASTING TECHNOLOGIES, INC! FAILURE TO HEED THIS WARNING MAY RESULT IN DAMAGE TO COMPONENTS AND SEVERE INJURY OR DEATH!**



# Stripe Hog Support Web Page




## Stripe Hog Support

[Home](#)
[Training](#)
[Ambassador Club](#)
[Marketing](#)
[Stripe Hog Store](#)
[Contacts](#)




You are here → [Home](#)

[Mike](#) → [Logout](#) →



**VIDEO HELP**



### Typical Registration & Logon Window

**Welcome to the Stripe Hog Support Center!**  
**This resource is exclusive to Stripe Hog customers. In order to view the complete menu above and website you must be logged in.**  
**If you own or operate a Stripe Hog please login or register.**

REGISTER		LOG ON	
User Name:	<input type="text"/>	User Name	<input type="text"/>
First Name	<input type="text"/>	Password:	<input type="password"/>
Last Name:	<input type="text"/>		
Display name:	<input type="text"/>		
Email Address:	<input type="text"/>		
<a href="#">REGISTER</a>		<a href="#">Login</a>	

(001) 772-223-7393 This number that will find an available customer support representative 24/7.

We are excited to take your call any hour of the day. Please don't hesitate to call if we can help.

The "Ambassador Club" is added to the site - Tuesday, November 11, 2008

The Ambassador Club is a place for Waterblasting Technologies, Stripe Hog owners and operators to communicate so we all can benefit and become stronger. As an owner/operator of the Stripe Hog you are in an elite group. Welcome!

| [Home](#) | [Stripe Hog Training](#) | [Ambassador club](#) | [Marketing](#) | [Stripe Hog Store](#) | [Contacts](#) |

# WATERBLASTING TECHNOLOGIES

## SH8000 RECYCLE ONSITE TRAINING CLASS 1



THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

# WATERBLASTING TECHNOLOGIES

## SH8000

### ON SITE TRAINING



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

# TRAINING TOPICS

- OUR COMPANY
- OUR PRODUCTS
- SH8000 COMPONENTS & SYSTEMS
- OPERATING MANUAL & FACTORY SUPPORT



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

# COMPANY HISTORY



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

# HUMBLE BEGINNINGS – CONTRACTOR BUILT



1998



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

# GREAT ADVANCEMENTS





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

# WORLD LEADER



2005

- Contractor Built & Proven
- 12 gpm System
- Dual Blasting Heads
- Vacuum Recovery Standard
- Water/Debris Separation



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!



SHRINKING THE STRIPE HOG

50'



SH8000 | Before

36'



SH8000 | After



WATERBLASTING TECHNOLOGIES Presents **HONEY, I SHRUNK THE STRIPE HOG**



- Uses truck engine to power all systems
- Enabled the truck to shrink 5 feet
- Trailer became unnecessary



The World Leader in Marking Removal, Rubber Removal, Surface Preparation & Pavement Cleaning!

SH8000 LEADING THE WORLD





The World Leader in Marking Removal, Rubber Removal, Surface Preparation & Pavement Cleaning!

WATERBLASTING TECHNOLOGIES TODAY

THREE DIVISIONS

WATERBLASTING TECHNOLOGIES

WATERBLASTING.COM

SHEET METAL UNLIMITED



The World Leader in Marking Removal, Rubber Removal, Surface Preparation & Pavement Cleaning!

GLOBAL PRESENCE





The World Leader in Marking Removal, Rubber Removal, Surface Preparation & Pavement Cleaning!

HEADQUARTERS – STUART, FLORIDA



Assembly      Design      Administration





The World Leader in Marking Removal, Rubber Removal, Surface Preparation & Pavement Cleaning!

MANUFACTURING







The World Leader in Marking Removal, Rubber Removal, Surface Preparation & Pavement Cleaning!

FABRICATION, SHEET METAL AND SERVICE





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!


SHEET METAL FABRICATION, PAINTING & SERVICE







The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

TRUCK MODELS  
&  
POPULAR OPTIONS





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

SH8000 TRUCK SYSTEM





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

SH5500 TRUCK SYSTEM





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

SH3000 SKID MOUNTED SYSTEM





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!



POPULAR OPTIONAL EQUIPMENT



BLASTING TRACTOR



WALK BEHIND  
SPRAY HEAD



HANDHELD  
SPRAY HEAD



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

POPULAR OPTIONAL EQUIPMENT



POWER PACK



CUSTOM SH3000 SKID MOUNTED UNITS



HOG WALLER



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

CUSTOM CONTAINERIZED UNITS



SHIP BLASTING ROBOT







The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

SH8000 SYSTEMS  
OVERVIEW




The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

SYSTEMS OVERVIEW & NOTES

SH8000 Systems Overview

LESSON	NOTES
1) Water and Recovery Tanks: a. Clean Water - CLEAN indicates power b. Dirty - Solids and liquid c. Drain water each time you stop blasting d. Dirty Water when more than 50 full Empty all water storage before dumping - CLEAN & DIRTY	* Clean Water:  * Super * Empty all before
2) Water System: a. Ultra High Pressure (UHP) Pump - Piston type - 400 psi b. Control Valve - 1000 psi c. Change Pump - Control Valve type - 400 psi d. Servo water to UHP Pump - Servo by hydraulic control e. Dump Valve - Releases pressure back to the Clean Water Tank f. Manual Bypass Valve - Provides for setting high psi at set engine rpm's with Power Water than 100 gpm g. Filters - Usually the level of Low Charge psi 10 micron "medium" 1 micron "fine"	* High Pressure Pump Needs  * Change Pump * Dump Valve and Manual Bypass Valve  * Filters * High psi * Shut down * Temp Bar * Return to End vacuum
3) Hog Head: a. Arm - "Hog Arm" b. Blast Nozzle c. Spray Bar - "The Goose that Lays the Golden Egg"	* Vacuum Blower Unit * Vacuum Blower Unit (if not used) * Filter Canister * If the system * All components * Electric Switches * All operators * Transmission * Side Driveline
4) Vacuum System: a. Vacuum Blower - Control Valve - ELONG TOLERANCES - 1000 b. Filter Canister - Vacuum Filter (filter the air) CLEAN OVEN c. Kinked Valves - Operators at 7 PSI	
5) Control System - All controls are electric input: a. Air - Switches Gasless between Drive and Operator Modes b. Hydraulic - 3 pumps power the Drive Train, Implements & Circulation	
6) Power System: a. Truck Engine - 415 hp b. Transmission - Allison c. Gear Box - Allison 6000 series of gearbox d. Drive Mode - Transport to and from work site e. Work Mode - Hydraulic System - Hydraulic Operators - UHP pump - 400	



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

ULTRA HIGH  
PRESSURE SYSTEM



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

CLEAN WATER TANK

A SUCCESSFUL PROCESS  
BEGINS WITH  
"CLEAN WATER"

FROM FIRE HYDRANTS

Stainless Steel Tanks

Stainless Steel Valves





The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!

CHARGE WATER PUMP

- Airlocks
- Adjust charge pressure
- Pay attention to pump sounds
- Cavitation





The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!


CLEAN WATER FILTERS


MONITOR CHARGE  
WATER PRESSURE

NEVER BELOW 40 PSI

10 Micron Filter (Nominal)


1 Micron Filter (Absolute)





The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!

ULTRA HIGH PRESSURE (UHP) PUMP



DUMP VALVE – MANUAL BYPASS VALVE – RUPTURE DISKS



Dump Valve


High Pressure Gauge

Bypass Valve

Rupture Disks

Manual Bypass Valve Adjustment Knob





The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!

PACKING COOLING LINES & VALVES

Flush Valve





The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!



UHP PUMP WEEP HOLES




High Pressure Weep Holes

Face Seal Weep Holes




The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

UHP PUMP PACKING COOLING LINES



TOO MUCH FLOW  
WASTES WATER

IMPROPER FLOW  
DAMAGES PACKING  
SEALS



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

BILGE PUMP





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

FILLING THE CLEAN WATER TANK





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

SH8000 PRESSURE WATER SYSTEM





Diagram labels: Dump Valve, Manual Pressure, Bilge Pump, Manual Manual Entry, Charge Pump, Supply Valve, Heat Exchanger, Bilge Pump Return Line, Manual Absolute, Heat Exchange Supply Valve.





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

HOG HEAD



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!





SPRAY BAR SHIELDS



- Vortex
- Spray Bar Sizes
- Install Protectors Properly
- Wear Brush Function
- Wear Brush Adjustment & Replacement





The World Leader in  
Marking Removal • Rubber Removal  
Surface Preparation & Pavement Cleaning!

JOY STICK & MAIN SWITCH CONSOLE





The World Leader in  
Marking Removal • Rubber Removal  
Surface Preparation & Pavement Cleaning!

VACUUM SYSTEM



The World Leader in  
Marking Removal • Rubber Removal  
Surface Preparation & Pavement Cleaning!

VACUUM BLOWER, SILENCER, & DEBRIS TANK




Labels: Silencer, Debris Tank, Blower

VACUUM FILTER CANISTER, DRAIN VALVE & HOSES




Labels: Wok, Vacuum Canister, Drain Valve


VACUUM FILTER & KUNKLE VALVE



Labels: Filter, Kunkle Valve, Vacuum Sensor



The World Leader in  
Marking Removal • Rubber Removal  
Surface Preparation & Pavement Cleaning!



DRAIN TANKS BEFORE DUMPING



WARNING

To reduce the possibility of the truck tipping while dumping, always drain the water from the debris & clean water tanks before raising the tanks to dump debris.

- Water Filtered to 100 Microns
- Close Waste Drain Valve when dumping is complete

Waterblasting Technologies

The World Leader in Marking Removal, Rubbish Removal, Surface Preparation & Pavement Cleaning!

⚠

DANGER

⚠

TO AVOID SEVERE DAMAGE TO THE TRUCK OR SERIOUS INJURY TO PERSONNEL, ALWAYS FOLLOW THESE GUIDELINES BEFORE RAISING THE TANKS TO DUMP DEBRIS:

- ✓ DRAIN ALL WATER FROM THE CLEAN WATER AND DEBRIS TANKS.
- ✓ MAKE SURE THE TRUCK IS ON FLAT, SOLID GROUND. NEVER ATTEMPT TO DUMP ON SOFT GROUND OR UNEVEN TERRAIN.
- ✓ MAKE SURE THERE ARE NO OVERHEAD POWER LINES NEAR THE DUMPING AREA.
- ✓ ALWAYS SECURE THE RECOVERY DOOR WITH THE SAFETY CHAIN.
- ✓ MAKE SURE THE VACUUM AND WATER HOSES ARE DISCONNECTED AT THE QUICK DISCONNECTS.
- ✓ HAVE ALL PERSONNEL STAND WELL CLEAR OF THE TRUCK AND RECOVERY DOOR. THE OPERATOR SHOULD USE THE REMOTE CONTROL AND BE WELL CLEAR.
- ✓ LIFT THE UNIT SLOWLY AND MONITOR HOSES AND COMPONENTS AS IT IS RAISED. BE PREPARED TO IMMEDIATELY LOWER THE UNIT IF THERE IS A PROBLEM.
- ✓ NEVER JERK THE TRUCK WHILE DUMPING THE DEBRIS. JERKING THE TRUCK IS UNSAFE AND CAN DAMAGE THE TRUCK AND/OR CAUSE THE TANK FALL.
- ✓ SECURE THE UNIT WITH THE SAFETY STRUT BEFORE ENTERING THE RECOVERY TANK OR SERVICING ANY COMPONENT.
- ✓ LOWER THE UNIT SLOWLY WHEN DUMPING OPERATIONS ARE COMPLETE.

Waterblasting Technologies

The World Leader in Marking Removal, Rubbish Removal, Surface Preparation & Pavement Cleaning!



HYDRAULIC DUMPING SYSTEM



Safety Strut

Disconnect Hoses

Door Safety Chain

Level, Solid Ground


RECOVERY TANK DOOR & SEAL SYSTEM



- Door Seal Memory
- Keep Seal Clean
- Use Vacuum to Assist in Clamping Door
- IMPROPER CLOSING PROCEDURE WILL RESULT IN DAMAGE TO THE DOOR AND SEAL

ELECTRICAL SYSTEM

SH8000 ELECTRICAL SYSTEM



CONTROL PANEL

MANIFOLD


JOYSTICK

CONSOLE

CIRCUIT BREAKER

BATTERIES

BATTERIES, MAIN CIRCUIT BREAKER & SWITCH



Isolator & Circuit Breaker

JOY STICK & MAIN SWITCH CONSOLE



JOY STICK & MAIN SWITCH CONSOLE




➢ 25 Wire Harness to main Terminal Box  
➢ All wires are numbered


Fuse Panel



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!


MAIN TERMINAL PANEL






The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!


SH8000 ELECTRICAL SYSTEM





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

HYDRAULIC  
&  
DRIVE SYSTEMS



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

OMSI DRIVE GEAR BOX & HYDROSTATIC DRIVE



Shift Rod

40 K Clutch


Omsi Drive

Hydrostatic Drive



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!


HYDRAULIC COMPONENTS & COOLING PUMPS



Drive Belt Coupler






40 K Clutch

Hydraulic and Gear Lubrication Pump



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!






HYDRAULIC CONTROL SOLENOIDS






The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!

HYDRAULIC MANIFOLD SCHEMATIC



TRANSMISSION AND PTO CONTROLS



Hydrostatic Drive

4-4 Lockup

Charge Pump

Oil Lubrication Pump

40 K Clutch

Omsi Drive

JOY STICK CONTROLS



Hog Arm Movement

UHP Pressure Dump Valve


Truck Speed in Work Mode

Spray Bar Rotation Speed

Hog Arm Float Mode

UHP Pressure Gauge

HYDRAULIC SYSTEM SCHEMATIC



OPERATING MANUAL & SUPPORT



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning!



OPERATING MANUAL / CAUTIONS & WARNINGS



SH4000/SH8000

Operations Manual



CAUTION

HAZARDOUS OR UNSAFE PRACTICES WHICH COULD RESULT IN SEVERE PERSONAL INJURY OR PROPERTY DAMAGE.

WARNING

HAZARDOUS OR UNSAFE PRACTICES WHICH COULD RESULT IN SEVERE PERSONAL INJURY OR DEATH.

DANGER

HAZARDOUS OR UNSAFE PRACTICES WHICH WILL RESULT IN SEVERE PERSONAL INJURY OR DEATH.



The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!

SERVICE MATRIX & LUBRICATION CHART



Service Matrix

Model	Year	Engine	Capacity	Weight	Dimensions
SH4000	2008-2010	4.0L Diesel	1500L	1500kg	3000x1500x1500mm
SH8000	2008-2010	8.0L Diesel	3000L	3000kg	6000x3000x3000mm



Lubrication Chart

Model	Year	Engine	Oil Type	Oil Capacity	Filter Type	Filter Capacity
SH4000	2008-2010	4.0L Diesel	15W-40	1500L	40mm	1500L
SH8000	2008-2010	8.0L Diesel	15W-40	3000L	80mm	3000L



The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!

TECHNICAL SUPPORT & PARTS

24 / 7 Customer Service

Waterblasting Technologies Customer Service Department stands ready to answer your questions and provide technical assistance 24 hours a day, 7 days a week.

Customer Service can also assist you with part orders.

Always contact Waterblasting Technologies Customer Service Department for assistance and cross reference specifications for parts you intend to purchase locally.

Parts

All replacement parts are available directly through Waterblasting Technologies, Inc.

Get the parts you need when you need them

Next day delivery is available in most locations.

Same day delivery available in some areas for parts ordered before 10AM Eastern Standard Time.

Customer Service Hot Line 772-223-7393

[www.waterblastingtechnologies.com](http://www.waterblastingtechnologies.com)

[www.stripehogsupport.com](http://www.stripehogsupport.com)



The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!

ASSEMBLY DRAWINGS & PART LISTS



FLUID END REPLACEMENT PARTS





MOTOR END REPLACEMENT PARTS





The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!

PARTS DEPARTMENT AND ONLINE SUPPORT



Stripe Hog Support



Global Support

24-7

www.stripehogsupport.com

LOGGING ON TO WWW.STRIPEHOGSUPPORT.COM

Welcome to the Stripe Hog Support Center!

This resource is exclusive to Stripe Hog customers. In order to view the complete menu above and website you must be logged in.

If you own or operate a Stripe Hog please login or register.

REGISTER

User Name:

First Name:

Last Name:

Display name:

Email Address:

REGISTER

LOG ON

User Name:

Password:

Login



The World Leader in  
Marking Removal / Rubber Removal,  
Surface Preparation & Pavement Cleaning!

14



THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

## WATERBLASTING TECHNOLOGIES

# SH8000 ON SITE TRAINING CLASS 2



## TRAINING TOPICS

- REVIEW OF DAY ONE
- UPDATE OVERVIEW NOTES
- DWELL TIME
- NOZZLES
- SPRAY BAR CONFIGURATIONS



## DAY ONE REVIEW



## GENERAL OVERVIEW - NOTES

[illegible]

## RIGHT SIDE OVERVIEW



## LEFT SIDE OVERVIEW



OPERATOR REQUIRED KNOWLEDGE & MAINTENANCE

➤ The UHP Pump produces up to 12 gallons per minute according to its RPM's

➤ PSI is controlled by the quantity of nozzles, their sizes, and supplied GPM

➤ The Stripe Hog functions best between 34,000 and 38,000 psi / (2,344 – 2,620 bar)

➤ A loss of pressure is because of oversized, worn, or damaged nozzles, leaking seals or dirty filters

➤ Excellent removal is dependent on excellent nozzles

➤ Damage to the surface is because of improper DWELL TIME

➤ Debris removal is dependent on proper airflow at the blast head (ABH)

➤ ABH is limited by a dirty filter, leaking seals, damaged or blocked lines

➤ A properly maintained machine is the best antidote to downtime

➤ Cleanliness is always imperative

I Will

➤ Maintain my machine according to the Maintenance Matrix and Lubrication Chart

➤ Always work with appropriate nozzles, configurations and nozzle conditions

➤ Seek to master Dwell Time principles to affect 98% removal & no damage

➤ Call Waterblasting Technologies Support with any questions or problems

➤ Waterblasting Technologies Support is available 24/7 at: 011 – 772-223-7393

Waterblasting Technologies

The World Leader in  
Masking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning

DWELL TIME

Waterblasting Technologies

The World Leader in  
Masking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning

DWELL TIME FUNDAMENTALS

➤ Dwell time is the most counter intuitive dynamic of the stripe hog.

➤ Dwell time is critical to production.

➤ Mastering dwell time takes experience and a trained eye.

➤ The principles of dwell time should be applied to avoid undesirable impact to the surface and maximize productivity.

Waterblasting Technologies

The World Leader in  
Masking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning

DWELL TIME IS:

Length of Time a Nozzle Spends Above a Given Point

Waterblasting Technologies

The World Leader in  
Masking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning

STATIONARY NOZZLE @ 40 K PSI

If the nozzle is stationary, what happens?

Waterblasting Technologies

The World Leader in  
Masking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning

STATIONARY NOZZLE @ 40 K PSI

How far down will we have to turn the pressure?


Waterblasting Technologies



The World Leader in  
Masking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning



ONE DROP OF WATER

After 1000 YRS








The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning

SAME NOZZLE @ 40 K PSI MOVING @ 1000 MPH

No Noticeable Affect





The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning

Damage is Not Caused By Pressure

Damage is Caused by Too Much

DWELL TIME



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning

DWELL TIME CONTROLS



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning

DWELL TIME CONTROL - LATERAL MOVEMENTS


Four Types

- Truck Speed
- Head Rotation Speed
- Hog Arm Movement – Left to Right
- Nozzle Size and Position




The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning



DWELL TIME CONTROL





Truck Speed



Head Rotation Speed



The World Leader in  
Marking Removal, Rubber Removal,  
Surface Preparation & Pavement Cleaning



NOZZLE PERFORMANCE

The diagram illustrates the spray bar configuration for nozzle performance. It shows a horizontal spray bar with seven nozzles mounted on it. A vertical double-headed arrow indicates the spray pattern or coverage area. Below the spray bar, a yellow rectangular area represents the treated surface. The Waterblasting Technologies logo and tagline are at the bottom.

NOZZLE ROTATION PATTERN

The diagram shows the rotation pattern of the nozzles. It features a central red circle surrounded by concentric orange circles. Seven nozzles are positioned around the perimeter, each labeled with a number (1 through 7). The Waterblasting Technologies logo and tagline are at the bottom.

PAVEMENT MARKING PROFILE

The diagram displays two types of pavement marking profiles. The top profile is labeled 'Concave Profile' and shows a downward-curving shape. The bottom profile is labeled 'Convex Profile' and shows an upward-curving shape. Above the profiles, a photograph of the spray bar with seven nozzles is shown. The Waterblasting Technologies logo and tagline are at the bottom.

SPRAY BAR CONFIGURED WITH DIFFERENT SIZED NOZZLES

The diagram illustrates a spray bar configured with different sized nozzles. It shows a horizontal spray bar with seven nozzles of varying sizes, labeled with numbers 15, 13, 11, 9, 7, 9, 13, 15. Below the spray bar, a yellow rectangular area represents the treated surface. The Waterblasting Technologies logo and tagline are at the bottom.

SPRAY NOZZLE CONFIGURATION CHARTS

This chart displays various spray nozzle configurations and their corresponding flow rates. It includes a table for 'High Cohesive Nozzle Flow Chart' with columns for GPM, PSI, and Flow. The table lists flow rates for different nozzle sizes and pressures. The Waterblasting Technologies logo and tagline are at the bottom.

SPRAY NOZZLE CONFIGURATION CHARTS

This chart displays various spray nozzle configurations and their corresponding flow rates. It includes a table for 'High Cohesive Nozzle Flow Chart' with columns for GPM, PSI, and Flow. The table lists flow rates for different nozzle sizes and pressures. The Waterblasting Technologies logo and tagline are at the bottom.



**NOZZLE CONFIGURATION EXAMPLES**

**Waterblasting Technologies**

**The World Leader in**  
Marking Personnel, Rubber Removal,  
Surface Preparation & Paintwork Cleaning!

# TYPICAL CUT – 8 NOZZLE, LEAD SPRAY HEAD




Typical 8 Nozzle Cut Profile – 1<sup>st</sup> Pass

The World Leader in  
Marking Removal, Tubing Removal,  
Surface Preparation & Penetration Cleaning

WHAT IS THIS TELLING YOU?


**Waterblasting Technologies**

The World Leader in  
Misting, Removal, Inhibitor Application,  
Surface Preparation & Environment Cleaning









## LUBRICATION & MAINTENANCE



## LUBRICATION POINTS & GREASE FITTINGS



### PRIMARY LUBRICATION POINTS – DRIVER SIDE & FRONT



### BLOWER GREASE FITTINGS



### HOG HEAD & ARM GREASE FITTINGS




### PRIMARY LUBRICATION POINTS – PASSENGER SIDE






BLOWER AND UHP PUMP PULLEY PILLOW BLOCK BEARINGS



UNIVERSAL JOINT &amp; DRIVE SHAFT GREASE FITTINGS



DOOR HINGES



HOIST LUBRICATION POINTS








## OIL SUMP SYSTEMS




OMSI DRIVE SIGHT GLASS AND FILL PLUG







[illegible]

**Waterblasting  
Technologies**

The World Leader in  
Marking Removal, Rust Removal,  
Surface Preparation & Pavement Cleaning

## UHP DRIVE BELTS & BELT TENSION

The image is a composite. The left side shows a close-up of a large yellow industrial machine, likely a conveyor system, featuring a large grey pulley and a drive belt. The right side shows a digital belt tensioner device, which is a handheld electronic unit with a screen and buttons, connected by a cable to a small black probe used for measuring belt tension.

**The World Leader in**  
Marking Removal, Rust/Jet Removal,  
Surface Preparation & Pavement Clearing

**TECHNICAL SUPPORT & PARTS**

**24/7 Customer Service**

- Waterblasting Technologies Customer Service Department stands ready to answer your questions and provide technical assistance 24 hours a day, 7 days a week.
- Customer Service can also assist you with part orders.
- Always contact Waterblasting Technologies Customer Service Department for assistance and cross reference specifications for parts you intend to purchase locally.

**Parts**


- All replacement parts are available directly through Waterblasting Technologies, Inc.
- Get the parts you need when you need them
- Next day delivery is available in most locations.
- Same day delivery available in some areas for parts ordered before 10AM Eastern Standard Time.

**Customer Service Hot Line 772-223-7393**  
[www.waterblastingtechnologies.com](http://www.waterblastingtechnologies.com)  
[www.stripehogsupport.com](http://www.stripehogsupport.com)

**Waterblasting Technologies**

**The World Leader in**  
 Marking Removal, Rust/Scale Removal,  
 Surface Preparation & Pavement Cleaning

## SH8000 STRIPE HOG

A yellow SH8000 STRIPE HOG truck is shown from a front-three-quarter view. The truck is equipped with a large yellow hose and a metal frame. It is parked on a paved surface, and a city skyline is visible in the background. The truck has a large yellow hose connected to a metal frame, which is used for applying paint or marking on the pavement. The truck is yellow with black accents and has "SH8000 STRIPE HOG" written on the side. The background shows a city skyline with several tall buildings under a clear sky.

# CLASS THREE

## END

 **Waterblasting  
Technologies**



**The World Leader in**  
Marking Removal, Rubble Removal,  
Surface Preparation & Pavement Cleaning



THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

# SH8000/SH8000T Operations Manual





We would like to extend to you our "Thank You" for choosing a Stripe Hog™!

Please take the time to read this operations manual before attempting to operate your waterblasting system. This manual is an important aid in the operation and maintenance of your new equipment. The information is intended as a guide and cannot cover every question you may have about your Stripe Hog and every operating situation. We encourage you to contact Waterblasting Technologies, Inc.® for any additional information you might need. We provide first class support to our customers for all of the equipment we sell. Additionally, we maintain a well stocked inventory of parts and accessories in addition to technical staff with the experience to satisfy all of your support questions. Please contact us for all of your support issues and questions toll-free at (877) 964-7312 and on-line at [www.waterblastingtechnologies.com](http://www.waterblastingtechnologies.com) or [www.stripehogsupport.com](http://www.stripehogsupport.com).

## Safety

High pressure, waterblasting equipment can cause serious injury or even death if it is not operated or maintained properly. Your Stripe Hog manual has been written to include a number of safety instructions to assure the safe operation and maintenance of your equipment. These instructions are in the form of a General Safety Section as well as **individual DANGER, WARNING and CAUTION** statements. There are also **CAUTION, WARNING AND DANGER LABELS** located on some Stripe Hog components. You should read these warnings carefully and make sure you understand the nature of the hazard and the precautions and recommended procedures required to ensure your safety.

## Major Component Operation Manuals

The suppliers of some of the major components such as truck chassis, tractors, engines, pumps, and drive units, provide their own owner's manuals which have been included with your equipment. You should read the information in this manual and the manuals of other suppliers completely and have a thorough understanding of all component systems and their proper operation before operating your equipment.



*Caution and Warning Labels on High Pressure Pump*



*Water Filter Warning Label*

**REMEMBER - IT IS YOUR RESPONSIBILITY TO ENSURE THAT YOUR EQUIPMENT IS SAFE FOR YOU AND YOUR CREW. ALWAYS EXERCISE GOOD COMMON SENSE WHEN INSTALLING OR REPAIRING EQUIPMENT AND WHILE OPERATING THE STRIPE HOG.**

## Warranty

The Waterblasting Technologies Limited Warranty Statement is included with this manual. It has been written to be clearly stated and easily understood. If you have any questions after reading the warranty, please contact the Customer Service Department.



Waterblasting Technologies, truck and tractor manufacturers, engine manufacturers, and the suppliers of major components maintain their own manufacturer's warranty and service facilities. Waterblasting Technologies automatically validates your warranty at the time of purchase and does not require a warranty registration card. However, the manufacturers of some major components require a completed warranty registration card to validate their warranty. It is important that you properly complete any warranty registration cards included with your Stripe Hog and mail them back to the manufacturer to register your ownership. This should be done within 15 days of the date of purchase and before the unit is put into service.

## IMPORTANT:

The terms and conditions of the Waterblasting Technologies Limited Warranty are outlined in the warranty statement included with this manual. The manufacturer will automatically honor the warranty to the original purchaser for 15 days from the date of purchase. However, during that 15 day period, owners must comply with the steps outlined in the warranty statement to validate their warranty.

All manufacturers are required by the US Government to notify first time owners in the event any defect is discovered "which creates a substantial risk of personal injury to the public." ***It is essential that we have your warranty registration card complete with your name and mailing address in our files so that we can comply with the law if it should become necessary.***

Waterblasting Customer Service will assist you in filling in the serials numbers and other data required on your registration card if you experience difficulty. Your Warranty Registration Card will be added to our permanent files.

## Product Changes

Waterblasting Technologies, Inc.® is committed to the continuous improvement of our products. As a result, some of the equipment described in this manual or pictured in the catalog may change or no longer be available.

***All information, illustrations, and specifications contained in this manual are based on the latest product information available at the time of publication. Waterblasting Technologies, Inc.® reserves the right to make changes at anytime, without notice, in colors, materials, equipment, specifications, and models.***

If you have questions about the equipment on your Stripe Hog, please contact the Customer Service Department.

## Service

All warranty repairs must be authorized by Waterblasting Technologies, Inc. Should a problem develop that is related to faulty workmanship or materials, as stated in the Limited Warranty, you should contact our Customer Service Department to arrange for assistance and prior approval for the necessary repair. ***It is the owner's responsibility to contact Customer Service for prior authorization for warranty service.***



## **WARNING**



**INCORRECT USE OF HIGH PRESSURE WATERBLASTING EQUIPMENT MAY CAUSE SERIOUS INJURY OR EVEN DEATH.**

**DO NOT USE THIS EQUIPMENT WITHOUT PROPER SUPERVISION AND TRAINING.**

**ALL OPERATING AND MAINTENANCE PERSONNEL MUST BE THOROUGHLY TRAINED IN SAFE OPERATION, INSTALLATION AND MAINTENANCE OF THIS EQUIPMENT AND PROVIDED WITH ADEQUATE SUPERVISION.**

**BEFORE ATTEMPTING TO CONNECT, OPERATE, OR REPAIR THIS EQUIPMENT, THOROUGHLY READ THESE INSTRUCTIONS AND ANY SAFETY WARNING OR INSTRUCTION PAMPHLETS INCLUDED WITH YOUR SHIPMENT.**

**FOR ANY QUESTIONS CONCERNING SAFE OPERATIONS AND MAINTENANCE PROCEDURES, CONTACT YOUR WATERBLASTING TECHNOLOGIES, INC. REPRESENTATIVE PRIOR TO USE.**

**(772) 223-7393 OR (877) 964-7312  
WATERBLASTING TECHNOLOGIES, INC.  
WWW.WATERBLASTINGTECHNOLOGIES.COM**

This manual has been written to include a number of safety instructions to assure the safe assembly, operation and maintenance of your Waterblasting Equipment. These instructions are in the form of **DANGER, WARNING, and CAUTION** statements. The following definitions apply:



All instructions given in this book are as seen from the rear looking forward. Common industry terminology is used throughout the manual.

**IMPORTANT NOTE:** Your Waterblasting equipment uses internal combustion engines and flammable fuel. Every precaution has been taken by Waterblasting Technologies to reduce the risks associated with possible injury and damage from fire or explosion, but your own precaution and good maintenance procedures are necessary to ensure the safe operation of your equipment.



WELCOME .....	3
SAFETY WARNINGS AND INSTRUCTIONS .....	6
TABLE OF CONTENTS .....	7

## **Section 1:**

### **Safety Information**

1.1 General Safety.....	9
1.2 Blasting Safety .....	10
1.3 Nozzle Safety .....	11
1.4 Hose Safety .....	12
1.5 High Pressure Fitting Safety.....	12
1.6 Dumping Safety.....	12

## **Section 2:**

### **Stripe Hog Systems**

2.1 Truck Chassis .....	13
2.2 Truck Power System and PTO.....	15
2.3 Primary Drive Belts .....	17
2.4 Truck Hydraulic System .....	18
2.5 Truck Mounted Hog Head .....	19
2.6 Waterblast System .....	24
2.7 Vacuum System .....	31

## **Section 3:**

### **Stripe Hog Tractor Operation**

3.1 Tractor Controls & Deployment.....	37
3.2 Tractor Hog Head & Hydraulic Systems.....	39
3.3 Tractor Waterblasting.....	43

## **Section 4:**

### **Waterblasting Hog Tools**

4.1 Hog Tools (Optional) .....	45
4.2 Hog Tool Waterblast Systems.....	46
4.3 Hog Tool Vacuum Systems.....	46

## **Section 5:**

### **Stripe Hog Operation**

5.1 Emergency Shutdown .....	47
5.2 SH8000 Start Up/Shutdown.....	47
5.3 SH8000T Tractor Startup/Shutdown.....	49
5.4 Waterblasting Operations .....	51
5.5 Operating in Freezing Conditions .....	52

## **Section 6:**

### **General Maintenance**

6.1 Lubrication .....	53
6.2 Truck Maintenance .....	53
6.3 UHP Pump & Vacuum Blower Drive Belts .....	55
6.4 High Pressure Blasting System & Charge Pump .....	58
6.5 Hog Head Maintenance .....	60
6.6 Hydraulic System Maintenance.....	61
6.7 Vacuum System & Debris tank .....	62
6.8 Stripe Hog Tractor (SH8000T) .....	66
6.9 Lubrication Chart .....	67

## **Section 7:**

### **Component Repair**

7.1 Swivel Shaft Repair .....	69
7.2 Thru-Shaft Motor Bearing Pre-Load.....	74
7.3 Caster Wheel Care – Hog Head Assembly .....	87
7.4 Stripe Hog Dump Valve Assemblies & Diagrams.....	89
7.5 Shut-Off (Dump) Valve Repair.....	91
7.6 Manual Bypass Valve Repair .....	93

## **Appendix A:**

### **Drawings and Supplies**

Fluid End Replacement Parts .....	95
Recommended Tools and Supplies.....	96

## **Appendix B:**

Troubleshooting Guide.....	97
----------------------------	----

## **Appendix C:**

SH8000 Specifications .....	103
-----------------------------	-----

## **Appendix D:**

Pre-Start Inspection.....	105
Warm Weather Shutdown .....	106
Freezing Conditions Shutdown.....	107

## **Appendix E:**

Spray Bar Configuration and Nozzles .....	109
Nozzle Calculation Sheet .....	115

## **Appendix F:**

Technical Support .....	117
Stripe Hog Support Web Page .....	118

# Safety Information

## 1.1 General Safety

### Use Safety Training

Only trained personnel should be allowed to setup, operate, or maintain this equipment. Water blast operators should be made aware that the water jet nozzles can cause serious bodily injury. Training supervisors should demonstrate the powerful potential damage of the nozzles by showing new trainees the effect of water jets cutting a piece of 2 x 4 wood.

### Check Water Supply

Use only clean water in any ultra high pressure system. ***DO NOT*** accept water drawn from retention ponds, canals or other non-potable sources.

### Work Area Safety

Remember, safety is first! Only set up to work in areas properly protected from traffic and other hazards.

Outfit all operators with proper safety apparel. Hard hats, safety shields or glasses, gloves, ear protection, etc.

Most ultra high pressure waterblasting operations generate noise levels above 90dB. Hearing protection is required in accordance with OSHA standards.

### Use Only Products Intended for High Pressure Waterblasting Use

Know the pressure ratings of all equipment being used and never exceed any operating pressure higher than the rating of the weakest component. This system is designed to work with pressures up to but not exceeding 40,000 psi (2758 bar).

### Never Alter a Waterblasting Product

Do not alter any product without written consent from the manufacturer. Any alterations could have serious consequences including bodily harm or death.

### Always Read Instructions

Read and follow all the manufacturer's instructions prior to using any waterblasting product. Contact Waterblasting Technologies, Inc. should any questions arise.

### Inspect Equipment

Inspect the condition of all components prior to use. Do not use any item that is in questionable condition. Use only components which are marked with the recommended operating pressure. Never exceed the operating pressure of the weakest component in the system.

### Check Connections

Check the condition of the connection threads prior to connecting any fittings or hoses. Use an Anti-seize compound on all fittings and hoses to prevent "galling," as galling will destroy the threads and essentially the fittings and/or hose ends.

### Tighten Connections

Properly tighten all high pressure connections. Usually, snug plus a 15% tightening will properly seal connections.

### Purge System

Before attaching spray bar to Hog Head assembly, engage pump at low speed to purge the system. Any dirt or debris in the system can clog nozzle orifice's and cause system pressure to spike excessively causing damage to components.

### Test System

With the spray bar installed with proper high cohesive nozzles, operate the pump at low pressure to check for nozzle accuracy and leaks on spray bar or nozzles. Should any repairs or adjustments be necessary, disengage the pump to relieve all pressure before making any required repairs or adjustments.

### Set System Pressure

With system operating properly, set your pressure according to methods described by pump manufacturer's instructions. Refer to the Pump operating manual for specifications and instructions.

### Use the Minimum Pressure Required

Do not exceed the operating pressure of the system's lowest pressure-rated component. All equipment pressure rating and warning tags should be left intact.

### Be Prepared

If the equipment malfunctions or a malfunction is suspected, immediately stop all blasting activity



and relieve the pressure in the system before attempting any repair. Always follow manufacturer's repair instructions.

### Use Only Thoroughly Trained Personnel to Perform Maintenance or Repairs

#### Low Pressure Test

Following repair, operate the system at low pressure for a test. Bring equipment up to operating pressure slowly.

#### Freezing Conditions

System hoses and Hog Head assembly should be drained of all water or filled with an anti-freeze solution. For the 40K water blaster, refer to pump manufacturer's procedures for maintaining equipment in freezing climates. If you do decide to operate at freezing temperatures or even temperatures below 60 degrees Fahrenheit, you will need to run system with the high pressure pump engaged at IDLE speed only, under load, until the oil temperature rises above 60 degrees Fahrenheit.

#### Store Components Properly

Protect all components from damage when not in use. Secure for travel.

## 1.2 Blasting Safety

### Safety First – ALWAYS!

Whenever pump is engaged for setting pressure or operations, always be sure work area is clear of people, hands, feet, etc., before engaging the high pressure switch on Stripe Hog.



### WARNING



INJURIES FROM ULTRA HIGH PRESSURE WATERBLASTING ARE VERY SERIOUS AND CAN RESULT IN A FATALITY. ALWAYS MAKE SURE ALL PERSONNEL ARE A SAFE DISTANCE FROM THE WORK AREA BEFORE THE PRESSURE PUMP IS ENGAGED. NEVER PUT HANDS, FEET OR ANY PART OF YOUR BODY IN OR NEAR THE HIGH PRESSURE STREAM.

#### Check Hog Head

Check the Hog Head for smooth and proper operation before each shift. Do not use equipment that has not been checked thoroughly.



Hog Head

#### Check Stripe Hog Control Components

Check all switches and control panel devices to ensure each is working properly before beginning operations. Do not use equipment if any device is malfunctioning.

#### Stripe Hog Tractor Brake

Always set the tractor brake before beginning any testing, pressure testing system or blasting. The force from blasting head can move tractor backwards causing blast to cross the path of people or equipment.

#### Use Safety Protection

Always use eye protection from projected debris. Use ear protection to protect from noise levels generated from pump, vacuum and hog head blasting.



### WARNING



ULTRA HIGH PRESSURE BLASTING CAN CAUSE DEBRIS TO BE PROJECTED UNEXPECTEDLY IN AND AROUND THE WORK AREA THAT CAN CAUSE SEVERE INJURY. MAKE SURE ALL PERSONNEL STAY WELL CLEAR OF THE BLASTING AREA AND USE HARD HATS, EYE AND EAR PROTECTION.

#### Start at Low Pressure

Always start blasting with the system at low pressure slowly increasing to operating pressure. Engage and disengage yellow Ultra High Pressure



High Cohesive Nozzle Flow Chart					
FLOW - GPM @ Pressure Indicated					
Orifice Dia./ins	20KPSI (1379 Bar)	26KPSI (1723 Bar)	30KPSI (2068 Bar)	36KPSI (2482 Bar)	40KPSI (2758 Bar)
0.005	0.08	0.09	0.09	0.10	0.11
0.006	0.11	0.12	0.13	0.15	0.15
0.007	0.15	0.17	0.18	0.20	0.21
0.008	0.19	0.22	0.24	0.26	0.28
0.009	0.25	0.28	0.30	0.33	0.35
0.010	0.30	0.35	0.37	0.41	0.43
0.011	0.37	0.42	0.45	0.49	0.52
0.012	0.44	0.50	0.54	0.59	0.62
0.013	0.51	0.59	0.63	0.69	0.73
0.014	0.60	0.68	0.73	0.80	0.84
0.015	0.68	0.78	0.84	0.92	0.97

lever two times at operating pressure to check operation of Hog Head before starting blasting operations.

### Check Your Stripe Hog Dumping Pressure

When setting pressure ALWAYS ensure that the system pressure drops to less than 500 psi (34.475 bar) immediately when yellow lever is released. If this does not relieve system pressure immediately to below 500 psi when released, do not use the Stripe Hog until repairs are made to the dump valve.

### Know Your Surroundings

Know your surroundings well – i.e. - truck, hoses, people, walls, moving vehicles, live lanes of traffic, etc.

### Never Blast When Stopped

Always make sure yellow Ultra High Pressure lever is disengaged BEFORE forward or reverse motion is stopped. Damage to road surface will occur if blasting continues when Stripe Hog is brought to a stop.

## 1.3 Nozzle Safety

### Check Flow Rating

Nozzles combined flow rating must be compatible with the pump discharge and pressure rating. Refer to your nozzle flow rating chart in this section.

### Check Pressure Rating

Use only nozzles with a manufacturer's pressure rating of at least the pump's operating pressure or a burst rating of no less than 54,000 PSI.

### Check Orifices

Prior to installation, make sure the nozzles have no clogged orifices. Also, check to ensure nozzles are sharp and not excessively worn.

### Check Connections

Be sure to never force a nozzle into the blasting head. Clean threads to ensure nozzle is not cross-threading. Use an ample amount of anti-seize on threads only, never on the seat of the nozzle. Inspect the seat area on nozzle to ensure a tight seal. If it is damaged, do not use.





## Connect Nozzle

Insert the nozzle into blasting head hand tight. Using a 3/8" socket or box end wrench, tighten the nozzle about 15% more. In some situations, it may be necessary to tighten additionally. Be certain the nozzle seat in the blasting head is in good condition. If it is damaged, replace with a new blasting head.

## Clogged Nozzles

If a nozzle appears clogged, immediately disengage pump. Remove any clogged nozzles and replace with new nozzles. Any particles of the smallest size will clog nozzles. Clogged nozzles can create excessive pressure in pump.

## Remove Nozzle from Service if:

- A) Nozzle is split or damaged.
- B) Nozzle is clogged.
- C) Nozzle water spray is fanned out.
- D) Nozzle's ability to hold pressure is suspect.
- E) Nozzle's hex head is worn excessively from blasting.
- F) Nozzle threads are damaged.

## 1.4 Hose Safety

### Check Pressure Rating

Only Use high pressure hoses with an operating pressure rating of 36,000 - 40,000 psi.

### Check Burst Rating

Do not use a high pressure hose that does not have a listed burst rating or with a burst rating of less than 54,000 PSI.

### Take Care of Your Hose

Protect the hose from contact with sharp objects, abrasive surfaces and foot or wheel traffic.

### Retire Hose from Service if:

- A) Cover is damaged and reinforcing wires are exposed to rust and corrosion.
- B) Cover is loose, has blisters or bulges.
- C) Hose has been crushed or kinked.

- D) End fitting shows evidence of damage, slippage or leakage.
- E) Hose has been exposed to pressures of 2 times the operating pressure.
- F) Hose has been stressed or stretched.

## Check Dump Valve Water Hose

Any hose used for returning dumped water back to the pump or vacuum line must have a large enough diameter and psi strength so that potentially dangerous release pressure is allowed full flow and release pressure is contained safely. Keep hose in good condition.

## 1.5 High Pressure Fitting Safety

### Fitting Ratings

Use high pressure fittings with a rating of 60,000 psi.

### Check Fittings

Do not use fittings that have been cross threaded or have damaged threads.

### Fitting Connections

Use anti-seize compound on ***all*** hose and fitting connections to prevent galling. Do NOT use anti-seize on the seating area of any connections.

## 1.6 Dumping Safety

- A) Drain the Clean Water Tank before dumping. Never leave more than 100 gallons when preparing to dump.
- B) Always dump on level ground, never uneven or sloped ground.
- C) Always choose solid ground, not soft sand or wet soil.
- D) Never allow personnel under raised tank without safety supports in place.
- E) Always be careful to avoid any pinch points which could cause injury.
- F) Always drain all the liquid from the debris tank before dumping the solids.

## Stripe Hog Systems



*SH8000 Stripe Hog*

### 2.1 Truck Chassis

#### Overview

The Stripe Hog SH8000 waterblasting system is mounted on a truck chassis. The operation and maintenance requirements for the engine, drive train and chassis components are unique to the manufacturer and the selected options. Each truck chassis manufacturer provides owners information manuals with their product. It is important that you read the manuals carefully and become familiar with the proper care and operation of engine, drive system, chassis, safety equipment and all components of your truck chassis.

Warranty registration forms are included with the information manuals. All requested information on these forms should be filled out completely and submitted to the dealer or manufacturer as soon as possible.

#### Truck Electrical System

Your truck can be equipped with either a 12-volt or 24-volt DC electrical system depending on your location and the chassis manufacturer. Some, but not all, trucks are equipped with a main battery switch that activates or deactivates the electrical system. If your truck is equipped with a main battery switch, it is usually located just behind the cab near the batteries. The main battery switch is a safety feature that must be turned to the "ON" position before operating the vehicle or waterblasting components.

All truck chassis are equipped with a heavy duty main circuit breaker located just behind the cab near the batteries. The circuit breaker protects the DC circuit that provides electrical power to the cab control panels and the electric solenoids that activate the functions of the PTO, high pressure waterblasting system, hydraulic system and other electrical equipment installed by Waterblasting Technologies.



The circuit breaker is equipped with a yellow indicator/reset lever that indicates the status of the breaker (ON or OFF) and is used to reset the breaker if it trips. A test button near the lever can be pressed to test the breaker to ensure it is operating properly. This is a heavy duty circuit breaker that typically trips only when there is a fault in the system. If it trips, you should find and correct the problem before resetting the breaker. The breaker is reset by turning the yellow lever to the "ON" position. Contact Waterblasting Technologies Customer Service if you need assistance correcting a problem with the Stripe Hog electrical system.

There is another fuse panel inside the main control switch panel in the cab. The fuses in this panel protect the circuits activated by the joystick and control panel switches.

Refer to the information manual for your truck chassis for information on the electrical system on your vehicle.

## Video Systems and Dual Side Steering and Controls (Optional)

Video systems and dual side steering are optional features that enable better visibility for the operator while blasting on the passenger side of the vehicle. The video system also provides improved visibility while backing the vehicle. The Hog Head control console is positioned so that it is available to drivers on either side of the vehicle. Refer to the truck and video manufacturers information for instructions on operating and maintaining video systems and dual side steering and controls.

## Skip Meter

Most trucks are equipped with a "Skip Meter" that records the distance traveled while in Work Mode. When the meter is activated, an inductive sensor records the revolutions of the truck drive shaft and converts the readings into linear feet or meters. The data is recorded and saved until the operator deletes it.

There are two toggle switches on the front of the meter. One toggle switch turns the meter ON or OFF, the other toggle switch is used to start the meter when blasting operations begin and stop the meter when operations stop or are paused. Menu buttons select the meter to read in feet or meters and various recording and data modes. An operating manual for the Skip Meter has been included with your Stripe Hog that provides de-



*Typical Battery ON/OFF Switch  
Main Circuit Breaker*



*Stripe Hog Skip Meter*




*Skip Meter Inductive Pickup on Drive Shaft*


tailed information on its operation and available data modes.

## Side Access Ladders


A ladder on each side of the unit provides access to the Stripe Hog tractor pad or other components located on the chassis between the water tank and the truck cab. Each ladder is hinged and has a spring loaded safety pin that locks the ladder in the stored position. To use the ladder, release the safety pin and rotate the ladder to the down position. Return the ladder to the stored position and secure it with the safety pin when service or inspections are complete.



*Typical Side Access Ladder*



**CAUTION**



**ALWAYS RETURN THE LADDER TO THE STORED POSITION AND LOCK IT WITH THE SAFETY PIN BEFORE OPERATING THE TRUCK. THE LADDER STICKS OUT FROM THE SIDE OF THE VEHICLE AND CAN CAUSE DAMAGE TO THE LADDER, TRUCK OR OTHER VEHICLES IF THE TRUCK IS OPERATED WITH AN ACCESS LADDER DOWN.**


## Tool Boxes

Heavy duty, lockable tool boxes are located on the truck chassis. The tool boxes are used for the storage of hoses, fittings, extra parts and tools. Instructions for routine maintenance and adjusting the latches are located on labels attached to the inside of the each door.


## 2.2 Truck Power System and PTO

All major components of the Stripe Hog are powered by the truck engine. The primary drive system has two modes, Drive Mode and Work Mode. Drive Mode connects the drive shafts from the transmission directly to the differential and is the normal mode for highway driving. Work Mode disconnects the transmission from the differential and connects it to the hydraulic system that powers the hydrostatic truck drive system and all waterblasting features and components.

Controls in the cab allow the operator to switch quickly between Drive Mode and Work Mode. A specially designed gear-box called the "Omsi Drive" facilitates this operation by transferring the energy in the drive shaft from the differential to a system of hydraulic pumps, PTO clutch, and special belts and pulleys that power the high pressure water pump and vacuum blower. Pneumatically activated control levers on the Omsi Drive shift



*Typical Omsi Drive with 40K Clutch*



*Omsi Drive Sight Glass*



the unit from Drive Mode to Work Mode when the PTO switch is activated.

The Omsi Drive, hydrostatic drive and 40K clutch have specific lubrication requirements. The fluid level must be checked weekly to ensure the drive and clutch are full and there are no leaks. The fluid level is monitored by site glasses on the Omsi Drive main gearbox, the hydrostatic drive gearbox and the 40K clutch. Refer to the Omsi Drive operating and maintenance manual for more information on checking fluid levels and routine maintenance for the Omsi Drive and 40K clutch system.

## Shifting the Omsi Drive Modes

Changing from Drive Mode to Work Mode and back again is orchestrated by the PTO switch on the control panel inside the cab. The normal vehicle drive train is disabled and the hydrostatic drive system moves the truck whenever the PTO switch and Work Mode is engaged.

When Work Mode is selected, a key switch in the panel is used to select forward or reverse, the Mode switch engages the transmission in the proper Work Mode gear and a speed dial on the joystick controls the truck speed in forward or reverse (0 - 7 mph.) Engine RPM is typically controlled by the truck cruise control that usually can be quickly disengaged by pressing the brake pedal.

Always make sure the key switch is in the neutral position and the truck speed dial is set to 0 before engaging Work Mode to avoid the possibility for the truck to surge unexpectedly in forward or reverse when the hydrostatic drive is engaged.

The system should only be engaged into Work Mode when the Stripe Hog is on a job site and ready for operations. The truck must be stopped with the engine at idle and transmission in neutral before the Omsi drive can be shifted from Drive Mode to Work Mode. In-cab instructions are visible to assist in the start-up and shut-down procedures for the operation of the unit. The instructions are specific to each unit as there are differences between truck chassis, transmissions and drive trains. There are also significant differences between foreign and domestic (USA) truck chassis.

The control panel has lighted switches, gauges and indicator lights that show the system function and operation. A green light indicates the system is ready for normal driving. A red light indicates



Control Switch Panel



Work Mode Gears Selected with Mode Switch

### EMERGENCY SHUT DOWN

Engine to Idle - Transmission to "N"

START UP PROCEDURE	SHUT DOWN PROCEDURE
1. All Switches "OFF" or set to "0"	1. 40K PSI "OFF" (Stop)
2. Transmission in "N" (green light on)	2. Engine set to idle
3. Start Engine	3. 40K Clutch "OFF"
4. System PTO on (wait for red light)	4. Truck Transmission to "N"
5. Select MAN PTO	5. MAN PTO "OFF"
6. Select Gear (8 high or 6 high)	6. System PTO "OFF" (wait for green light approx. 15 seconds)
7. Charge Pump "ON" (check for 60 PSI)	7. All switches set to "OFF"
8. 40K Clutch "ON"	
9. Set Engine RPM's to (1000) with cruise control	
10. Press Start Switch	
11. Set PSI with cruise control (40K Max)	

A. Operate Arm  
B. Dump Tank  
C. Move Truck Hydraulics  
D. Operate Charge Pump

Implement Mode


**WARNING** NEVER SWITCH SYSTEM PTO WHEN TRUCK TRANSMISSION IS IN DRIVE POSITION **WARNING**

Typical In-Cab Instruction Label


INSTRUCTION LABEL SHOWN IS A SAMPLE AND MAY NOT BE THE SAME AS THE ACTUAL IN-CAB INSTRUCTIONS ON YOUR STRIPE HOG



the system is engaged for Work Mode operation. It is important when disengaging the system to "LISTEN" for disengagement and then watch for the green light indicating the waterblast system is inoperable. This is necessary to insure none of the waterblasting equipment functions are operable during normal driving of the truck.




**WARNING**




THE TRUCK COULD SURGE FORWARD OR BACKWARD UNEXPECTEDLY WHEN WORK MODE IS SELECTED IF THE KEY SWITCH IS IN FORWARD OR REVERSE AND/OR THE SPEED CONTROL DIAL IS NOT SET TO 0. ALWAYS MAKE SURE THE TRUCK SPEED CONTROL DIAL IS SET TO 0 AND THE KEY SWITCH IS SET TO NEUTRAL BEFORE ENGAGING "WORK MODE."



*Typical Drive Belt Configuration for PTO Clutch Powered UHP Pump and Vacuum Blower*



**WARNING**



IT IS NOT POSSIBLE FOR THE OPERATOR TO SEE PEOPLE OR OBSTACLES THAT ARE IMMEDIATELY BEHIND THE TRUCK IF YOUR UNIT IS NOT EQUIPPED WITH A REAR VIDEO CAMERA. ALWAYS PUT THE TRUCK IN PARK, SET THE PARKING BRAKE AND CHECK BEHIND IT BEFORE DRIVING IN REVERSE. IF YOU HAVE AN ASSISTANT, HAVE HIM STAND AT THE REAR OF THE TRUCK AND DIRECT YOU.

## Omsi Drive PTO clutch

The Power Take-Off (PTO) clutch provides power to the belts and pulleys that drive the high pressure pump and vacuum blower. It is a hydraulic, multi-disc clutch that is controlled by the 40K Clutch switch in the control panel and available whenever the Omsi Drive is engaged in Work Mode.

Refer to the Omsi Drive operating manual for additional information on the PTO clutch.


## 2.3 Primary Drive Belts

The primary drive belts that connect the PTO 40K clutch to the high pressure pump and vacuum blower are special carbon fiber industrial belts that are designed for high horsepower applications.


The ribbed drive belts are matched to grooved pulleys and have very little stretch. Therefore, they typically don't require adjustment often and proper belt tension is extremely important when

adjustment is required. The belts are strong enough to cause severe damage to bearings, shafts and other components if they are set too tight. Additionally, if a belt is too loose, it can ride on top of the grooves and thus become too tight.

The drive belts for the high pressure pump and vacuum blower are different and, therefore, have different tension specifications. Additionally, new belts have a different tension specification than used belts (drive belts with 20 hours or more). Instructions for adjusting the primary drive belts and tension specifications are included in the Maintenance section of this manual.



**WARNING**




THE PRIMARY DRIVE BELTS CAN CAUSE SEVERE DAMAGE TO PULLEYS, SHAFTS AND BEARINGS IF THEY ARE ADJUSTED TOO TIGHT OR MISALIGNED. THIS CAN CAUSE SEVERE DAMAGE TO DRIVE SYSTEM COMPONENTS AND INJURY TO PERSONNEL IF DAMAGED COMPONENTS ARE THROWN FROM THE MACHINE. ALWAYS MAKE SURE THE BELTS ARE PROPERLY ALIGNED AND SET TO THE BELT MANUFACTURER'S SPECIFICATIONS WHEN THEY REQUIRE ADJUSTMENT. NEVER OVERTIGHTEN THE BELTS.

Make sure you refer to the belt tension specifications in the Maintenance section of this manual or the belt manufactures information manual when adjusting the belt tension and never overtighten them.



*Hydraulic System Reservoir and Fluid Level & Temperature Gauge*



*Hydraulic System Solenoid Valves and Gauges*

## 2.4 Truck Hydraulic System

### General

The Hog Head and hydraulic Hog Arm is mounted to the front of the truck. All movement and the rotation of the spray bars are activated and controlled by the hydraulic system.


The hydraulic system is powered by the truck engine activated by the PTO switch in the control switch panel. It is equipped with a pump, large reservoir/cooling tank and an in-line filter. An oil cooler with a thermostatically activated fan cools the hydraulic fluid during operation. Electric solenoid valves activated by switches in the control panels direct hydraulic pressure to the various components. The hydraulic oil level and temperature is monitored by a site gauge and thermometer on the side of the reservoir.

The in-line filter is equipped with an indicator that alerts the operator when the filter is dirty and requires changing. Additional filtration is provided by a filter screen built into the fill cap assembly

The hydraulic system provides the hydraulic power for the hydrostatic truck drive system, the Hog Arm, the hydraulic motors that rotate the Hog Head spray bars and the charge water pump. It also provides hydraulic power to the cylinder that lifts the water and debris tank to dump the debris when the debris tank is full.



*Hydraulic System Oil Cooler with Thermostatically Controlled Fan, In-Line Filter and Filter Change Indicator*



*Hydraulic System Fill Cap and Filter*





*Truck Mounted Hog Head*

## 2.5 Truck Mounted Hog Head

The Hog Head and Hog Arm are mounted to the front of the chassis, just forward of the bumper. The hydraulic system provides the power for all functions of the Hog Arm and the hydraulic motors that rotate the spray bars on the Hog Heads.

The high pressure water pump provides ultra high waterblasting pressure to the rotating spray bars and the vacuum blower provides the vacuum. A joystick and control switch panel in the cab control all functions of the Hog Head and control arm. The Hog Head is a two blast head design. The blast heads are mounted on one Hog Arm and operate simultaneously.

Auxillary connectors for high pressure water and DC power are located on the bumper near the Hog Head. The connection provides high pressure water and DC power for Waterblasting accessories or Hog Tools that can be powered by the SH8000 systems.

### Hog Head Hydraulic System

The hydraulic system is powered by the truck engine. The truck must be in "Work Mode" with


the PTO engaged before the hydraulic system will operate. A control panel and joystick in the cab controls all hydraulic functions of the Hog Arm. The Hog Head can be moved up and down, right and left or can be set to float, which allows the Hog Head to freely move up and down with the contour of uneven surfaces. When the Hog Arm is raised to the full up position, it will automatically lock. This lock is a safety feature that prevents the Hog Arm from being lowered accidentally while the vehicle is operating in Drive Mode.

The operator must release the Hog Arm lock manually before it can be lowered. Make sure the truck is stopped with the parking brake set before manually releasing the Hog Arm lock.

### Notice:

**If the lock will not release, the hydraulic system will have to be engaged and the hog head raised to relieve the strain on the lock. Additionally, the lock handle should be secured with a plastic tie wrap or other type of fastener to ensure it cannot accidentally release while driving.**





*Typical Control Switch Panel  
The panel on your unit may be slightly different*

## Control Panel and Joystick

### Control Panel

All functions and features of the waterblasting system are activated by labeled switches in the main control panel. There are also switches that activate the hydrostatic drive forward and reverse, work lights and strobe lights. Accessory switches activate the optional video system or other optional accessories that may be installed by Waterblasting Technologies. Individual fuses in a fuse panel located inside the control switch panel protect the circuits activated by the switches.

There is no power available to the control panel until the PTO switch is activated. The PTO switch uses power from the truck's ignition system to energize a relay inside the control panel which then provides power to the individual rocker switches that control other functions.

There are two red LED lights and one green LED light on the control panel. The lower red LED light indicates low gear box oil pressure. The upper

red LED light indicates the system is engaged into Work Mode. The green LED light indicates the truck is engaged in normal Drive Mode. LED lights in the switches illuminate when the function is activated. If no features are activated by accessory switches, they will be wired in reserve for equipment or options that may be installed at a later date.

It is important to note that once the PTO has been engaged or disengaged, the appropriate LED be lit before engaging the automatic transmission. When the Omsi Drive is engaged in Work Mode, the engine RPM is controlled with the truck cruise control. Typically the RPM is set to provide the desired water pressure and vacuum for the current operation. Normally tapping the brake pedal will immediately deactivate the cruise control and return the engine to idle in either drive mode.

Refer to the truck chassis manual for information on the operation of the cruise control in your truck.



## Joystick Panel

The Hog Arm, truck speed (hydrostatic drive in "Work Mode"), and spray bar rotation speed are controlled by the joystick and speed dials in the joystick panel. Separate digital gauges monitor the vacuum, charge pressure and ultra high pressure in the waterblasting system.

The joystick controls the Hog Arm. Move it forward to lower the arm, pull it back to raise it. Move it to the right and the hog arm moves right, move it left and the arm moves left. The "trigger" on joystick controls which stage of the Hog Arm moves right and left with the joystick. When the "trigger" is not activated, the joystick controls the 1st stage of the arm and moves the entire Hog Arm right and left. When the "trigger" is activated, the joystick moves only the 2nd stage of the Hog Arm (the portion forward of the center hinge) for more precise positioning of the Hog Head. When the joystick is released, the handle automatically returns to center and the Hog Arm stops in that position. A rocker switch in the joystick panel activates and deactivates the Hog Head float feature that enables the Hog Head to float freely over uneven contours.

The Truck Speed dial rotates to control the speed of the truck (0-7 MPH) while in "Work Mode" (hydrostatic drive engaged.) The Head Rotation dial controls the speed of the Hog Head spray bars. Rotating the dial clockwise increases speed and rotating it counterclockwise reduces speed. Setting the Truck Speed dial to 0 will stop the truck motion, setting the Head Rotation dial to 0 will stop the rotation of the spray bars.

## Hog Heads

The Hog Heads are attached to the end of the Hog Arm. There are two blasting heads supported by a chassis with three heavy duty castors that support the Hog Head at a preset height and prevent the spray bar from contacting the pavement. Spacers on each caster adjust the height of the Hog Head. Adjustment may be required to maintain proper clearance by adding spacers as the caster wheels wear.

The wear brush is clamped to the blast head shroud and provides a partial seal between the Hog Head and the pavement. The wear brush regulates vacuum air flow into the Hog Head and reduces the amount of debris and water exiting the blast head during waterblasting operations. The wear brush is a important safety feature of the Hog Head and must be adjusted as it wears



*Joystick Control Panel with Speed Dials, Pressure Gauges, UHP Switch and Float Mode Switch*



*Hog Heads, Casters and Wear Brush*

and replaced as necessary. It should always be adjusted so the brushes are making light contact with the pavement.

To adjust the wear brush, lower the Hog Head to the ground and note the gap between the wear brush and the pavement. Raise the Hog head, loosen the clamp on the blast head and slide the wear brush enough to eliminate the gap. Tighten the clamp and recheck. Readjust if necessary.


**Notice:**

**Always make sure to check the Hog Head for smooth and proper operation before each shift. Do not use equipment that has not been checked thoroughly.**


Double Hog Head assemblies swivel to enable the operator to control the width of the blasting area (4"/10.2cm to 28"/71.1cm) or set the Hog Heads to remove two separate lines simultaneously. The head orientation on the Hog Arm can be preset in nine positions using the cam lock pin in the center of the Hog Head. To adjust the position, raise the cam lock lever, swivel the Hog Head to the desired position and lock it in place with the cam lock pin. Additional adjustments to head orientation can be made with the joystick in the cab by changing the blast head orientation in relation to the direction of travel with the Hog Arm.

The spray bar is rotated by a thru-shaft hydraulic motor or a hydraulic motor attached to a belt driven swivel shaft. The rotation speed is controlled by the head rotation dial in the joystick panel. The center of the rotating shaft is drilled to allow high pressure water to pass through the shaft to the spray bar. A special swivel seal assembly provides a positive seal for the connection to the high pressure hose while allowing the thru-shaft to turn freely. The hose is secured to the rotating shaft housing by the swivel nut. The swivel nut is hand tightened. If the nut becomes loose, the hose will wobble and damage the swivel seal. Additionally, if the swivel nut is overtightened by using a pipe wrench or pliers, the swivel seal will be damaged. The swivel nut must be checked daily to ensure it is tight and that the swivel seal is not leaking. Any water dripping from the weep holes just below the swivel nut while the system is pressurized indicates the seal is leaking and must be replaced. Operating the Hog Head with a leaking swivel seal will cause complete failure of the seal, stopping blasting operations and could cause severe damage to the thru-shaft motor or swivel shaft.

The spray bar is a quick change design. Spray bars are available in 6", 8", 10", 14", widths. Aggressive and non-aggressive patterns are available for all heads.



*Hog Head Swivel Cam Lock and Belt Driven Swivel Shaft*



*Typical Thru-Shaft Motor and Swivel Nut*



*Swivel Seal on Thru-Shaft Motor*



If you are new to waterblasting equipment, Waterblasting Technologies offers a variety of spray bar and nozzle configurations to meet the requirements of most paint and rubber removal projects. Examples of available spray bar configurations are included in the Appendix section of this manual. You can also contact Waterblasting Customer Service for assistance in selecting the right spray bars for your project.

To change a spray bar, hold the shaft by inserting a 3/4" wrench into the slot at the bottom of the thru-shaft housing, located just above the blast head shroud. Twist the spray bar counterclockwise by hand until it is free of the shaft. Purge the blast head at low pressure, then apply anti-seize to the threads, insert a new brass button seal and install the new spray bar by turning it clockwise *slowly* until it seats. Then tighten it by turning the spray bar another 15%. Make sure you remove the wrench when the installation is complete.

### Notice:


**Before attaching the new spray bar to the Hog Head Assembly, engage pump at low pressure to purge the system. Any dirt or debris in the system can clog nozzle orifices and cause system pressure to spike excessively causing damage to components or the rupture discs on the UHP pump to burst. Refer to the Stripe Hog Training DVD for detailed information on changing the spray bar.**

The dirt shield that protects the thru-shaft is located between the spray bar and blast head shroud. It consists of a special felt seal that is held against the bottom of the blast head shroud by a stainless steel flat washer threaded on the shaft. The felt seal should be inspected and adjusted whenever the spray bar is removed. The dirt shield should be replaced if it is damaged or worn and be adjusted "finger tight." If it is too tight it will prevent the spray bar from rotating.


With the spray bar installed, operate the pump at low pressure to check for nozzle accuracy and leaks on the spray bar or nozzles. Water dripping from any of the weep holes in the side of the spray bar indicates that a nozzle is not seated properly. Leaks at the nozzle seats or thru-shaft threads must be corrected before beginning high pressure operations or the spray bar will be ruined. Should any repairs or adjustments be necessary, disengage the pump to relieve all pressure before making any required repairs or adjustments.



*8 and 16 Nozzle Spray Bars*



*Spray Bar Removed and Dirt Shield  
Button Seal on Thru-Shaft and Anti-Seize on Threads*



*Spray Bar and Nozzles Installed  
Anti-Seize on Nozzle and Spray Bar Threads*


Each spray bar is equipped with a spray bar protector that is held in place with one or two cotter pins, depending on the size of the spray bar. The spray bar protector shields the nozzles and spray bar from damage caused by debris during blasting operations. Never waterblast without the spray bar protector installed. Spray bars and nozzles are expensive and the life of the nozzles and spray bars will be dramatically shortened without the spray bar protector.

**Never blast when stopped. Damage to road surface will occur if blasting continues when the stripe hog is brought to a stop.**

## 2.6 Waterblast System

The ultra high waterblasting system consists of a water storage tank, charge pump, ultra high pressure (UHP) pump, high pressure hoses and the Hog Heads. Switches in the control and joystick panels in the truck cab or on the tractor enable the operator to control all aspects of the high pressure blasting system from the cab of the truck or the tractor.

Each manufacturer of the high pressure waterblasting system components provides an information and operating manual with its product. It is extremely important that you read the manuals and become familiar with the proper care and operation of the components before operating the waterblasting system.



*Spray Bar with Nozzles Installed and Weep Holes*



*Spray Bars with Spray Bar Protectors Installed*



### WARNING



HIGH PRESSURE WATER FROM SPRAY JETS OR RUPTURED HOSES CAN CAUSE SEVERE INJURY OR EVEN DEATH. ALWAYS BE SURE WORK AREA IS CLEAR OF PEOPLE, HANDS, FEET, ETC., BEFORE ENGAGING THE 40K CLUTCH/HIGH PRESSURE SWITCH FOR THE STRIPE HOG.

## Clean Water Tank

The forward tank on the rear of the truck chassis is reserved for the pressure water supply. The inner tank is stainless steel to reduce corrosion and provides a supply of clean, fresh water to the charge pump. A site tube on the side of the tank indicates the water level and a 4" valve allows for quick draining of the tank. The fill connection on the passenger side of the tank accommodates large hoses, such as a fire hose, that are typically connected to a metered fire hydrant to expedite the filling of the tank. Make sure to flush the fill



*Clean Water Tank and Fill*

source with twice the water flow as used to fill the tank to reduce the risk of debris entering the clean water tank.



The tank should be flushed frequently with clean, fresh water to prevent the accumulation of debris that may accidentally enter the tank during filling. It must be thoroughly cleaned if the tank was filled from a contaminated water source or if the source was not properly flushed prior to filling. A ladder on the side of the tank provides access to the top and a large hatch provides access to the inside of the tank for inspection or to facilitate cleaning, if necessary.

## Charge Water System

The water tank provides clean fresh water to the low pressure charge pump. The charge pump is hydraulically powered and activated by the Charge Pump switch in the control panel. It delivers water to Ultra High Pressure Pump and should maintain a minimum of 40 PSI (2.8 Bar) on the Charge Pressure gauge located in the Joystick panel. A green LED light in the switch illuminates when the charge pump is activated.

### Notice:

**The UHP pump can cavitate if the charge water pressure drops below 25 PSI (1.7 Bar.) Cavitation can cause severe damage to the UHP pump and should never be allowed to occur. You should always monitor the charge water pressure and never operate the UHP pump when the charge water pressure drops below 30 PSI (2.1 Bar.)**

The charge pump impeller will be damaged if the pump is allowed to run dry for more than a few seconds. Always monitor the water level in the clean water tank and make sure you have enough water for the intended shift. Never operate the charge water pump when the water tank is low on water and always stop blasting, turn off the charge pump and disengage the 40K clutch immediately when low water or low charge pressure is observed.

Water supply problems to the charge pump can also be indicated by the sound of the pump. Fluctuating pump RPM, inconsistent high pitch whines, and fluctuating charge water pressures are indications of a water supply problem to the charge pump. You should be familiar with the normal sound of the pump and stop blasting if the sound changes. Find and correct the problem before waterblasting operations resume.

Two filters in the supply line between the charge pump and high pressure pump remove any small debris that may accidentally find its way into the



*Charge Water Pump and Drain Valve*



*Charge Water Filters  
Top Filter is 10 Micron (Nominal) Bag Type Filter  
Bottom is 1 Micron (Absolute) Cartridge Type Filter*

water supply tank. The first filter is a 10 micron (Nominal) filter to trap larger particles and the second filter is a 1 micron (Absolute) filter to trap small particles that pass through the first filter.

The filters are critical to the proper operation of the high pressure blasting system and should be checked frequently and replaced as necessary. Dirty charge water filters are the number one reason for low charge water pressure that can cause the UHP pump to cavitate and reduce the flow of lube water to the packing seals. Therefore it is normal and recommended that the filters be checked frequently and changed whenever the charge water pressure drops below 40 PSI (2.8 Bar.)

Please remember that the filters can be under pressure. Always make sure the charge pump is

off, the PTO disengaged and the pressure has been bled from the system before removing the filter caps. You should also make sure to thoroughly flush the filter canisters and charge water system when the filters are changed and before activating the UHP pump.

A valve located on the low pressure (charge water) side of the pump can be opened to flush the charge water side of the pump if the system becomes contaminated. This valve is also used to assist in purging the system after a filter change or adding anti-freeze in cold weather operations.

A supply of clean fresh water is critical to the proper operation of a high pressure waterblasting system. You should only use clean fresh water from a potable water source, usually a fire hydrant, and make sure to keep supply hoses and the area around the tank fill valve clean. Never use water drawn from retention ponds, canals or other non-potable sources.


## Packing Lube Water and Bilge Pump

Lube and cooling water for the plunger packing is provided by three cooling lines connected to a manifold in the charge water supply line near the pump connection. A metering valve for each line controls the flow of water to the packing. Lube water is supplied whenever the engine and charge pump are operating.

The water flow to the packing should be checked at the beginning of each shift by monitoring the flow of water from each packing with the PTO engaged, the charge pump activated and the engine at idle. There should be a noticeable flow of water from each packing. If necessary, use the metering valves to adjust the flow. If no water is flowing from any of the packing glands, find and correct the problem before operating the pump. Refer to the high pressure pump operation manual for more information on adjusting the packing lube water.

Packing lube water is drained from the high pressure pump by a bilge pump drain system. The system is completely automatic and activated whenever the main battery switch is ON. A fuse in the control switch panel protects the bilge pump circuit from an overload.


Water drains from the high pressure pump by gravity to a sump box equipped with an automatic switch that is connected to the bilge pump. When the water level in the sump box raises enough to



*Charge Water/Low Pressure Purge Valve*



*Packing Lube Water Lines & Metering Valves*



*Packing Glands and Lube Water Lines*



activate the automatic switch, the bilge pump is activated and pumps the water from the sump box to the debris tank. When the water level in the sump box is lowered, the switch will turn the pump off.

The sump automatic switch and inside of the sump box are accessed by removing the sump box lid. It is important to periodically remove the lid to inspect the switch and clean out accumulated debris that can restrict water flow to the pump.

## Ultra High Pressure System

Clean, fresh water is supplied to the high pressure pump by the charge pump. The high pressure pump is powered by the main truck engine through the PTO and is activated by the 40K Clutch switch in the control panel. The switch also activates the solenoid which enables the hydraulic rotation of the spray bars that are controlled by the Head Rotation dial. Green LED lights in the switches illuminate to indicate the pump and spray bar hydraulic rotation are activated. When the system is activated, the ON/OFF UHP switch on the joystick console supplies or turns off the high pressure water to the Hog Head spray nozzles.


When the high pressure is turned off by the switch, the dump valve, located on the UHP pump is activated to divert the water from the Hog Head pressure lines to the bypass line and back to the clean water tank. The Dump Valve is a safety feature that enables the high pressure water supply to the blast head to be immediately reduced to less than 500 PSI (34.474 Bar) at any time without causing damage to the high pressure lines and components.

Maximum operating pressure for the UHP pump of 40,000 PSI (2,758 Bar) @ 12 gallons (45 Liters) per minute is achieved at maximum engine RPM. (typically 1400 RPM) The water pressure is monitored by the High Pressure gauge on the pump and a digital gauge in the joystick panel. High pressure is controlled by the RPM of the engine and/or by adjusting the manual bypass valve on the pump. Since engine RPM also controls the level of vacuum, adjusting the pressure using the manual bypass valve is beneficial when maximum engine RPM is required for vacuum and less than maximum waterblasting pressure or gallons per minute is desired for the material being removed or the waterblasting tools being used.

The UHP system is activated by engaging the PTO clutch and setting engine RPM to the desired op-



*Bilge Pump*



*UHP Pump, Dump Valve and Manual Bypass Valve*

erating pressure setting (typically 800 RPM - 1400 RPM max.) There may be some variation of this depending on the engine and other components unique to your unit. When setting pressure **ALWAYS** ensure that the system pressure drops to less than 500 PSI (34.475 Bar) immediately when the UHP switch is turned off. If this does not relieve system pressure immediately to below 500 PSI when released, do not use the equipment until repairs are made to the dump valve.

The high pressure pump is a positive displacement pump that requires a constant water supply at a minimum of 30 PSI (2.1 Bar) from the charge water system to operate properly. Always make sure there is enough water in the tank before engaging the PTO to activate the UHP and charge pump systems. Pressure gauges for the charge water system are near the water filters and on the joystick panel. Pressure gauges for the UHP system are located on the UHP pump and on the

joystick panel. The gauges should be monitored frequently whenever waterblasting operations are underway. If the pressure rises or drops outside of the normal operating range in either system, stop waterblasting operations immediately, turn off the charge pump and disengage the PTO. Then find and correct the problem before resuming blasting operations.

## Notice:

**A pressure switch in the charge water supply line near the UHP pump monitors charge water pressure and automatically shuts down the UHP system by disengaging the PTO if the charge water pressure drops below 25 PSI (1.7 Bar.) This is a safety feature to prevent damage to the UHP pump from cavitation caused by low charge water pressure.**

## Rupture Discs

Rupture discs are installed on the high pressure side of the UHP pump to protect the waterblasting system against unusually high spikes in pressure. The discs are designed to burst and immediately relieve pressure when the system water pressure exceeds the disc burst pressure. If a rupture disc bursts it will have to be replaced before waterblasting operations can resume, therefore, you should keep spare rupture discs of the proper pressure rating on hand. You should test the system at low pressure and correct the problem that caused the disc to burst before resuming high pressure operations.

Rupture disc burst pressure ratings are unique to each unit and critical to operator safety. Refer to the label on the rupture disc assembly or contact Waterblasting Customer Service for the correct rupture disc rating for your equipment. **Never install a rupture disc with a burst pressure rating higher than recommended.**




## WARNING



EXCESSIVE PRESSURE IN THE HIGH PRESSURE BLASTING SYSTEM CAN CAUSE EXTENSIVE DAMAGE TO EQUIPMENT AND SEVERE INJURY OR EVEN DEATH TO PERSONNEL. IF A RUPTURE DISC BURSTS IT USUALLY INDICATES A PROBLEM THAT NEEDS TO BE CORRECTED BEFORE WATERBLASTING OPERATIONS CAN RESUME. NEVER INSTALL RUPTURE DISCS WITH A HIGHER BURST RATING THAN RECOMMENDED.

The filters in the charge pressure line immediately before the UHP pump remove any debris prior



Rupture Discs and Manual Bypass Valve

to the water entering the high pressure system. These filters prevent damage caused by debris in the high pressure system and are critical to the proper operation of the waterblasting system. They should be checked frequently and replaced as necessary, typically daily or when the charge water pressure drops below 40 PSI (2.8 Bar.) Even the smallest debris can cause severe damage to components in the ultra high pressure system.

Refer to the Charge Water System in this section for information on the water filters and the pump manufacturer's operating manual for instructions on operating and maintaining the Ultra High Pressure Pump. You should also refer to the Stripe Hog Training video available on DVD or online at [www.stripegohogsupport.com](http://www.stripegohogsupport.com) for additional instructions on maintaining the high pressure pump.

Each manufacturer of the major UHP waterblasting system components provides an information and operating manual with its product. It is extremely important that you read the manuals and become familiar with the proper care and operation of the components before operating the waterblasting system.



## WARNING




HIGH PRESSURE WATER FROM SPRAY JETS OR RUPTURED HOSES CAN CAUSE SEVERE INJURY OR EVEN DEATH. ALWAYS BE SURE WORK AREA IS CLEAR OF PEOPLE, HANDS, FEET, ETC., BEFORE ENGAGING THE PTO AND THE HIGH PRESSURE SWITCH FOR THE STRIPE HOG.




## High Pressure Hoses and Fittings

The SH8000 waterblasting system operates at ultra high pressures of up to 40,000 PSI (2,758 Bar). Therefore, it is critical that the operator and maintenance personnel inspect the high pressure hoses, fittings, nozzles and other components frequently. A visual inspection of the high pressure system should be conducted each day before operating the unit. Any hose or component that is questionable or shows any sign of deterioration, wear or leakage should be replaced immediately and before operating any waterblasting equipment. A more thorough inspection of all high pressure pumps and components should be conducted at each routine service interval.

Check the condition of threads prior to connecting any fittings or hoses. Use an anti-seize compound on all fitting and hose threads to prevent "galling." Galling is the term for thread damage that occurs from heat build up in the threads of stainless steel fittings as they are tightened. Galling will destroy the threads and lockup the fittings before they are tight, destroying the fittings and/or hose ends rendering them unusable. Be careful not to get anti-seize on the seating area of any fitting. Always test the system with the Hog Head up following repairs or at the start of each shift by operating the system at low pressure first. Then slowly bring the equipment up to operating pressure while carefully monitoring the replaced components.



**WARNING**



**REFER TO THE GENERAL SAFETY SECTION OF THIS MANUAL FOR A LIST OF PRECAUTIONS TO BE OBSERVED WHEN OPERATING OR SERVICING ULTRA HIGH PRESSURE EQUIPMENT. USE ONLY THOROUGHLY TRAINED PERSONNEL TO PERFORM MAINTENANCE OR REPAIRS ON THE HIGH PRESSURE SYSTEM.**

Take care of Your Hoses. Protect the hoses from contact with sharp objects, abrasive surfaces and foot or wheel traffic. Add additional anti-chaffing material to protect hoses when necessary. Never operate the high pressure system with a hose that is questionable.

When replacing damaged or worn hoses, check the burst rating marked on the hose. Do not use a high pressure hose that does not have a listed

burst rating or with a burst rating of less than 54,000 PSI (3,723 Bar).

### Retire a Hose from Service if:

- A) Cover is damaged and reinforcing wires are exposed to rust and corrosion;
- B) Cover is loose, has blisters or bulges;
- C) Hose has been crushed or kinked;
- D) End fitting shows evidence of damage, slippage or leakage;
- E) Hose has been exposed to pressures of 2 times the operating pressure.
- F) Hose has been kinked, stressed or stretched.

## High Pressure Nozzles and Spray Bars

Each nozzle delivers a stream of water at extremely high pressure. The size and intensity of the stream is determined by orifice size in the nozzle. The performance ranges from least aggressive to most aggressive.

Nozzles typically last 12-16 hours of blast time, however, you could experience shorter or longer nozzle life, depending on the type of surface being blasted. They should be inspected before the start of each shift or when the operator notices a change in performance while waterblasting.

Nozzles are easy to replace and different nozzle sizes in a variety of spray bar configurations can be selected to accommodate the material to be removed and the type of substrate. The nozzle flow chart and spray bar configuration diagrams located in the Safety Information section and Appendix C will provide assistance in choosing the best nozzles for the job. As the operator becomes more experienced, nozzle selection becomes easier. You can also contact Waterblasting Customer Service for assistance in selecting the proper spray bar and nozzle configuration for your job.

To check the nozzles on the Hog Head spray bars, raise the hog head, set the parking brake, activate the high pressure system and set the operating pressure to a safe level. Make sure the head rotation speed dial is set to 0 so the spray bars do not rotate. Staying well clear of the water jets, visually inspect the spray pattern of each nozzle. If the spray is tight with a cohesive stream for 1/2 - 1 1/2 inches from the nozzle, it is good.

## Remove Nozzle from Service if:

- A) Nozzle is split or damaged;
- B) Nozzle is clogged;
- C) Nozzle water spray is fanned out;
- D) Nozzle's ability to hold pressure is suspect;
- E) Nozzle's hex head is worn excessively from blasting.
- F) Nozzle threads are damaged.

Refer to the Stripe Hog Training video available on DVD or at [www.stripehogsupport.com](http://www.stripehogsupport.com) and the Hog Head Maintenance section of this manual for instructions on changing nozzles.



*Good Nozzles*




## DANGER



THE HIGH PRESSURE STREAM FROM THE SPRAY NOZZLES CAN CAUSE SEVERE INJURY OR DEATH IF IT COMES IN CONTACT WITH HANDS, FEET OR ANY PART OF A PERSON'S BODY. IT CAN ALSO PROJECT LOOSE DEBRIS IN THE AREA OF THE HOG HEAD WITH ENOUGH FORCE TO CAUSE SERIOUS INJURY, PARTICULARLY TO THE EYES. HIGH PRESSURE WATER CAN TEAR OFF SKIN AND INJECT WATER DIRECTLY INTO THE BLOOD STREAM WHICH CAN BE FATAL. ALWAYS DEACTIVATE THE HIGH PRESSURE SYSTEM BEFORE RAISING THE HOG HEAD AND MAKE SURE THE AREA IS CLEAR OF PEOPLE, HANDS AND FEET BEFORE ENGAGING THE PTO AND 40K PSI SWITCH FOR THE HIGH PRESSURE SYSTEM TO CHECK THE NOZZLES WITH THE HOG HEAD RAISED.

When replacing nozzles make sure to check the flow and pressure rating and use only nozzles with a manufacturer's pressure rating of at least the pump's operating pressure or a burst rating of no less than 54,000 PSI (3,723 Bar.) We recommend that you only use nozzles, high pressure hoses and fittings supplied by Waterblasting Technologies to ensure the nozzles and other components are compatible with your Ultra High Pressure Waterblasting System.

Prior to installation, make sure the nozzles have no clogged orifices. Also, check to ensure nozzles are sharp and not worn. To prevent galling, make sure to apply anti-seize to the threads before installing the replacement nozzle and be careful not to get anti-seize on seating area of the nozzles.



*Bad Nozzle*

## Notice:

To increase the life of the spray bars and nozzles, always remember to install the spray bar shield after testing the nozzles and before beginning blasting operations.



## 2.7 Vacuum System

### Vacuum System

The vacuum system is powered by the main truck engine and is activated whenever the PTO and 40K Clutch is engaged. The blower creates vacuum in the filter canister, debris tank, vacuum hoses and Hog Head. A filter located in the filter canister protects the blower.

Flexible hoses with quick disconnect fittings provide vacuum to the truck or tractor mounted Hog Head. Special swivel brackets and/or a swing arm boom allow the hose to move with the Hog Head or optional tractor. The boom helps prevent the hoses from dragging on the ground when the tractor or other Hog Tools are used.

The blower bearings require lubrication daily using special grease specified by the blower manufacturer. Refer to the Lubrication Chart in the Maintenance section of this manual and the blower manufacturer's manual for lubrication specifications and additional information on the operation and maintenance of the blower.

The vacuum is monitored by a digital gauge in the control switch panel or an optional gauge on the vacuum tank. It is adjusted by increasing or decreasing the engine RPM. Thus, maximum vacuum, -7 PSI (-.5 Bar,) is typically achieved at 1400 RPM (Maximum engine operating RPM.) Relief valves (Kunkle Valves) on top of the vacuum canister and the debris tank will automatically open if they sense excessive vacuum in the system. Always test these valves and all vacuum hose connections at the start of each shift to ensure the valve is operating properly and there are no vacuum leaks in the system.

The blower components have extremely small tolerances and must be protected from the debris. The vacuum filter should be cleaned daily. The canister is equipped with a door in the side that provides easy access to the filter and a means to inspect the canister for excessive debris, water or to clean the filter. There is a manual drain valve at the bottom to remove water from the canister as needed. Make sure the vacuum system is shutdown before opening the canister door or attempting to drain the water and never leave the drain valve open when the vacuum system is operating.



*Vacuum Blower System*



*Vacuum Canister, Kunkle Valve and Drain Valve*

## Notice:

Make sure the drain valve is closed, the canister door seal is clean and the door is properly latched before operating the vacuum system. The system will not be able to develop enough vacuum if the canister door is not sealed and latched or the drain valve is open.

It is normal for some water to travel to the vacuum filter canister, therefore, it should be drained each time the debris tank is drained or at least once every 2 hours of operation. **Remember that excessive water in the canister can pass through the filter and cause severe damage to the blower. Always make sure the 40K Clutch is disengaged to stop the vacuum blower before draining the filter canister and always close the drain valve when draining is complete.**

## Vacuum Hoses

The primary, 6" vacuum hose runs from the cutoff ball valve connection on top of the debris tank to the vacuum hose connection on the vacuum filter canister. Another 4" debris suction vacuum hose runs from the debris inlet elbow on the top of the debris tank to the Hog Head and/or boom assembly for the tractor. The hoses are equipped with quick connectors at the Hog Head and/or boom and ends that allow additional 4" vacuum hoses to be added or for servicing Hog Head vacuum hoses and components. Other quick connectors provide access to other components of the vacuum system. The SH8000 can provide enough vacuum and water pressure to operate Waterblasting equipment up to 400' from the unit.

Consistent and proper vacuum is important to the proper operation of the vacuum system. Debris buildup, kinks, damage or leaks will cause a reduction in vacuum at the blasting head, reducing the efficiency of operation or cause operations to stop completely. Many problems with vacuum hoses are caused by damage or kinks. You should avoid tight bends and maximize the radius of all hose curves to minimize the chance of a kink. It is very important to protect the hoses from contact with sharp objects, abrasive surfaces, foot or wheel traffic and to inspect the hoses daily to ensure there is no damage, signs of chaffing or kinks.

The inside walls of vacuum debris suction hoses develop wear points caused from the high velocity of abrasive debris traveling inside the hoses. The wear points are most prevalent in the outside radius of tight bends near the blast head and where



Filter Canister and Vacuum Filter

the debris hose rises above the truck cab or connects to the boom for the optional tractor. The life of the hoses in these areas can be extended by rotating the hoses 120° once each week.

Some types of debris will buildup on the inside walls of the vacuum debris suction hoses to the point where it restricts debris flow in the system and reduces vacuum at the blast head. Debris buildup inside the hoses can be removed by tapping the outside walls with a dead blow hammer while the system is operating at maximum vacuum. This will flex the hose walls and cause the debris to break off and be sucked into the debris tank.

Damaged vacuum hose can be repaired by cutting out the damaged area and splicing in new hose. Temporary repairs can be made using duct tape.

## Vacuum/Debris tank

The vacuum/debris tank is constructed from stainless steel panels that provide corrosion resistance and low maintenance. There is a stainless steel cutoff ball valve that automatically shuts off the vacuum flow if the tank becomes full, protecting the blower system. This valve reduces the possibility of excessive water from damaging the blower. If the cutoff ball valve shuts off the vacuum flow, the vacuum relief valves on the tank and vacuum filter canister will automatically open and reduce the vacuum to near 0 to prevent damage to the vacuum system. A special filter bag (debris bag) is mounted on re-



Cutoff Ball Valve



taining hooks near the top the stainless steel liner in the debris tank. The vacuum system creates vacuum in the tank and debris mixed with water from the Hog Head and vacuum intake hose flows directly into the debris bag where solid debris and particles over 100 microns are trapped. The filtered water exits the filter bag and flows into the vacuum tank where it accumulates until it is drained by the drain valve at the bottom of the tank. The filter system allows for quick draining and easy disposal of filtered waste water while retaining the solids, enabling the operator to regain tank capacity.

A site tube on the side of the debris tank indicates the recovered water level and a removable inspection port on top of the debris tank is used to monitor the solid waste level. A 4" ball valve allows for quick draining of the tank. Some water can travel to the vacuum filter canister, therefore, it should be drained each time the operator stops the machine or at least once every 2 hours of operation.

The filtered waste water is usually clean enough to dump in swales alongside the road, vacant fields and designated areas at airports. It should never be dumped directly into lakes and ponds or any standing water. Always check with the authorities to ensure you are dumping within local guidelines.

The filter bag is biodegradable and designed to slide out of the tank with the debris during dumping. When installing a new bag, make sure to attach the loops at the top of the filter bag on the rear, horizontal side of the hooks in the tank. Do not wrap the loops around vertical section of the hooks. The hooks and loops hold the bag in position during operation and are designed to release the bag and allow it to automatically slide out with the debris during dumping. The bag will not stay in the proper position during operation and may not release properly during dumping if it is not installed properly.



*Removable Inspection Port on Top of Debris tank*





*Debris tank Drain Ball Valve*

## Dumping Debris

Solid debris (larger than 100 microns) is separated from the waste water by the filter bag and needs to be dumped when the debris tank is near full. A Hydraulic ram and tilting mechanism raises the front of the water and debris tanks, causing them to tilt for easy dumping.

To dump the solid debris, turn OFF the 40K Clutch switch to shutdown the UHP Pump and vacuum blower, then disengage the PTO. Completely drain the water from both tanks. Make sure the dump location is on solid, level ground and there are no overhead obstructions or power lines that could be hit by the tanks as they are raised. Disconnect the vacuum and water hoses at the quick release fittings near the tanks. Release the safety chain and loosen the ratchet binders on each side of the debris tank door. Be prepared to stand back when the last ratchet binder is removed as the door will

**WARNING**

AN IMPROPERLY INSTALLED DEBRIS BAG MAY NOT RELEASE PROPERLY DURING DUMPING. THIS CAN CAUSE THE LINER TO SEPARATE FROM THE DEBRIS TANK, DAMAGING THE TANK AND/OR CAUSE SEVERE INJURY TO PERSONNEL. ALWAYS MAKE SURE THE DEBRIS BAG IS INSTALLED PROPERLY AND THAT ALL PERSONNEL STAY WELL CLEAR OF THE TRUCK AND DEBRIS TANK DOOR WHEN DUMPING OPERATIONS ARE UNDERWAY.

open slightly and some water will pour out as the binder is removed. Secure the door in the open position with the safety chain.

Attach the cord for the hydraulic lift remote control to the receptacle in the driver's side tool box and engage the PTO to activate the hydraulic system. While you and all other personnel stand well clear of the truck, press the white UP button to raise the tank to dump the debris. Lift the unit slowly and monitor hoses and components as it is raised. Be prepared to immediately lower the tanks if there is a problem.

As the unit raises, the filter bag will normally slide out with the debris. If the debris does not slide out, use a high pressure jet rod to break up the debris until it is all removed. Never use the hydraulics to bounce the tanks or jerk the truck in an effort to remove debris. Jerking the truck or bouncing the hydraulic unit is unsafe and can damage the truck and/or break the ram hinge pins, causing the tanks to fall.

A safety strut that secures the hydraulic dumping system in the up position is incorporated in the linkage next to the hydraulic lifting ram. Always secure the unit with the safety strut before entering the debris tank for any reason or servicing components below the tanks when they are tilted.

When dumping is complete, press the black Down button and slowly lower the tank. Monitor all hoses and components as the tank is lowered and be prepared to stop if a hose becomes pinched or a component is misaligned. Pay particular attention




*Disconnect Hoses at Quick Disconnect Fittings Before Dumping*



*Hydraulic Lift Remote Control*



*Safety Strut*



*Tanks Tilted to Dump Debris from Debris tank*



to the vacuum tube and make sure it aligns with the work, a funnel shaped fitting on the vacuum filter canister that guides the vacuum tank tube into the fitting on the vacuum canister tube.

Use a hose to clean the debris tank, door jam and seal. Inspect the automatic cutoff ball valve and make sure it is free and not damaged. Then install a new filter bag, making sure it is attached to the liner properly. Close the door, attach the safety chain and secure it by systematically tightening the ratchet binders on each side of the door.

**Notice:**

**The door is designed with a slight bow to facilitate a positive vacuum seal and can be damaged if it is not clamped properly. Make sure to tighten the door binders evenly, pulling each side in a little at a time to ensure a tight even seal.**

When the door is secure, start the engine, engage the PTO and turn the 40K Clutch switch ON to activate the vacuum system. Increase the RPM to create maximum vacuum in the debris tank which will pull the door against the seal. Check that the door ratchet binders are still tight. Retighten if necessary.

With the system still at maximum vacuum, check the door seal area for leaks. If vacuum is leaking around the door, the problem could be that the door didn't close properly, there is debris on the seal, or the seal is damaged. Find and correct the problem before operating the system.



*Rear Door Ratchet Binder*

**Notice:**

**The system will not be able to develop enough vacuum if the vacuum tank or canister doors are not sealed and closed properly or a drain valve is open.**



# DANGER



**TO AVOID SEVERE DAMAGE TO THE TRUCK OR SERIOUS INJURY TO PERSONNEL, ALWAYS FOLLOW THESE GUIDELINES BEFORE RAISING THE TANKS TO DUMP DEBRIS:**

- DRAIN ALL WATER FROM THE CLEAN WATER AND DEBRIS TANKS.
- MAKE SURE THE TRUCK IS ON FLAT, SOLID GROUND. NEVER ATTEMPT TO DUMP ON SOFT GROUND OR UNEVEN TERRAIN.
- MAKE SURE THERE ARE NO OVERHEAD POWER LINES NEAR THE DUMPING AREA.
- ALWAYS SECURE THE RECOVERY DOOR WITH THE SAFETY CHAIN.
- MAKE SURE THE VACUUM AND WATER HOSES ARE DISCONNECTED AT THE QUICK DISCONNECTS.
- HAVE ALL PERSONNEL STAND WELL CLEAR OF THE TRUCK AND RECOVERY DOOR. THE OPERATOR SHOULD USE THE REMOTE CONTROL AND BE WELL CLEAR.
- LIFT THE UNIT SLOWLY AND MONITOR HOSES AND COMPONENTS AS IT IS RAISED. BE PREPARED TO IMMEDIATELY LOWER THE UNIT IF THERE IS A PROBLEM.
- NEVER JERK THE TRUCK WHILE DUMPING THE DEBRIS. JERKING THE TRUCK IS UNSAFE AND CAN DAMAGE THE TRUCK AND/OR CAUSE THE TANK FALL.
- SECURE THE UNIT WITH THE SAFETY STRUT BEFORE ENTERING THE RECOVERY TANK OR SERVICING ANY COMPONENT.
- LOWER THE UNIT SLOWLY WHEN DUMPING OPERATIONS ARE COMPLETE.

THIS PAGE WAS LEFT BLANK  
INTENTIONALLY



### Stripe Hog Tractor Operation



*SH8000T and Tractor*

#### 3.1 Tractor Controls & Deployment


The optional tractor blasting system is a versatile system that utilizes the SH8000T Ultra High Pressure water and vacuum recovery systems to provide speed and flexibility to the waterblasting process.

The operation and maintenance requirements for the engine, drive train and hydraulic components are stated in the tractor information manual. It is important that you read the manual carefully and become familiar with the proper care and operation of the engine, drive train, hydraulics and safety features for your tractor.

A warranty registration form is included with the tractor information manual. All requested information on this form should be filled out completely and submitted to the dealer or manufacturer as soon as possible.

#### Tractor foot controls

The tractor is equipped with a hydrostatic transmission that is controlled by foot peddles on the tractor. There are three peddles, one for forward, one for reverse and the brake. The brake peddle is the largest of the three peddles and also acts as



*Tractor Foot Controls*

the parking brake when pressed hard enough to engage the brake locking mechanism. Arrows on each drive peddle indicate the direction the tractor will move when the peddle is pressed. Press the peddle with the forward pointing arrow and the tractor moves forward. Press the peddle with the reverse pointing arrow and the tractor moves



backwards. The further a peddle is pressed, the faster the tractor will go until it reaches the maximum speed for the throttle setting selected. Release the selected peddle and press on the brake to stop the tractor.



### WARNING



OPERATING THE TRACTOR WITHOUT COMPLETELY UNDERSTANDING THE FUNCTION OF EACH CONTROL PEDDLE CAN CAUSE THE OPERATOR TO LOSE CONTROL OF THE TRACTOR WHICH COULD RESULT IN DAMAGE TO EQUIPMENT OR SEVERE INJURY TO THE OPERATOR. THE INFORMATION IN THIS MANUAL IS MERELY AN OVERVIEW OF THE TRACTOR CONTROLS AND NOT INTENDED TO COVER ALL ASPECTS OF THEIR OPERATION.


ANYONE THAT OPERATES THE TRACTOR SHOULD READ THE TRACTOR OPERATING MANUAL AND COMPLETELY UNDERSTAND THE PEDDLE AND ENGINE THROTTLE CONTROLS IN THEORY AND OPERATION BEFORE ATTEMPTING TO DRIVE THE TRACTOR. NEVER ALLOW ANYONE TO OPERATE THE TRACTOR UNTIL THEY HAVE READ THE TRACTOR OPERATING MANUAL OR RECEIVED INSTRUCTIONS FROM AN EXPERIENCE OPERATOR.

### Tractor Loading and Unloading

The tractor is typically stored and transported on a special landing pad on the chassis. The pad is equipped with tie down locations so that the tractor can be tied down for transport. A folding, heavy duty ramp provides safe and easy loading and unloading for the tractor. The aluminum ramp is equipped with a lift assist system that allows the ramp to be easily raised and lowered by the operator.

The ramp angle can become too steep for the tractor to be safely loaded or unloaded in some situations. Additionally, the Hog Arm can hit the ramp if it is too steep. You should pay attention to the angle of the ramp and compensate for this situation by selecting a different location that reduces the angle when necessary.

To unload the tractor, release the spring loaded safety pin or other safety pin assembly located on the side of ramp that secures it in the up or stored position. Simultaneously lower and unfold the ramp until it is completely open and sitting firmly



on level ground. Make sure the parking brake is set, then remove the tie downs. Start the tractor engine and let it warm up for a couple of minutes. Set the throttle slightly above idle, release the parking brake and carefully back the tractor down the ramp. Go slow and pay close attention to the position of the tractor on the ramp during loading and unloading operations. Reverse the process to load the tractor. Note that a slightly higher throttle setting may be required for loading than for unloading.



### WARNING



THE TRACTOR CAN SURGE UNEXPECTEDLY IN FORWARD OR REVERSE IF THE THROTTLE IS SET TOO HIGH WHILE LOADING AND UNLOADING THE TRACTOR. THIS CAN CAUSE THE OPERATOR TO LOOSE CONTROL RESULTING IN DAMAGE TO THE EQUIPMENT OR SEVERE INJURY TO THE OPERATOR. ALWAYS MAKE SURE TO SET THE THROTTLE AT A LOW RPM, SLIGHTLY ABOVE IDLE, FOR LOADING AND UNLOADING OPERATIONS.

Once the tractor is loaded, make sure the parking brake is set and the tractor is secured with the tie downs. Simultaneously raise and fold the ramp and secure it with the safety pin. The pin secures the ramp in the up position and prevents it from swinging out while operating the truck.

#### Notice:

You should always pay attention to the location of the hoses and make sure they are not snagged or strained. This is particularly important while loading or unloading the tractor.

### 3.2 Tractor Hog Head & Hydraulic Systems

The Hog Head and hydraulic Hog Arm is mounted to the front of the tractor. All movement and the rotation of the spray bars are activated and controlled by the tractor electric and hydraulic systems.

The high pressure water pump system on the SH8000T provides the ultra high waterblasting pressure to the rotating spray bar. A joystick and rocker switches in the console control all functions of the Hog Head and control arm.

#### Notice:

The tractor throttle setting must be set at 75% or higher to provide enough hydraulic pressure to properly activate the Hog Arm and rotate the spray bar.



*Typical Loading Ramp Safety Bar and Pin Assembly*



*Loading Ramp Folded*



*Always Be Aware of the Location of the Hoses  
Never Strain or Damage the Hoses*



## Hog Head Hydraulic System

The hydraulic system is powered by the tractor engine. Switches and the joystick on the console control all hydraulic functions of the Hog Arm. The Hog Head can be moved up and down, right and left or can be set to float, which allows the Hog Head to freely move up and down with the contour of uneven surfaces.

## Joystick

A multi-function joystick on the tractor console controls lateral and vertical movement of the blast head and makes it easy to change nozzles. The Hog Arm and spray bar rotation speed are controlled by the joystick and a speed dial in the console. Separate gauges on the SH8000T monitor the charge pressure and ultra high pressure in the waterblasting system.

The joystick controls the Hog Arm. Move it forward to lower the arm, pull it back to raise it. Move it to the right and the hog arm moves right, move it left and the arm moves left. The "trigger" on joystick controls which stage of the Hog Arm moves right and left with the joystick. When the "trigger" is not activated, the joystick controls the 1st stage of the arm and moves the entire Hog Arm right and left. When the "trigger" is activated, the joystick moves only the 2nd stage of the Hog Arm (the portion forward of the center hinge) for more precise positioning of the Hog Head. When the joystick is released, the handle automatically returns to center and the Hog Arm stops in that position. The Float rocker switch in the console activates and deactivates the Hog Head float feature that enables the Hog Head to float freely over uneven contours. Float mode is recommended for most situations and the most common operating mode for the Hog Arm while waterblasting operations are underway.

The Head Rotation dial controls the speed of the Hog Head spray bar. Rotating the dial clockwise increases speed and rotating it counterclockwise reduces speed. Setting the Head Rotation dial to 0 will stop the rotation of the spray bar.

The computer that controls the joystick functions is mounted below the seat near the battery. The 12-volt circuits for the joystick, console switches and strobe light are protected by in-line fuses located near the battery.

## Hog Head

The Hog Head is attached to the end of the Hog Arm. There is one blasting head and four heavy



*Hog Head and Hydraulic Hoses*



*Tractor Joystick and Control Panel*



*Head Rotation Speed Dial, Console Rocker Switches and Tractor Multi-Gauge*




duty castors that support the Hog Head at a preset height and prevent the spray bar from contacting the pavement. Spacers on each caster adjust the height of the Hog Head. Adjustment may be required to maintain proper clearance by adding spacers as the castor wheels wear.

The wear brush is clamped to the blast head shroud and provides a partial seal between the Hog Head and the pavement. The wear brush regulates vacuum air flow into the Hog Head and reduces the amount of debris and water exiting the blast head shroud during waterblasting operations. The wear brush is an important safety feature of the Hog Head and must be adjusted as it wears. It should always be adjusted so the brushes are making light contact with the pavement.


To adjust the wear brush, lower the Hog Head to the ground and note the gap between the wear brush and the pavement. Raise the Hog head, loosen the clamp on the blast head and slide the wear brush enough to eliminate the gap. Tighten the clamp and recheck. Readjust if necessary.

**Always make sure to check the Hog Head for smooth and proper operation before each shift. Do not use equipment that has not been checked thoroughly.**

The spray bar is rotated by a thru-shaft hydraulic motor or a thru-shaft rotated by a separate hydraulic motor, depending on the options selected. The rotation speed is controlled by the head rotation dial in the tractor console. The center of the thru-shaft is drilled to allow high pressure water to pass through the shaft to the spray bar. A special swivel seal assembly provides a positive seal for the connection to the high pressure hose while allowing the thru-shaft to turn freely. The hose is secured to the thru-shaft motor or swivel shaft housing by the swivel nut. The swivel nut is hand tightened. If the nut becomes loose, the hose will wobble and damage the swivel seal. Additionally, if the swivel nut is overtightened by using a pipe wrench or pliers, the swivel seal will be damaged. It must be checked daily to ensure it is tight and that the swivel seal is not leaking. Any water dripping from the weep holes just below the swivel nut while the system is pressurized indicates the seal is leaking and must be replaced. Operating the Hog Head with a leaking swivel seal will cause complete failure of the seal, stopping blasting operations and severely damage the thru-shaft motor or swivel shaft.



*Joystick Control Panel Computer, Tractor Battery And In-Line Fuses*



*Hog Arm and Hog Head (Blast Head)*



*Blast Head, Spray Bar and Wear Brush*

The spray bar is a quick change design. Spray bars are available in 6", 8", 10", 14", widths. Aggressive and non-aggressive patterns are available for all heads.

If you are new to waterblasting equipment, Waterblasting Technologies offers a variety of spray bar and nozzle configurations to meet the requirements of most paint and rubber removal projects. Examples of available spray bar configurations are included in the Appendix section of this manual. You can also contact Waterblasting Customer Service for assistance in selecting the right spray bars for your project.


To change a spray bar, hold the shaft by inserting a 3/4" wrench into the slot at the bottom of the thru-shaft motor or swivel shaft housing, located just above the blast head shroud. Twist the spray bar counterclockwise by hand until it is free of the shaft. Purge the blast head at low pressure, then apply anti-seize to the threads, insert a new brass button seal and install the spray bar by turning it clockwise slowly until it seats. Then tighten it by turning the spray bar another 15%. Make sure you remove the wrench when the installation is complete.

### Notice:


**Before attaching the new spray bar to the Hog Head Assembly, engage pump at low speed to purge the system. Any dirt or debris in the system can clog nozzle orifice's and cause system pressure to spike excessively causing damage to components or the rupture discs on the UHP pump to burst. Refer to the Stripe Hog Training DVD for detailed information on changing the spray bar.**

The dirt shield that protects the thru-shaft motor or swivel shaft bearings is located between the spray bar and blast head shroud. It consists of a special felt seal that is held against the bottom of the blast head shroud by a stainless steel flat washer threaded on the shaft. The felt seal should be inspected and adjusted whenever the spray bar is removed. The dirt shield should be replaced if it is damaged or worn and be adjusted "finger tight." If it is too tight it will prevent the spray bar from rotating.


With the spray bar installed, operate the pump at low pressure to check for nozzle accuracy and leaks on the spray bar or nozzles. Water dripping from any of the weep holes in the side of the spray bar indicates that a nozzle is not seated properly. Leaks at the nozzle seats or thru-shaft threads must be corrected before beginning high pres-



Swivel Nut and Weep Holes



Spray Bar, Button Seal, Thru-Shaft and Dirt Shield




Spray Bar with Nozzles Installed and Weep Holes





*Good Nozzle Spray Pattern and No Water at Weep Holes*



*Bad Nozzle*

sure operations or the spray bar will be ruined. Should any repairs or adjustments be necessary, disengage the pump to relieve all pressure before making any required repairs or adjustments.

Each spray bar is equipped with a spray bar protector that is held in place with one or two cotter pins, depending on the size of the spray bar. The spray bar protector shields the nozzles and spray bar from damage caused by debris during blasting operations. Never water blast without the spray bar protector installed. Spray bars and nozzles are expensive and the life of the nozzles and spray bars will be dramatically shortened without the spray bar protector.

**Notice:**

**Never Blast When Stopped. Damage to road surface will occur if blasting continues when the Stripe Hog is brought to a stop.**

### 3.3 Tractor Waterblasting

The tractor Hog Arm and Hog Head are supplied high pressure water and vacuum from the SH8000T waterblasting system. Quick disconnect

fittings on the hoses and swing arm booms allow the tractor to be quickly connected to the SH8000T systems and enable unrestricted movement of the tractor around the truck. The operation of the Ultra High pressure water is controlled by the operator on the tractor.

The SH8000T UHP pump is designed to provide high pressure water to two blasting heads at a maximum operating pressure of 40,000 PSI (2,758 Bar) @ 12 gallons (45 Liters) per minute that is achieved at maximum engine RPM. (typically 1400 RPM) The tractor is equipped with a single blasting head that operates at a maximum pressure of 40,000 PSI (2,758 Bar) @ **6 gallons (23 Liters) per minute**. Therefore, the high pressure system must be adjusted to provide the desired pressure at half the volume required for the truck mounted Hog Head. It is extremely important that the pressure and volume be adjusted at the time the high pressure and vacuum systems are switched from the truck mounted Hog Head to the tractor or any other Hog Tool.





## DANGER



THE SINGLE BLASTING HEAD ON THE TRACTOR OR ANY OTHER HOG TOOL WILL BE OVERPOWERED BY THE SH8000 HIGH PRESSURE PUMP IF THE SYSTEM IS NOT ADJUSTED TO THE REDUCED VOLUME FOR A SINGLE BLASTING HEAD. FAILURE TO ADJUST THE SYSTEM WILL PROVIDE TOO MUCH PRESSURE TO THE SPRAY HEAD THAT WILL CAUSE THE RUPTURE DISCS TO BLOW AND COULD CAUSE SEVERE DAMAGE TO THE UHP SYSTEM AND/OR INJURY TO THE OPERATOR OR CREW WHEN THE SYSTEM IS ACTIVATED.

WHEN SWITCHING THE UNIT FROM THE MAIN HOG HEAD TO EQUIPMENT WITH A SINGLE BLASTING HEAD, ALWAYS ENGAGE THE TRUCK 40K SWITCH WITH THE ENGINE AT IDLE AND TURN THE DUMP VALVE ON. GRADUALLY INCREASE THE RPM WHILE ADJUSTING THE MANUAL BYPASS VALVE UNTIL THE DESIRED PRESSURE AND VACUUM FOR THE SINGLE BLASTING HEAD IS ACHIEVED. THIS PROCEDURE MUST BE DONE BEFORE THE TRACTOR OR HOG TOOL IS USED AND MUST NEVER BE OVERLOOKED.

The water pressure is monitored by the High Pressure gauge on the pump and a digital gauge in the joystick panel. High pressure and water volume are controlled by the RPM of the engine and adjusting the manual bypass valve on the pump. Since engine RPM also controls the level of vacuum, you must use the manual bypass valve to reduce water volume to blasting head as the RPM is increased to achieve the pressure, gallons per minute and vacuum desired for the material being removed and the waterblasting tools being used.

Refer to the Water Blast System (Section 2.6) of this manual for information on waterblasting controls and systems.

**High pressure hoses and fittings can be dangerous if a hose fails or a fitting breaks during high pressure blasting.** Outfit the tractor operator with proper safety apparel. Additionally, the operator must always be aware of the maximum distance from the truck the hose length will allow. The SH8000T is capable of supporting the tractor with high pressure and vacuum to a maximum distance of 400' from the truck. Always operate the tractor well within the maximum distance to avoid straining or damaging hoses.

### 40K PSI ON/OFF and Nozzles Test Switch

A dual position rocker switch activates and deactivates the Ultra High water system and lower pressure for testing the nozzles. The center position of the switch is off. Push the top of the switch to close the tractor mounted dump valve and supply high pressure water to the Hog Head. Press the bottom of the switch to supply low pressure to the Hog Head for testing the nozzles.

The START switch in the truck joystick panel must be activated by the truck operator to supply High Pressure to the tractor dump valve. The UHP pressure can then be controlled at the tractor by the tractor operator. The truck operator can also shut down the UHP pressure to the tractor in an emergency by pressing the STOP switch in the joystick panel.

### Tractor Vacuum System

The truck powered vacuum system provides the vacuum to the tractor. Flexible hoses with quick disconnect fittings provide vacuum to the tractor Hog Head. Refer to the Vacuum System (section 2.7) in this manual for information on the vacuum system.

Make sure to protect the hoses from damage and abrasion from dragging on the pavement. This is particularly important when working a long distance from the truck. In some situations anti-chaffing protection may need to be added to the hoses in contact areas.


### Strobe Switch

Activates and deactivates the strobe light on the tractor roll bar.

### Work Mode Cruise Control

When the tractor is in "Work Mode", a separate, "Cruise Control" can be used to set the tractor speed (0-7 MPH). To set the speed, rotate the knob on the control. Turn it counterclockwise to increase tractor speed. Rotate it clockwise to decrease tractor speed. An adjustable friction control below the knob increases and decreases friction on the cruise control cable. It should be set just tight enough to prevent the speed setting from changing during operation. The button on top of the throttle knob releases the rotating control and allows the control to be pushed directly to the stop position.

### Waterblasting Hog Tools



#### 4.1 Hog Tools (Optional)

Waterblasting Technologies builds a variety of useful attachments called Hog Tools that can be used with the SH8000. The most common tools are the HT1100 Hog Waller, HT1000 Ground Hog and the HT100 Hand Hog. These tools connect to the electrical and hydraulic quick disconnect couplers just behind the bumper on the driver's side of the truck and to the truck UHP and vacuum systems.

This section provides a brief overview of how these tools work with the SH8000 for your information. An operating manual that ships with each Hog Tool provides more detailed information on the operation, safety and maintenance. Handheld, ultra high pressure waterblasting tools can be extremely dangerous if they are not used properly and all safety precautions followed. You should read the operating manual for each tool and completely understand the operation, maintenance and all safety precautions before operating the tool.



#### WARNING



INJURIES FROM ULTRA HIGH PRESSURE WATERBLASTING CAN BE VERY SERIOUS AND RESULT IN FATAL INJURIES. PROPER OPERATION OF HIGH PRESSURE WATERBLASTING TOOLS IS ESSENTIAL, PARTICULARLY WITH HANDHELD UNITS BECAUSE THE OPERATOR IS CLOSE TO THE BLAST HEAD.

##### THE FOLLOW PRECAUTIONS APPLY:

- ALWAYS FOLLOW THE SAFETY GUIDELINES LISTED IN THE HOG TOOL OPERATION MANUALS.
- MAKE SURE ALL SUPPORT PERSONNEL ARE AT A SAFE DISTANCE FROM THE WORK AREA BEFORE THE PRESSURE PUMP IS ENGAGED.
- MAKE SURE THAT THE OPERATOR HAS READ THE MANUAL FOR THE TOOL AND HAS BEEN TRAINED IN THE PROPER USE OF HANDHELD WATERBLASTING EQUIPMENT.
- MAKE SURE THE OPERATOR AND ALL PERSONNEL ARE EQUIPPED WITH REQUIRED SAFETY EQUIPMENT INCLUDING HARD HATS, GLOVES, EYE AND EAR PROTECTION, ETC.
- NEVER PUT HANDS, FEET OR ANY PART OF YOUR BODY IN OR NEAR THE HIGH PRESSURE STREAM.
- NEVER ALLOW AN INEXPERIENCED PERSON TO OPERATE A HANDHELD, HIGH PRESSURE WATERBLASTING TOOL WITHOUT PROPER TRAINING.

## 4.2 Hog Tool Waterblast Systems

### General

When a Hog Tool is connected to the auxiliary connections, the Waterblasting electrical system senses that a tool is connected and allows the levers on the tool to control the dump valve and hydraulic pressure to the blast head thru-shaft motor. The truck hydraulic system provides the hydraulic power that rotates the spray bar on the Hog Tool. The truck UHP pump and vacuum system provides water pressure and vacuum.

### Hydraulic and electrical Systems

Hydraulic hoses with quick disconnect fittings are connected the to the truck hydraulic system. The hydraulic manifold on the truck controls the oil flow and regulates the pressure. Switches and/or control knobs on the Hog Tool provide the operator with control of the hydraulically activated features.

A 12-Volt DC harness runs from the outlet plug on the front of the truck to a plug on the tool and allows the switch lever on the tool to activate the spray head rotation.

### High Pressure Waterblasting System

The High Pressure water line runs from the UHP pump and dump valve on the SH8000 to the Hog Tool. The manual bypass valve on the UHP pump and engine RPM is used to adjust the volume and pressure supplied to the tool.

When the SH8000 is connected to a Hog Tool, the high pressure water is controlled by a lever on the tool handle. The control lever activates a switch that sends electrical current to the dump valve on the UHP pump to engage or disengage high water pressure water at the blasting head on the tool.

When the system is activated, it operates much like the truck mounted high pressure water system. The tools must be moving before the high pressure is activated and all waterblasting safety precautions apply.

High pressure hoses and fittings can be dangerous if a hose bursts or a fitting fails during high pressure blasting. Outfit the Hog Tool operator with proper safety apparel. Hard hat, safety shield or glasses, gloves, ear protection, etc.



### DANGER



THE SINGLE BLASTING HEAD ON THE TRACTOR OR ANY OTHER HOG TOOL WILL BE OVERPOWERED BY THE SH8000 HIGH PRESSURE PUMP IF THE SYSTEM IS NOT ADJUSTED TO THE REDUCED VOLUME FOR A SINGLE BLASTING HEAD. FAILURE TO ADJUST THE SYSTEM WILL PROVIDE TOO MUCH PRESSURE TO THE SPRAY HEAD THAT WILL CAUSE THE RUPTURE DISCS TO BLOW AND COULD CAUSE SEVERE DAMAGE TO THE UHP SYSTEM AND/OR INJURY TO THE OPERATOR OR CREW WHEN THE SYSTEM IS ACTIVATED.

WHEN SWITCHING THE UNIT FROM THE MAIN HOG HEAD TO EQUIPMENT WITH A SINGLE BLASTING HEAD, ALWAYS ENGAGE THE TRUCK 40K SWITCH WITH THE ENGINE AT IDLE AND TURN THE DUMP VALVE ON. GRADUALLY INCREASE THE RPM WHILE ADJUSTING THE MANUAL BYPASS VALVE UNTIL THE DESIRED PRESSURE AND VACUUM FOR THE SINGLE BLASTING HEAD IS ACHIEVED. THIS PROCEDURE MUST BE DONE BEFORE THE TRACTOR OR HOG TOOL IS USED AND MUST NEVER BE OVERLOOKED.

## 4.3 Hog Tool Vacuum Systems

The HT1100 Hog Waller and HT1000 Ground Hog are equipped with blast heads that are designed to be attached directly to the SH8000 vacuum system. When the system is activated, it performs much like the vacuum system when it is connected to the tractor blast head. Vacuum is supplied whenever the engine on the SH8000 is running and the 40K clutch is engaged.



# Stripe Hog Operation

## 5.1 Emergency Shutdown

### Truck Emergency Shutdown

1. IMMEDIATELY PUT TRUCK TRANSMISSION IN "N" (NEUTRAL) OR SHUTDOWN THE ENGINE. THIS WILL INSTANTLY SUSPEND OPERATIONS OF THE ENTIRE SYSTEM.
2. WHEN THE SITUATION PERMITS, RETURN ALL SWITCHES TO THE "OFF" POSITION AND ALL DIALS TO THE "0" SETTING.

### Tractor Emergency Shutdown

1. IMMEDIATELY STOP THE TRACTOR AND TURN THE 40K PSI SWITCH OFF. GET OFF THE TRACTOR AND OUT OF HARMS WAY IF NECESSARY.
2. IMMEDIATELY PUT TRUCK TRANSMISSION IN "N" (NEUTRAL) OR SHUTDOWN THE SH8000 ENGINE. THIS WILL INSTANTLY SUSPEND OPERATIONS OF THE ENTIRE SYSTEM.
3. WHEN THE SITUATION PERMITS, RETURN ALL SWITCHES TO THE "OFF" POSITION AND ALL DIALS TO THE "0" SETTING.

## 5.2 SH8000 Start Up/Shutdown

Before operating the Stripe Hog check the fluid levels in the truck engine, transmission and hydraulic system. A thorough understanding of the component systems and their operation is essential to the proper operation the Stripe Hog. This manual and the associated manufacturers' information is provided to enhance your knowledge of the Stripe Hog. Make sure you have read them carefully and fully understand the operation of the unit.

You should walk around the unit and visually inspect the Hog Head, high pressure hoses, hydraulic hoses, vacuum hoses, and all waterblasting system components for obvious signs of leaks, wear and deterioration. Do not operate the unit until all questionable components are repaired or replaced.

The startup and shutdown procedures described in this section are for a typical truck chassis equipped



Truck Cab Control Switch Panel



Truck Cab Joystick



Tractor Control Panel and Joystick

with an automatic transmission. This information is provided as a general guide and overview of the process for educational purposes. The exact procedure for your truck may be different, depending on the chassis and the options selected. Waterblasting Technologies includes a quick reference card in the cab of the truck, usually attached to the drivers side sun visor, that provides the proper startup and shutdown procedures for your truck.

#### Notice:

**Always check the Hog Head nozzles and spray bars for wear and damage before each shift. Refer to High Pressure Hoses and Nozzles in Section 2.7 (Water Blasting Systems) for information on inspecting spray bars and nozzles).**

#### Notice:

**The pavement will be damaged immediately if high pressure blasting is activated without the Hog Head moving. Always make sure truck, tractor or Hog Tool is moving before supplying high pressure to the Hog Head.**

#### Pre-start Inspection Check List:

1. Inspect all hoses for chaffing and signs of wear.
2. Check fuel levels and make sure you have enough for the shift.
3. Check engine and all systems fluid levels. Refer to the truck operating manuals.
4. Check the fluid level in the tractor hydraulic system.
5. Check all waterblasting and vacuum components for oil leaks, damaged or loose bolts and parts.
6. Inspect the Hog Head for loose components and damage.
7. Check that all quick release pins on the ladders and ramp are in place, secure and in good condition.
8. Check vacuum canister for water and the vacuum filter. Drain water or clean filter as required.
9. Check the vacuum blower and UHP pump drive belt tension and alignment.
10. Check clean water tank level and fill if necessary.
11. Drain debris tank water and check debris level. Empty if necessary.
12. Walk around truck and visually check all components and look for obvious problems.

#### Startup Procedure:

1. Make sure all switches and dials are in the "OFF" position or set at "0".
2. Be sure the truck Transmission is in "N", (*NEUTRAL*) position.
3. Start Truck Engine.
4. Turn the Mode switch "ON".
5. Turn the console PTO switch "ON". Listen for the PTO to engage and then wait for the green (Drive Mode) light to go off and the red (Work Mode) light to turn on.
6. Select "D", (*Drive*), on the truck transmission only when the red light is on. Wait until 4 4 is displayed on the transmission LED.
7. Turn the Charge Pump "ON" - operating pressure should be above 40 PSI (2.8 Bar).
8. Turn the 40K Clutch "ON". The RPM of the vacuum system is set in conjunction with the 40K PSI pump RPM.
9. Turn the truck Cruise Control "ON" - setting RPM to desired level for correct operating pressure setting (800 RPM min. - 1400 RPM max.). There may be some variation of this especially if there is a Stripe Hog Tractor and/or a Bypass Valve for relieving excess water with the system.
10. Use "Start" switch on the joystick box to activate high pressure at the spray bars.
11. Check the nozzle spray pattern and the spray bar weep holes for leaks.
12. Check all High pressure hose fittings and the Hog Head for leaks.
13. With the pressure set and the spray bar and nozzles working properly, press the "STOP" switch on the joystick then lower the Hog Head.
11. Release the truck Parking Brake - truck cannot move hydraulically unless brake is released.
14. The truck operator can now press the "Start" switch and begin blasting operations.



## WARNING



ANY CONTACT WITH HIGH PRESSURE WATER IS VERY DANGEROUS AND CAN BE FATAL! USE EXTREME CAUTION RAISING OR MOVING HOG HEAD & ARM ASSEMBLY IF HIGH PRESSURE IS ENGAGED.

### Shutdown Procedure:

1. Turn high pressure OFF by pressing joystick "Stop" switch.
2. Turn the 40K Clutch and Charge Water switches "OFF".
3. Allow the vacuum blower to operate for a couple of minutes after shutting down the high pressure and charge water pumps to clear waste water from hoses and dry out blower system.
4. Reduce the engine speed to idle.
5. Raise the Hog Head to the full "UP" and locked position. Make sure the locking lever is engaged and secure it with a plastic tie wrap to ensure the locking lever cannot accidentally be released during transportation.
6. Put the Truck Transmission in "N" (NEUTRAL).
7. Turn the PTO switch to "OFF". Listen for the PTO to disengage and then watch for the red light to turn OFF, the green light to turn ON.



## WARNING



IT IS VERY IMPORTANT THAT THE PTO IS FULLY DISENGAGED TO INSURE THAT NONE OF THE FUNCTIONS WILL OPERATE ACCIDENTALLY.

8. Drain waste water from the vacuum canister. Close the valve when draining is complete.
9. Turn the Mode switch to "OFF". It is VERY important that this switch is off to insure that the truck transmission will not go directly into 4th gear lock-up when put into DRIVE causing the truck to lunge forward.
10. Turn all other switches and dials on the control panels to "OFF" or "0".
11. When the truck is parked, set the parking brake and allow the engine to run for several minutes to cool internal components, then shut off the engine.

### 5.3 SH8000T Tractor Startup/Shutdown

Before operating the ST2500 tractor, check the fluid levels in all components. A thorough understanding of the component systems and their operation is essential to the proper operation the Stripe Hog tractor or any other Hog Tool used with the SH8000. This manual, the manuals for the tractor or Hog Tools and the associated manufacturers' information is provided to enhance your knowledge of the equipment. Make sure you have read them carefully and fully understand the operation of the units.

You should walk around the truck and tractor and visually inspect the high pressure hoses, hydraulic hoses, vacuum hoses, and all waterblasting system components for obvious signs of leaks, wear and deterioration. Do not operate the unit until all questionable components are repaired or replaced.

#### Notice:

**Always check the Hog Head nozzles and spray bars for wear and damage before each shift. Refer to High Pressure Hoses and Nozzles in Section 2.6 (Water Blast Systems) for information on inspecting spray bars and nozzles).**

#### Notice:

**The pavement will be damaged immediately if high pressure blasting is activated without the tractor or Hog Tool moving. Always make sure tractor or Hog Tool is moving before supplying high pressure to the Hog Head and spray bar.**

### Pre-start Inspection Check List:

1. Inspect all hoses for chaffing and signs of wear.
2. Check fuel levels and make sure you have enough for the shift.
3. Check engine, truck systems and tractor fluid levels. Refer to the tractor and engine operating manuals.
4. Check the fluid level in the tractor hydraulic system.
5. Check all waterblasting and vacuum components for oil leaks, damaged or loose bolts and parts.
6. Inspect the Hog Head for loose components and damage.





7. Check that all quick release pins on the ladders and ramp are in place, secure and in good condition.
8. Check vacuum canister for water and the vacuum filter. Drain water or clean filter as required.
9. Check the vacuum blower and UHP pump drive belt tension and alignment.
10. Check clean water tank level and fill if necessary.
11. Drain debris tank water and check debris level. Empty if necessary.
12. Walk around truck and visually check all components and look for obvious problems.

## Start UP Procedure:

1. Unload the tractor.
2. Connect the pressure water and vacuum hoses to the tractor and position it for operation.
3. Set the tractor parking brake, start the tractor engine and set the throttle to idle.
4. Make sure all switches are in the "OFF" position and the spray bar speed dial is set at "0".
5. Start the truck engine.
6. Allow the engine to warm up at idle speed for several minutes.
7. Activate the charge pump and make sure the charge water pressure is above 40 PSI (2.8 Bar.)
8. With the truck engine at idle, follow the truck startup instructions to engage the waterblasting UHP pump and vacuum systems.

## At this stage the following implements will function:

- A. Operation of charge water Pump.
  - B. Operation of the UHP Pump.
  - C. Operation of Vacuum System.
9. With the truck still at idle, the operator on the tractor, all personnel clear and the Hog Head in the "UP" position, turn the 40K PSI switch "ON".

10. Slowly raise the engine RPM and adjust the manual bypass valve to set the high water pressure and vacuum to the desired levels. (Typically 800 RPM minimum - 1400 RPM max.) There may be some variation of this depending on the blasting equipment attached and/or the manual bypass valve setting. **The RPM of the vacuum system is set in conjunction with the 40K PSI pump RPM.**
11. Check the nozzle spray pattern and the spray bar weep holes for leaks.
12. Check all High pressure hose fittings and the Hog Head for leaks.
13. With the pressure set and the spray bar and nozzles working properly, select the "OFF" position on the 40K PSI switch on the tractor, then lower the Hog Head.
14. The tractor operator can now activate the 40K PSI switch and begin blasting operations.



## WARNING



ANY CONTACT WITH HIGH PRESSURE WATER IS VERY DANGEROUS AND CAN BE FATAL! USE EXTREME CAUTION RAISING OR MOVING HOG HEAD & ARM ASSEMBLY IF HIGH PRESSURE IS ENGAGED.

## Shutdown Procedure:

1. Turn the tractor 40K PSI switch "OFF".
2. Raise the Hog Head to the full "UP" position.
3. Turn all the switches on the control panel to "OFF" and the speed dial to "0".
4. Stop the tractor near the truck so there is slack in the hoses.
5. Turn the throttle on the SH8000 engine to idle speed, disengage the PTO, and allow the engine to run for several minutes to cool internal components.
6. Load the tractor. Make sure the tractor is properly secured before traveling. Refer to Tractor Loading and Unloading in Section 3.1 (Tractor Operation) in this manual for more information on loading and properly securing the tractor.
7. Raise the ramp and make sure it is properly secured with the safety pin.

8. Properly store or secure all hoses and make sure the booms are properly secured for travel
9. Shutdown the SH8000 following the instructions in this section.

### 5.4 Waterblasting Operations

Before you start the job, you should evaluate the pavement you will be working on, the material to be removed, and choose the appropriate spray bars and/or nozzles best suited for the job. You should also consider the desired or expected profile of the blasted surface in your selection. There are many variables that affect blasting efficiency, productivity and the profile of the blasted surface. As the operator becomes more experienced, the selection process becomes more refined and easier.

Generally, large, high volume (.015 - .017) nozzles are the most aggressive and provide faster results, but more potential for damage and a course profile. High volume nozzles should be used only on strong pavement (concrete or newer pavement). Small, low volume (.007 - .011) nozzles are less aggressive and will provide somewhat slower results but less damage potential and a smoother profile. Low volume nozzles are well suited for weak pavement (older or damaged pavement). Low volume nozzles are typically a better choice for inexperienced operators on any surface.

Waterblasting Technologies offers an on-site training program that dramatically reduces the learning curve and increases productivity. If you are new to Waterblasting, we highly recommend that you consider this factory training for your operators. You can also contact Waterblasting Technologies Customer Service department for assistance in choosing spray bars and nozzles or more information regarding the factory training program.

#### Waterblasting Guidelines:

##### Evaluate the Pavement and Select a Spray Bar

- Strong pavement withstands high aggression spray bars. This is generally concrete or new asphalt.
- Cracked pavement is weak and will require lighter aggression spray bars.
- Brittle pavement is a challenge and will require lighter aggression spray bars and reduced pressure.

- Consider spray bar width. Choose a spray bar 2" wider than the line being removed to provide steering tolerance plus slight over spray to reduce the need to back up and re-do sections.

#### Do's

- Pre-clean the work area with a power broom before blasting.
- Stop blasting before stopping the truck or tractor. Blasting with the unit stopped will damage the pavement and Hog Head.
- Stop blasting before changing direction.
- When in doubt, choose a less aggressive spray bar. It is always best to error on the side of caution.
- Adjust the forward speed and head rotation to remove 95% of the paint in a single pass to eliminate a second pass and more potential for damage.
- Adjust the pressure for the pavement. Typically blast pressures between 32,000 and 38,000 PSI are used.
- Check and clean the vacuum filters frequently to ensure strong vacuum pressure while blasting. Dirty filters and low vacuum will leave excessive paint chips and debris on the pavement slowing productivity.
- Check the pavement frequently and watch the outer edges of the lines for damage. Continuously make adjustments as required.

#### Dont's

- Do not allow untrained personnel to operate Stripe Hog equipment.
- Do not continue blasting with a damaged nozzle. It can cause damage, waste water, reduce the power of other nozzles and slow production.
- Avoid running the Hog Head wheels on rumble strips. Always adjust the Hog Arm to keep the wheels off the rumble strips.
- Do not blast directly on sealed joints in the pavement. Especially weather stripping on bridges or airfields.
- Do not blast over pavement markers. Markers can damage the blast head and spray bars and should be removed prior to blasting.

- Do not blast over damaged or uneven pavement that can damage the blast head and spray bars.
  - Do not allow the Smart Tank to become over-filled. This can cause an unexpected shutdown of the vacuum system. Monitor the tank and empty it before it is full.
  - Do not allow the charge pump to run out of water. Water is a lubricant and cools the charge and high pressure pumps. They will be damaged if they run dry. Always monitor the water level in the clean water tank and refill when it gets low.
5. Open the drain valve at the charge water pump and allow the hoses and pump to completely drain. With the valve still open, activate the pump briefly to pump out any remaining water, about a cupful. Then close the valve.
  6. Pour 2 gallons of anti-freeze into the high pressure pump stuffing box sump so it will drain to the bilge pump sump system. Allow the bilge pump to run until anti-freeze is visible at the bilge pump hose fitting in the debris tank.
  7. Drain the vacuum canister immediately at the end of each shift.

### 5.5 Operating in Freezing Conditions Shutdown

1. Allow the vacuum blower to operate for a couple of minutes after shutting down the high pressure and charge water pumps to clear waste water from hoses and dry out blower system.
2. Make sure the clean water and debris tanks are drained immediately at the end of each shift.
3. All system hoses and the Hog Head assembly, including the tractor Hog Head, should be drained of all water and/or filled with an anti-freeze solution. (non alcohol)
4. For the 40K water blaster, refer to pump manufacturer's procedures for maintaining equipment in freezing climates.




#### CAUTION



IF YOU OPERATE AT FREEZING TEMPERATURES OR EVEN TEMPERATURES BELOW 60 DEGREES FAHRENHEIT (16° CELSIUS), IT WILL BE NECESSARY TO OPERATE THE SYSTEM, INCLUDING ENGAGING THE BLOWER AND HIGH PRESSURE PUMP, AT IDLE SPEED ONLY UNDER LOAD, UNTIL OIL HEATS UP ABOVE 60 DEGREES FAHRENHEIT (16° CELSIUS).  
TRACTOR SYSTEMS



### General Maintenance



*Drivers Side Lubrication Points*

A. Hog Head and Hog Arm	D. Oil Tool Box Door Hinges and Latches
B. Lubricate Ladder & Ramp Hinges and Safety Pins	E. Grease Drive Splines and Universal Joints
C. Grease Blower Bearings	F. Grease Hydraulic Cylinder Hinge Pins

#### 6.1 Lubrication

You should become familiar with the location of all components that require frequent lubrication and include them in the routine maintenance schedule. Some of these lubrication points require specialized lubricants. Refer to the Lubrication Chart in this section and the component manufacturer's operating manuals for lubrication specifications and maintenance schedules.

#### 6.2 Truck Maintenance

##### Engine and Chassis

Proper engine and chassis maintenance is essential to the proper performance and reliability of the Stripe Hog truck. You should perform all recommended maintenance according to the manufacturers' specifications. Maintenance schedules and procedures are outlined in the truck owner's manual. They should be followed exactly.

#### Tool Boxes and Ladders

##### Tool Boxes

- Periodically lubricate all hinges and latch assemblies with a light oil.
- Periodically clean and coat gasket materials with silicone to help keep them pliable.
- Adjust latches as necessary.

##### Ladders

- Periodically lubricate all hinges.
- Periodically lubricate the retaining ball or sliding shaft on safety pins.
- Replace damaged or worn out safety pins or spring loaded safety latches immediately if the spring becomes weak or damaged.

#### Stripe Hog Loading Ramp

- Periodically lubricate all hinges.
- Periodically lubricate the ramp assist ball hinges with oil.



*Passenger Side Lubrication Points*

A. Grease Door Hinges	D. Lubricate All Ball Valves
B. Lubricate Tool Box Hinges and Latches	E. Lubricate Ladder Hinges and Safety Pins
C. Grease Pulley Pillow Block Bearings	F. Lubricate Vacuum Canister Hinges and Latches

- Replace damaged or worn safety pins and bars immediately.

## Hydraulic Cylinders Hinge Fittings

- Grease the hinge fittings for the hydraulic cylinders with a general purpose grease weekly.

## Vacuum Canister

- Lubricate the drain valve with oil and open and close the drain valve weekly.
- Lubricate latches and hinges weekly.

## Debris tank


- Grease door hinges weekly.

## Pulley Pillow Block Bearings

- Grease weekly.

## Omsi Drive PTO and 40K Clutch

Maintenance schedules for the Omsi Drive and 40K Clutch are outlined in the Omsi Drive operating



*Omsi Drive Main Gearbox Oil Level Site Glass*



manual included with your SH8000. They should be followed exactly.

Refer to the Lubrication Chart in this section for lubrication specifications

### Weekly:

- Check fluid level in the Omsi Drive site glasses and inspect for signs of leakage. There are three site glasses, the main gearbox oil level on the driver side near the frame, the hydrostatic drive gearbox oil level on the passenger side at the hydrostatic motor and on the 40K clutch oil level on the forward passenger side of the Omsi Drive. Refer to the pictures in this section for the site glass locations and add fluid as required.
- Inspect components for loose bolts and universal joints.

### Periodic Maintenance:


- Grease drive shaft splines and universal joints monthly.
- Change fluid in Omsi Drive components as recommend in the operators manual.

## 6.3 UHP Pump & Vacuum Blower Drive Belts


The primary drive belts that connect the 40K clutch to the UHP pump and vacuum blower are special carbon fiber industrial belts that are designed for high horsepower applications.

The ribbed drive belts are matched to grooved pulleys and have very little stretch. Therefore, they typically don't need to be adjusted often and proper belt tension is extremely important when adjustment is required. The belts are strong enough to cause severe damage to bearings, shafts and other components if they are set too tight. Additionally, if a belt is too loose, it can ride on top of the grooves in the pulleys and become too tight.

Make sure you follow the instructions and set the tension to proper specifications when adjusting the drive belts. Never overtighten them.



*Hydrostatic Drive Gearbox Oil Site glass*



*Omsi Drive Component Site Glass Locations*



*Typical Waterblasting Drive Belt Configuration*





## WARNING



OVERTIGHTENED DRIVE BELTS CAN CAUSE SEVERE DAMAGE TO PULLEYS, SHAFTS AND BEARINGS IF THEY ARE ADJUSTED TOO TIGHT OR MISALIGNED. ALWAYS MAKE SURE THE BELTS ARE PROPERLY ALIGNED AND SET TO THE MANUFACTURES SPECIFICATIONS WHEN THEY REQUIRE ADJUSTMENT AND NEVER OVERTIGHTEN THE BELTS.

### Drive Belt Inspection and Maintenance Daily:

- The belts must be inspected before each shift for damage, tension and alignment.

### Periodic Maintenance:

- Check drive belt tension, pulleys and belt alignment monthly. Adjust or replace as required.

### Checking Belt Tension

The proper way to check belt tension is to use a tension tester. While a simple spring scale type tester will do the job, the more sophisticated Sonic Tension Meter is recommended.

### Spring Scale Tester and the Force Deflection Method

The spring scale type tester is used by measuring how much force is required to deflect the belt at the center of its span by a specified distance (force deflection method), as shown in the sketch on this page.


### Checking belt tension using the force deflection method:

- At the center of the span, apply a force perpendicular to the span large enough to deflect the belt on the drive from its normal position. One sprocket should be free to rotate. Be sure the force is applied evenly across the entire belt width. Place a piece of steel or angle iron across the belt width to deflect the entire width of the belt evenly.
- If it is less than the minimum recommended deflection force, the belt should be tightened. If it is greater than the maximum recommended deflection force, the belt should be loosened.

### Force Deflection Method Belt Tension Specifications:

#### UHP pump belt tension

New Belt = .70" (1.8cm) deflection @ 143-154 LBS pressure.



Checking Belt Tension using the Force Deflection Method



Typical Gates Sonic Tension Meter

Used Belt (more than 20 hours of operation) = .70" (1.8cm) deflection @ 109 - 120 LBS pressure.

### Blower belt tension

New Belt = .82" (2.1cm) deflection @ 37-40 LBS pressure.

Used Belt (more than 20 hours of operation) .82" (2.1cm) deflection @ 30-32 LBS pressure.

### Sonic Tension Meter Method

The Sonic Tension Meter detects the vibration frequency in the belt span, and converts that measurement into the actual static tension in the belt.

### Checking belt tension using a sonic tension meter:

Begin by entering the belt unit weight, belt width, and the span length. To measure the span vibration, press the "Measure" button on the meter, tap the belt span, and hold the microphone approximately 1/4" (.6mm) away from the back of the belt. The Sonic Tension Meter will display the static tension vibration frequency.

If the frequency is lower than the minimum recommended frequency, the belt should be tightened. If it is higher than the maximum recommended frequency the belt should be loosened.

### Notice:

The procedure in this example is for the Gates Sonic Tension Meter shown. Sonic meters from different manufacturers will require procedures unique those meters. **Sonic Meter Belt Tension Frequency Specifications:**

### UHP Pump Belt Tension Frequency

New Belt = 61-63 Hz

Used Belt (more than 20 hours of operation) = 52-55 Hz

### Blower Belt Tension Frequency

New Belt = 46-48 Hz

Used Belt (more than 20 hours of operation) = 39-41 Hz


Refer to the belt manufacturer's manual for additional maintenance information on the drive belts.

### Drive Belt Adjustment

The UHP pump and vacuum blower are on slotted, adjustable mounts. A threaded adjusting bolt on each side of vacuum blower mount is used for adjusting and aligning the blower drive belt. A single adjusting bolt in the center of the UHP pump mounts is used to adjust the UHP drive belt.



UHP Pump Drive Belt Adjusting Bolts



Vacuum Blower Drive Belt Adjusting Bolts

### Drive Belt Adjustment Procedure:


1. Loosen the four bolts on the slotted holes on the mounting plate just enough to allow the plate to move. Make sure not to loosen them too much.
2. Rotate the adjusting bolts on each side of the blower mount equally or the use the center bolt on the UHP pump to adjust the belt to the proper specification. Use a spring scale tester or sonic tension meter to achieve proper tension.
3. Check the pulley alignment with a straight edge against the outside face of the drive and driven pulleys to make sure the pulleys are parallel.

### Important:

**Tighten the mount bolts on the slotted holes and recheck the belt tension and alignment. Readjust as necessary to achieve correct belt tension and/or alignment.**



4. Tighten the bolts on the slotted holes.
5. Start the engine and engage the PTO and activate the 40K clutch at idle speed for 30 seconds.
6. Deactivate the 40K clutch, disengage the PTO and shutdown the engine.
7. Check that the belt is riding on the center of the pulleys. If it is not centered and riding hard on either side of the pulleys, the blower or UHP pump will have to be aligned slightly using the mounting plate adjusting bolts. Repeat alignment and tension steps until the belt is set to the proper tension and centered on the pulleys.
8. Tighten the mounting bolts securely.




UHP Pump and Packing Lube Metering Valves

### 6.4 High Pressure Blasting System & Charge Pump


The 40K UHP pump operates at very high pressures and has specific lubrication and maintenance requirements. Refer to the Lubrication Chart in this section and the pump manufacturer's operating and maintenance manual for lubrication specifications and maintenance schedules.

#### UHP System Inspection and Maintenance Daily:

- Check for obvious loose mounting nuts and bolts.
- Check all hoses, fittings, valves and seals for leaks and proper operation daily. Repair or replace leaking or malfunctioning components before operating the system.
- There are filters in the water system immediately before the high pressure pump to remove any particulates from the water prior to entering the UHP pump. These filters should be changed when dirty or when the charge pump pressure is 30 PSI (2.1 Bar) or less. The filters are typically replaced daily.
- Make sure cooling water is flowing to the plunger packing seals when the charge water is activated. Constant water flow is essential to lubricate and cool the seals.
- Make sure the cooling water sump and drain are clean for proper drainage.



UHP Pump Weep Holes



UHP Pump Packing Lube Lines and Sump



- Check for water dripping from UHP Pump weep holes during high pressure test. Water dripping from the square holes indicates the face seals are leaking. Water leaking from round high pressure seal indicates the high pressure seals are leaking. Find and correct the problem before waterblasting.
- Test the dump valve for proper operation daily. Never operate the system if the dump valve is not working properly.
- Check the bypass valve and make sure it is operating properly.

### Periodic:

- Service the pump as recommended in the pump operating manual. Change crankcase lubricating oil after the first 100 hours and every 500 hours thereafter.

### Important:

**Make sure to install the safety plug in crankcase drain valve when draining is complete. The safety plug prevents crankcase oil from draining if the valve is accidentally opened.**

- Check pulley clearances and drive belt tension at least once each month.
- Check and tighten all mounting bolts and hardware.
- Inspect all hoses and fittings weekly for signs of deterioration, chaffing and leaks. Repair or replace as necessary.
- Inspect and lubricate ball valves periodically. Make sure to open and close all ball valves at least once each month to keep them free and operating properly.
- Inspect and lubricate the manual bypass valve to keep it operating properly.


### Charge Pump

Information and owner's manuals for the charge water system components are included with this manual. Refer to this information for additional operation and service data.

- Periodically inspect the charge pump, hoses and fittings for leaks and signs of wear or deterioration. Any questionable or leaking components should be repaired or replaced before operating the system.



*UHP Pump Oil Sump Level Indicator and Oil Fill*



*Typical UHP Pump Crankcase Drain Valve and Safety Plug*

- If the Charge Pump pressure is lower than 25 PSI, replace both of the filters between the charge pump and the high pressure pump.

To change the filters, make sure the system is not engaged and the switches for the charge water pump and 40K clutch are off. If necessary, relieve the pressure in the system. Refer to the filter installation and maintenance guide included with this manual for detailed information on replacing the filter elements.

### Bilge Pump

The bilge pump returns packing cooling and lube water from the ultra high pressure pump to the debris tank. It is a centrifugal pump that requires little maintenance. It can run dry for short peri-

ods without damage, but prolonged dry operation will cause the seals to overheat and damage the pump.

Information and owner's manuals for the bilge drain system components are included with this manual. Refer to this information for additional operation and service data.

### Inspection and Routine Maintenance: Daily:

- Inspect the cooling water sump in the UHP pump daily and clean any debris that may restrict drainage to the bilge pump system.
- Inspect the drain hoses and sump system for loose fittings and leaks daily.
- The bilge pump is activated by an automatic float switch in the drain sump. Monitor the operation of the bilge pump system at the start of each shift to make sure the pump and automatic switch are operating properly.

### Periodic:

- Remove the lid for the bilge drain sump box and clean debris that may reduce drainage to the bilge pump or interfere with the operation of the float switch weekly.

## 6.5 Hog Head Maintenance

The maintenance requirements for the truck and optional tractor mounted Hog Head and Hog Arm assemblies are very similar. The following maintenance procedures apply to both Hog Head units.

### Hog Head

The Hog Head must be inspected daily and serviced as required.


### The following service procedures apply.

#### Daily:

- Grease the thru-shaft bearings daily with the lube specified in the lubrication chart.

Check the wear brush for wear and proper adjustment. Adjust and replace as necessary.


- Check all bolts and wheel nuts for anything loose.



Charge Pump



Charge Water Filters



Typical Bilge Pump



- Check hydraulic and high pressure hoses for deterioration and wear. Correct problems or replace questionable components before waterblasting.
- Check hydraulic connections for leaks – tighten if necessary.
- Test and inspect the nozzles and spray bars for proper operation and leaks. Correct any problems or questionable components before waterblasting.
- Check the swivel seal weep holes for leaks.
- Test the optional tractor mounted dump valve for proper operation daily. Never operate the system if the dump valve is not working properly.

### Periodic:

- Check wheel casters for height and excessive wear. Add shims to adjust if necessary.
- Clean and grease wheels and caster assemblies weekly.

### Hog Arm

#### Daily:

- Check all bolts and nuts. Tighten if necessary.
- Check the Hog Arm lock mechanism and make sure it is latched properly when the truck mounted Hog Arm is in the full up position.
- Check hydraulic and high pressure hoses for deterioration and wear daily. Replace hoses and fittings as necessary.

#### Periodic:


- Clean and grease Hog Arm bearing assemblies weekly. Note that the tractor Hog Arm bearings are sealed and lubricated by the hydraulic system and do not have grease fittings.
- Lubricate Hog Arm lock mechanism weekly.

Refer to the Lubrication Chart and System Maintenance Matrix in this section for lubrication specifications and maintenance schedules.


## 6.6 Hydraulic System Maintenance

### Hydraulic Pump

The hydraulic pump operates at very high pressures and has specific maintenance requirements. You should perform all recommended maintenance



Truck Mounted Hog Head



Truck Mounted Hog Arm & Hog Head Lubrication Points

according to the pump manufacturers' specifications.

- Check the hydraulic oil level each day or immediately following the repair of a blown hose, leaking fitting or any hydraulic system service. Use only hydraulic oil meeting the manufacturer's specifications. Refer to the Lubrication Chart in this section and the pump manufacturer's operating and information manual for information on the hydraulic system and oil specifications.



- Check all hoses, fittings, valves and seals for leaks and proper operation daily. Repair or replace leaking or malfunctioning components before operating the system.
- Change the filter in the return line at the hydraulic oil reservoir fill cap. The filter removes any debris that may enter the system and should be changed as necessary or specified by the pump manufacturer.
- Check the pressure indicator on the high pressure filter and make sure it is well within the green zone. Change the filter cartridge when the indicator moves near or into the red zone.
- Inspect the cooling fins for the oil cooler and clean as necessary. The cooler is critical in maintaining acceptable oil temperatures in the hydraulic system and must be kept clean to maintain efficiency.
- Monitor the cooling fan operation and make sure it is activating when necessary, sounds normal and pulls a strong flow of air through the cooler.


Refer to the Lubrication Chart and System Maintenance Matrix in this section for lubrication specifications and maintenance schedules.

### 6.7 Vacuum System & Debris tank Blower and Filter Canister


The vacuum blower has specific lubrication and maintenance requirements. Refer to the vacuum blower manufacturer's operating manual for lubrication specifications and maintenance schedules.

Be sure vacuum filter is always in good operating condition so it fully protects the blower from collecting vacuumed debris internally. If debris ever gets into the blower impellers, use a paint or lacquer thinner or other non-corrosive cleaner to remove any residue build-up inside. It will be necessary to remove the silencer in order to clean the blower. Remember that if large debris gets into the blower, it can cause severe damage to the blower.

Refer to the Lubrication Chart in this section and the blower manufacturer's operating manual for lubrication specifications and maintenance schedules.




*Typical Hydraulic System*



*Hydraulic Oil Fill and Filter*



*Vacuum System Blower*



*Blower Pulley End Grease Fittings*




*Vacuum Filter and Access Door*

### Inspection and Routine Maintenance: Daily:

- Check for obvious loose mounting nuts and bolts.
- Grease blower drive end and idler pulley bearings with the lube specified by the blower manufacturer.
- Check the vacuum canister door seal to ensure good vacuum sealing. Clean or replace the seal if necessary.
- Clean the filter before each shift and drain the filter canister at least once every 2 hours of operation for optimal performance. Filters may be cleaned with a pressure washer up to 2000 PSI (138 bars). A mild solvent solution may be used to clean thermoplastic or tar residue from the filter surface. Be sure the filter media is never damaged leaving holes or thin areas that could allow vacuumed water or debris to get into the vacuum blower or silencer. Clean, secure filtration is necessary to keep your vacuum blower in good operating condition. Inspect the filter for deterioration and replace if necessary.

### Periodic Maintenance:

- Change blower lubricating oil after the first 50 hours and every 500 hours thereafter. Service the blower as recommended in the blower operating manual.



*Vacuum System Blower Filter canister and Drain  
Hydraulic Fluid Filter*

### Important:

**Make sure to install the safety plug in crankcase drain valve when draining is complete. The safety plug prevents crankcase oil from draining if the valve is accidentally opened.**




- Check pulley clearances and drive belt tension at least once each month.
- Check and tighten all mounting bolts and hardware.
- Lubricate filter canister inspection door hinges regularly.
- Check vacuum canister door seal and replace if necessary. Coat the seal periodically with silicone to help keep it pliable.
- Inspect and lubricate drain ball valves periodically. Make sure to open and close all ball valves at least once each month to keep them free and operating properly.
- Inspect, clean and lubricate the vacuum relief valves to keep them operating properly.
- Inspect all hoses and fittings weekly for signs of deterioration, chaffing and leaks. Repair or replace as necessary.

### Vacuum Tank and Hoses

#### Daily:

- Check vacuum hoses regularly for deterioration or cracking. Replace any damaged hoses with new hoses.
- Check hose cam-lock fittings for damage and missing O-rings and replace as needed.
- Check water hoses and connections. Replace if damaged or leaking.
- Check view tubes for cracks or damage and clean or replace as necessary.
- Check vacuum door seal to ensure good vacuum sealing and clean if necessary.
- Clean glass view globes regularly for visibility and check for damage and replace if necessary.
- Grease vacuum door hinges and lubricate ratchet binders regularly.
- Inspect and lubricate ball valves periodically.
- Inspect the cutoff ball valve each time the tank is dumped to insure it is free, not damaged or cracked and operating properly.
- Inspect Hydraulic lift components and hinge pins to ensure they are tight and in good condition.



*Blower Crankcase Drain Valve and Safety Plug*



*Vacuum Relief Valve (Kunkle Valve) on Vacuum Filter Canister*



*Debris tank & Typical View Tube*

### Periodic Maintenance:






*Cutoff Ball Valve*




*Debris tank Drain Valve*

- Inspect vacuum tank door seal to ensure good vacuum sealing and clean if necessary. Coat the seal periodically with silicone to help keep it pliable.
- Grease vacuum tank door hinges. Check the stainless steel cutoff ball valve that automatically shuts off the vacuum flow if the tank becomes full. Make sure it is free and not cracked or damaged. Clean or replace if necessary.
- Grease the hydraulic lift hinge pins and fittings Weekly.
- Inspect safety strut. Make sure the hinge pins are tight and grease pins weekly.
- Inspect and lubricate ball valves. Make sure to open and close all ball valves at least once each month to keep them free and operating properly.
- Check vacuum hoses regularly for deterioration or cracking. Replace any damaged hoses with new hoses.
- Rotate vacuum hoses in high wear locations weekly to increase their life.
- Inspect the debris liner for worn and broken parts. Clean and replace parts as necessary to keep the liner operating properly.



*Hydraulic Lift, Safety Strut and Lubrication Points*



*Debris tank Door, Hinges, Ratchet Binder and Door Seal*

### 6.8 Stripe Hog Tractor (SH8000T)

Proper engine and component maintenance is essential to the performance and reliability of the Stripe Hog tractor. You should perform all recommended maintenance according to John Deere's specifications. Maintenance schedules and procedures are outlined in the tractor's owner's manual and the System Maintenance Matrix in this section. They should be followed exactly.

#### Daily Inspection:

- Fuel, oil, coolant leaks.
- Loose bolts, electrical connections.
- Worn belts.
- Trash build up.
- Fuel, lube oil, and coolant levels.
- Air cleaner.
- Hydraulic fluid reservoir level and hydraulic lines for leaks.
- Lubricate and service the Hog Arm and Hog Head as stated in this section.



*Optional Tractor*

## 6.9 Lubrication Chart

Equipment	Component	Intervals	Lubricant Specifications
Truck Engine	Oil and Filter	Refer to truck operating manual	Refer to truck operating manual
Truck Transmission	Oil and Filter	Refer to truck operating manual	Refer to truck operating manual
Truck Differential	Differential Oil	Refer to truck operating manual	Refer to truck operating manual
Omsi Drive	Main Gearbox	After 1 <sup>st</sup> 100 Hours Then every 600 Hours	Mobile Non Detergent 80w90
Omsi Drive	40K Clutch	After 1 <sup>st</sup> 100 Hours Then every 600 Hours	Dextron III Automatic Transmission Fluid
Omsi Drive	Hydrostatic Drive Motor	After 1 <sup>st</sup> 100 Hours Then every 600 Hours	Shell Spirax – Non Detergent 80w90
Hydraulic System	Hydraulic Oil Reservoir	Every 600 Hours	Napa – Aw68
Roots Vacuum Blower	Blower Crankcase Oil	After 1 <sup>st</sup> 50 Hours Then Every 500 Hours	ISO VG 320 Roots Oil High Temp – Synthetic
Roots Vacuum Blower	Pulley End Bearings (Grease fittings)	Daily (4 pumps each fitting)	Shell Darina EP NLGI Grade #2 Grease - Product Code 71522
Jetstream Pump	Grease Points	Weekly	Mobil PolyRex EM Grease
Jetstream Pump	Crankcase Oil	After 1 <sup>st</sup> 100 hours Then Every 500 Hours	High Grade 80w90 Gear Oil
<b>NEVER RUN BLOWER OR JETSTREAM PUMP UNDER LOAD IF CRANKCASE OIL TEMPERATURE IS BELOW 60 DEGREES F ( 16 DEGREES C ) START ENGINE AND IDLE FOR 10 MINUTES UNDER LOAD UNTIL OIL WARMS ABOVE 60 DEGREES F ( 16 DEGREES C )</b>			
Tractor – Engine	Engine Crankcase Oil & Filter	After 1 <sup>st</sup> 50 Hours Then Every 200 Hours	15w40 Shell Rotella Oil 15w40 Mobil Oil
Tractor – Grease Points	Refer to Tractor Manual	After 1 <sup>st</sup> 50 Hours Then Every 200 Hours	Mobil PolyRex EM Grease
Tractor – Hydraulic System	Hydraulic Oil & Filter <i>Clean Hydraulic Suction Line &amp; Strainer</i>	Every 600 Hours	John Deere Hydraulic Oil or Equivalent
Hog Head	Swivel Shaft or Thru-Shaft Motor Bearings	Daily	Mobil PolyRex EM Grease <b>No Substitutes</b>
Hog Head	Chassis Wheels and Casters	Daily	Mobil PolyRex EM Grease
Hog Arm	Hog Arm Bearing Assemblies	Weekly	Mobil PolyRex EM Grease
Hog Arm	Hog Arm Hinges and Other Grease Fittings	Weekly	Mobil PolyRex EM Grease
Unit General Grease Points	Hydraulic Ram Pivots – Door Hinges – Waste Tank Tilt Pins – ETC.	Weekly <b>More Frequently if Required</b>	Mobil PolyRex EM Grease
Unit General Lubrication Points	Vacuum Door Hinges – Ball Valves – Latches – ETC.	Weekly <b>More Frequently if Required</b>	General Purpose Oil
<b>This chart is a guide only and should never be used to supersede individual manufacturer's specifications. Please refer to your equipment manuals.</b>			



THIS PAGE WAS LEFT BLANK  
INTENTIONALLY


### Component Repair

#### 7.1 Swivel Shaft Repair


##### Swivel Seal Replacement

(MP2010 Swivel Shaft Assy. Diagram)


1. Remove UHP hose from top of swivel fittings. Loosen swivel nut (1) and remove. Pull swivel seal adapter (2) up evenly and straight in one motion without any side to side movement.
2. Remove brass back-up ring (4) from swivel seal adapter (2) with two 6/32 screws. Clean thoroughly. Make sure there are no dings, burrs or scratches on beveled flute and center shaft hole of the brass back-up ring (4). If brass back-up ring (4) is damaged, replace with a new one.
3. Use an extractor tool (T-6452) to remove spent swivel seal (3). Clean swivel seal adapter (2) of any debris, including the two pressure relief holes on bottom side.
4. Clean swivel shaft (8) nipple and upper cup of swivel shaft housing (5) area thoroughly, taking care not to get any dirt or debris into shaft center. Re-insert brass back-up ring (4) on swivel shaft nipple. Apply silicone lubricant around outside the swivel seal and of swivel shaft nipple, being careful not to get any inside the swivel shaft center. Slide a new swivel seal (3) onto the swivel shaft nipple with the beveled end facing down to the matching surface of the brass back-up ring (4).
5. Carefully replace swivel seal adapter (2) into swivel shaft housing (5) pressing straight down without any side to side motion. Be certain swivel seal adapter is fully inserted – failure to completely insert this will result in housing and adapter damage. Reconnect & tighten swivel nut (1). Reconnect UHP hose.



Hog Head Assembly




ITEM NO.	QTY.	PART NO.	DESCRIPTION
1	1	MP6504	NUT, SWIVEL MPMA
2	1	MP6524	ADAPTER, SWIVEL SEAL
3	1	MP2253	SEAL, SWIVEL
4	1	MP2752	RING, BRASS BACKUP
5	1	MP10025S	HOUSING, SWIVEL SHAFT
6	1	BR1001	SEAL, UPPER SWIVEL SHAFT
7	1	BR1002	BEARING, UPPER SWIVEL SHAFT
8	1	MP1001	SWIVEL SHAFT
9	1	BR1006	KEY, SHAFT & BUSHING
10	2	BR1003	BEARRING, LOWER SWIVEL SHAFT
11	1	BR4000-11	SEAL, COVER TOP
12	1	MP4000-1T	COVER, TOP (MAIN BODY HOUSING)
13	4	HD4000-07	BOLT, COVER TOP TO SWIVEL HOUSING
14	1	BR1007	RING, SNAP, 1"
15	1	BR1003R	BEARRING, SWIVEL SHAFT, LOWER, RADIAL



**MP 2010 SWIVEL  
SHAFT ASSEMBLY**

REV 3  
7-27-06

<b>PROPRIETARY AND CONFIDENTIAL</b> THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF WATERBLASTING TECHNOLOGIES. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF WATERBLASTING TECHNOLOGIES IS PROHIBITED.				 3341 SE SLATER ST STUART, FL 34997 (772) 223-7393		DO NOT SCALE DRAWINGS	
						<b>WATERBLASTING TECHNOLOGIES</b>	
MATERIAL:				DESCRIPTION: SWIVEL SHAFT ASSEM			
PART NUMBER: MP2010				SIZE 11"x17"			
DWG. NO. 1				DATE: Wednesday, October 11, 2006 9:42:36 AM			
SHEET 1 OF 1							



### Swivel Shaft Assembly Cleaning/ Disassembly

(MP2010 Swivel Shaft Assy. Diagram)

**In the event of repetitive swivel seal failure, it is necessary to remove the swivel shaft (8) and clean the swivel shaft housing (5) of all debris.**

1. Follow Swivel Shaft Replacement steps 1 – 5. (Below)
2. With swivel shaft (8) removed, clean the debris cavity in the upper swivel shaft seal (6) of all debris. Using a fine pick or wire, run through weep holes (total of 4) in top rim of swivel shaft housing (5) to dislodge debris build-up.
3. Once debris is loose, carefully pick fragments from swivel hole in the housing. Take care not to damage the rubber lip of upper swivel shaft seal (6).
4. Repeat steps 2 & 3, flushing with water and/or air until area is clean of debris. Do not use brake or carburetor cleaner as it will deteriorate the rubber seal.
5. Next, inspect the bearings (7, 10 & 15) for wear, debris or roughness. If you have any question on the life and performance of the bearings, replace them. If they are in good working order, clean with a solvent and re-pack with grease.
6. Reassemble swivel shaft (8) assembly into swivel shaft housing (5). When inserting swivel shaft (8) with bearings, insert only until bearings are flush with the edge of the swivel shaft housing (5); the top cover (12) will put shaft into proper position when tightened. Replace top cover (12) and snap ring (14).

### Swivel Shaft Replacement

(MP2010 Swivel Shaft Assembly Diagram)

1. Remove UHP hose, swivel nut (1), swivel seal adapter(2), brass backup ring (4) and swivel seal (3) from top of swivel shaft assembly.
2. Lift the Hog Head and place a 3/4" wrench through shroud slot and onto swivel shaft (8) flats and remove spray bar. Next, remove brass button seal.

3. Using a large flat screwdriver, remove dirt shield and felt gasket (MP1006FG-1) from the swivel shaft (8), unscrewing counterclockwise, with 3/4" wrench on shaft until loose.
4. Remove 4 allen bolts holding complete swivel shaft assembly in place. Gently and firmly pull swivel shaft assembly (MP2010) up out of the housing block.
5. Remove snap ring (14). Remove top cover (12) attached to the swivel shaft housing (5) by unscrewing the four 1/4 - 20 cap screws (13). Holding the threaded end, pull swivel shaft (8) out of the swivel shaft housing. It may be necessary to tap on bottom of swivel shaft housing (5) with a rubber or plastic hammer to remove the shaft assembly.
6. Clean and inspect upper swivel shaft seal (6) and top cover seal (11) and replace if necessary.
7. Insert a new swivel shaft assembly (\*). When inserting swivel shaft (8) with bearings, insert only until bearings are flush with the edge of the swivel shaft housing (5); the top cover (12) will put shaft into proper position when tightened. Reassemble top cover (12) to swivel shaft housing (5). Replace snap ring (14). Replace brass backup ring (4), swivel seal (3), swivel seal adapter (2) and swivel nut (1) making sure all parts are in place correctly and tightened.
8. Making sure the timing belt is on the swivel shaft pulley correctly, place new/rebuilt swivel shaft assembly (MP2010) through the swivel shaft pulley in the block. Be sure the shaft key (9) is correctly inserted in shaft and pulley. Press the swivel shaft assembly (\*) down by hand.
9. Replace shaft dirt shield and felt gasket, brass button seal and spray bar onto the bottom of the swivel shaft, being very careful no dirt gets inside shaft. Any amount of dirt will ruin your nozzles. Keep this area very clean!

### Shaft Assembly combined parts:

1. Swivel shaft (8),
2. Upper swivel shaft bearing (7),
3. Lower swivel shaft bearings (10 & 15)
4. Lower Swivel shaft radial bearing (15)

### Swivel Shaft Drive Belt Replacement

(MP3010 Hog Head Block Assy. Diagram)


1. Remove spray bar, dirt shield (8) and felt gasket (7), shroud and bottom plate (4). Clean area good, replace bottom cover seal (3) if necessary. Check for any noticeable reasons for belt breaking. Simply slip a new belt on and reassemble.

### Hydraulic Motor Replacement


(MP3010 Hog Head Block Assy. Diagram)

1. Lift up entire head assembly. Remove spray bar, brass button seal, and dirt shield (8) and felt gasket (7). Remove 3 bolts (9/16") that hold the shroud to the bottom of the housing block (1).
2. Remove hydraulic hoses, keeping feed line separate from return line. Insert hydraulic line hose plugs to reduce fluid loss.
3. Remove 4 flat head screws (5) holding bottom cover (4). Remove bottom cover (4) and clean thoroughly inside block.

4. Using an allen wrench, remove allen screws (17) from taper lock bushing (14) and timing pulley (16). Insert one Allen screw into center hole in bushing/pulley and tighten to remove the bushing from the pulley. It may be necessary to tap lightly on the timing pulley (16) to help break the bushing loose from the shaft. Be careful not to lose shaft & bushing key (15).
5. Loosen the 9/16" bolts (29) holding the hydraulic motor (9) to the top of the block. Lift the hydraulic motor off the block.
6. Re-install a new motor by reversing steps E-A.
7. Make sure timing pulley (16) is installed with clearance to the housing block (1) and is aligned with the swivel shaft pulley (2) to ensure belt alignment. Use loctite on the small 10-32 Allen screws (17) that tighten taper lock bushing into the pulley.
8. Re-install the bottom cover (4) with screws, shroud, dirt shield (8) and felt gasket (7), brass button seal, and spray bar.




ITEM NO.	PART NUMBER	DESCRIPTION	MP3010/QTY.
1	MP4000-1A	HOUSING BLOCK	1
2	BR1008	PULLEY, TIMING (SWIVEL SHAFT)	1
3	BR4000-12	SEAL, BOTTOM COVER	1
4	MP4000-1B	COVER, BOTTOM (MAIN BODY HOUSING)	1
5	HD4000-06	BOLT, COVER BOTTOM TO HOUSING BLOCK	4
6	HD4000-04	BOLT, COVER TOP TO HOUSING BLOCK	4
7	MP1006-FG	FELT GASKET	1
8	MP1006	SHIELD, DIRT	1
9	HY113	MOTOR, HOG HEAD ROTATION	1
10	FY4000-17	FITTING, HYDRAULIC MOTOR	2
11	MP4000-18	EXTENDER, MOTOR SHAFT	1
12	1173882	SCREW FLAT HEAD 1/4-20 x 3/4 SS	1
13	BR1006-A	KEY, MOTOR SHAFT EXTENDER	1
14	BR1004	BUSHING, TAPER LOCK	1
15	BR1006	KEY, SHAFT & BUSHING	1
16	BR1005	PULLEY, TIMING (HYD. MOTOR)	1
17	BR1005 (SET SCREW)	SET SCREW (COMES W/ BR1005 PULLEY)	2
18	BR4000-10	BELT, TIMING	1
19	HD4000-08	BOLT, HYD MOTOR TO HSNG BLOCK	2
20	87925186	WASHER, SPLIT LOCK, 3/8 SS	2



**MP 3010 HOG HEAD BLOCK ASSY**

**REV 3**  
**7-20-06**

PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THE DRAWING IS THE SOLE PROPERTY OF WATERBLASTING TECHNOLOGIES. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF WATERBLASTING TECHNOLOGIES IS PROHIBITED.



3341 SE SLATER ST STUART, FL 34997  
(772) 223-7393

DO NOT SCALE DRAWINGS

**WATERBLASTING TECHNOLOGIES**

DESCRIPTION:  
HOG HEAD BLOCK ASSY


PART NUMBER:  
MP3010

DATE: Thursday, July 20, 2006 12:02:05 PM

SHEET 1 OF 1



### 7.2 Thru-Shaft Motor Bearing Pre-Load



The bearing preload setting in the thru-shaft hydraulic motor that spins the spray head is critical to the proper operation of the thru-shaft motor. The bearings are carefully preset at the factory. Then, each motor is run for several hours to break-in the bearings and components. When break-in is complete, the bearing preload is reset and the motors are tested again on the truck and with pressure applied. This normally ensures trouble free operation of the thru-shaft motors and they don't require further adjustment.

Even though every effort is made at the factory to ensure the through shaft motors are properly broken-in and will provide trouble free operation, there are situations where the bearing preload will need to be reset after the truck has been operating

in the field for a period of time. Setting the bearing preload is not difficult and will not take much time. The following instructions will guide you through the bearing preload process and provide the information you need to do the job properly and in the shortest possible time.

The Instructions provide information on the tools and materials you will need as well as the step by step process. You can save time by reading the instructions completely before beginning and making sure you have all the tools and supplies you will need readily available.

If you have any questions or require assistance, please don't hesitate to contact Waterblasting Customer Service at 772-223-7393.

## Tools and Materials Required

### Tools

- 2 - Medium Sized Flat Blade Screwdrivers
- 1 - Medium Sized Channel Lock Pliers
- 1 - 3/4" (19mm) Open End Wrench
- 1 - 15/16" (24mm) Open End Wrench
- 1 - 15/16" (24mm) Box End Wrench
- 1 - 15/16" (24mm) Deep Well Socket
- 1 - 1 1/8" (28mm) Deep Well Socket
- 1 - 1/2" Drive Ratchet Wrench
- 1 - 1/2" Drive Torque Wrench
- 1 - Spanner socket (weldment tool)  
(Supplied in your Truck Tool Kit)
- 1 - 6 mm Allen Wrench

### Supplies

- Anti-Seize
- Grease Gun and Multi-Purpose Grease
- Rags or Paper Towels
- 9396K21 O-ring (Supplied in Spare Parts Kit)

### Notice:

**Use anti-seize compound on bolt and thru-shaft threads and threaded hose connections to prevent galling.**



### WARNING



INJURIES FROM ULTRA HIGH PRESSURE WATERBLASTING IS VERY SERIOUS AND CAN RESULT IN A FATALITY. ALWAYS MAKE SURE ALL PERSONNEL ARE A SAFE DISTANCE FROM THE WORK AREA BEFORE THE PRESSURE PUMP IS ENGAGED. NEVER PUT HANDS, FEET OR ANY PART OF YOUR BODY IN OR NEAR THE HIGH PRESSURE STREAM.






Figure 1: High pressure hose on top of the thru-shaft motor



Figure 2: High pressure hose removed

## Step 1

### Remove the High Pressure Hose

Remove the high pressure hose from the top of the thru-shaft motor by turning the hand nut at the base of the hose counterclockwise. If the hand nut is too tight to turn by hand, use the channel lock pliers to free it, then continue loosening it by hand. Figure 1 and 2.




Figure 3: Thru-shaft motor on work bench showing position of slot and 3/4" open end wrench.




Figure 4: Location of slot in thru-shaft motor mounted on hog head for 3/4" open end wrench.

## Step 2

### Insert Wrench to Hold Thru-Shaft

Insert the 3/4" (19mm) open end wrench through the slot in the base of the thru-shaft motor. The slot is located between the hog head chassis and the spray head. Figure 3 and 4.





Figure 5: Use two medium flat head screwdrivers to remove the thrust housing cap. Note that the bolts are loose and left in place to prevent thrust housing cap from falling and being damaged during removal.

### Step 3

#### Remove Thrust Housing Cap

Use a 6mm Allen wrench to remove the 6 Allen head bolts that secure the thrust housing cap to the thrust housing. Make sure to leave each bolt loose and turned 3 threads in as shown in figure 5. The loosened bolts will allow the cap to be removed and prevent the possibility of the cap falling once it is free from the thrust housing.

Use the two medium sized, flat head screwdrivers and insert them into the slots at each side of the base of the thrust housing cap. Slowly and carefully twist the screwdrivers to work the cap evenly off the thrust housing until it is free. Figure 5.

Note that the O-ring seal in the thrust housing cap will provide some resistance until it is clear of the thrust housing. The cap will tend to “pop” slightly when the O-ring clears the base.

Once the thrust housing cap is free, remove the Allen bolts and the cap.

Inspect the cap and O-ring seal for damage. Replace O-ring if necessary and place the cap assembly in a safe, clean location. Figure 6.



Figure 6: Thrust housing cap removed. Note the O-ring seal and the slots for the screwdrivers. Make sure the cap and O-ring is in good condition and clean.






Figure 7: Swivel Tit assembly/gland nut to be removed by turning counterclockwise with a 15/16" deep well socket or box end wrench.

### Step 4

#### Remove Swivel Tit Assembly/Gland Nut

While holding the thru-shaft with the 3/4" (19mm) open end wrench through the slot in the motor base, use a 15/16 (24mm) deep well socket or box end wrench to remove the swivel tit assembly/gland nut by turning it counterclockwise. Inspect the swivel tit assembly and set it in a safe, clean location. Figure 7 and 8.



Figure 8: 3/4" (19mm) open end wrench holding thru-shaft and preventing it from turning while removing swivel tit assembly/gland nut.






Figure 9: Jam nut and seal nut. Make sure to loosen Jam nut 4 full turns first.




Figure 10: Use spanner socket (weldment tool) to turn seal nut.

## Step 5

### Loosen Jam Nut and Set the Bearing Preload

While holding the thru-shaft with the 3/4" (19mm) open end wrench through the slot in the motor base, use a 1 1/8" (28mm) deep well socket to loosen the jam nut by turning it counterclockwise. Loosen the jam nut 4 full turns and stop. Figure 8 and 9.

While holding the thru-shaft with 3/4" (19mm) open end wrench, use the spanner socket (weldment) tool to Loosen the seal nut 2 full turns. Then put a rag on the spanner socket for padding and tighten the seal nut as tight as you can by hand to set the bearing. Figure 8 and 10.

Once the bearing is set, loosen the seal nut 2 full turns.

Hold the thru-shaft firmly with the 3/4" (19mm) open end wrench and use the spanner socket to hand tighten the seal nut until it is "snug." **Do not over-tighten!!** Figure 8 and 10.

**Then hold the thru-shaft firmly with 3/4" open end wrench so it doesn't move at all** and set the bearing preload by carefully loosening the spanner socket and seal nut one bolt hole. Then thread 2 - 3/8" thrust housing cap bolts through the holes in the spanner socket and into the threaded holes in the thrust housing to hold the spanner socket in that position. Figure 11.




Figure 11: Spanner socket secured with thrust housing cap bolts.





# WARNING



WHEN LOOSENING THE SPANNER SOCKET AND SEAL NUT ONE BOLT HOLE TO SET THE BEARING PRELOAD OR WHEN TIGHTENING THE JAM NUT, IT IS CRITICAL THAT THE THRU-SHAFT IS HELD FIRMLY WITH THE 3/4" (19MM) OPEN END WRENCH SO THAT IT DOES NOT MOVE AT ALL. IF THE WRENCH AND THRU-SHAFT MOVE DURING THIS PROCEDURE, THE BEARING PRELOAD WILL BE INCORRECT AND THE THRU-SHAFT MOTOR WILL NOT OPERATE PROPERLY.

IF THE THRU-SHAFT MOVES DURING WHILE SETTING THE BEARING PRELOAD, YOU MUST REPEAT STEP 5 TO ENSURE PROPER BEARING PRELOAD.




Figure 12: Thrust housing cap bolts securing the spanner socket are snug and a torque wrench and 1 1/8" deep well socket is used to tighten the jam nut to 50 Ft lbs.

## Step 6

### Set the Jam Nut Torque and Remove Spanner socket (Weldment Tool)

Tighten the bolts holding the spanner socket to "snug."

While holding the thru-shaft with the 3/4" (19mm) open end wrench through the slot in the motor base and the spanner socket held with the thrust housing cap bolts, use a 1 1/8" (28mm) deep well socket and a torque wrench to tighten the jam nut to 50 ft lbs. Figure 12. **Make sure the thru-shaft and 3/4" (19mm) open end wrench do not move at all during this procedure!!**

Remove the thrust housing cap bolts from the spanner socket and remove it from the housing. Now it is safe to move the thru-shaft.



Figure 13: O-ring seal at the top of the thru-shaft greased and the threads below the seal coated with anti-seize.



Figure 14: Swivel tit assembly/gland nut installed on the thru-shaft and torqued to 50 Ft lbs.

## Step 7

### Install the Swivel Tit Assembly/Gland Nut.

Inspect the O-ring seal near the top of the thru-shaft and make sure it is not damaged. Replace the O-ring if it shows any sign of nicks, cuts, deterioration or wear. Then apply a light layer of grease to the O-Ring. The grease will help the swivel tit assembly slide over the O-ring and reduce the possibility for the O-ring to be pushed out of the seat or damaged as the swivel tit assembly is installed. Figure 13.

Apply anti-seize to the thru-shaft threads. The anti-seize is extremely important and will prevent the stainless steel threads on the shaft and swivel tit assembly from galling and seizing. ***If anti-seize is not used and the threads seize, the thru-shaft and the swivel tit assembly will be ruined and the thru-shaft motor will have to be completely disassembled and rebuilt!!***

While holding the thru-shaft with the 3/4" (19mm) open end wrench, install the swivel tit assembly/gland nut and hand tighten. Then use a 15/16" (24mm) deep well socket and a torque wrench to tighten swivel tit assembly/gland nut to 50 ft lbs. Figure 14.

## Step 8

### Install the Thrust Housing Cap.

Inspect the O-ring seal in the thrust housing cap. Replace the O-ring if it shows any sign of nicks, cuts, deterioration or wear. Then apply light layer of grease to the O-Ring. The grease will help the cap assembly slide into the torque housing and reduce the possibility for the O-ring to be pushed out of the seat or damaged as the assembly is installed. Figure 15.



Figure 15: Inspect and grease the O-ring seal on the thrust housing cap.



### Step 8 (cont)

Set the thrust housing cap on top of the thrust housing and carefully press it into the housing. Align the bolt holes in the cap to the threaded holes in the thrust housing. Apply Anti-seize to the 3/8" Allen bolts and hand tighten using a crisscross pattern. Use the 6mm Allen wrench to tighten the thrust housing cap bolts to "snug" using a crisscross pattern. Figure 16.




Figure 16: Apply anti-seize to the thrust housing bolts and tighten them in a crisscross pattern to "snug" using a 6mm Allen wrench.



Figure 17: Apply anti-seize to the thrust housing threads and install the high pressure water line.




Figure 18: Thru-shaft bearing grease fitting and grease relief holes in thrust housing base.

### Step 9

#### Install the High Pressure Water Hose and Grease the Thru-Shaft Bearings.

Apply anti-seize to the threads on the top of the thrust housing cap and install the high pressure water hose. Hand tighten the hand nut on the pressure hose.

Use a grease gun and apply grease to the thru-shaft bearing until grease comes out of the relief hole on the side of the thrust housing.



### Step 10

**Run the Thru-Shaft Motor Without Water Pressure, Then Under Full Water Pressure.** Remove all tools and materials from the hog head and raise it to the full up position.

Activate the hydraulic system and run the thru-shaft motor at maximum rpm for 15 minutes. **Make sure not to apply water pressure during this step.**

Running motor without water pressure will fully test the thru-shaft motor operation and allow the bearings and seals to work themselves in. If the spray bar does not turn initially, use a 2' piece of wood or a broom handle to rotate the spray head counterclockwise to get it started. Figure 19.

If the thru-shaft motor is assembled properly, it will start on its own each time it is activated from this point forward. If it continues to stall on start up, contact Waterblasting Customer Service for assistance.

Once the initial run up is complete and with the spray head still turning at maximum rpm, make sure all personnel are well clear of the spray head and apply full water pressure. Run the thru-shaft motor for another 15 minutes. Figure 20.

When testing is complete and with the unit still running at maximum pressure, check the weep holes in the thrust housing cap just below the high pressure hose connection for water leakage. If water is dripping from the holes, the swivel seal in the hose fitting will need to be changed. If no water is dripping from the weep holes and the spray bar is still rotating at maximum rpm, your unit is ready to be put back into service. Figure 21.




Figure 19: Counterclockwise spray head rotation. Operate 1st 15 minutes at maximum rpm with no water pressure.



Figure 20: Operate another 15 minutes at maximum rpm and full water pressure.



### WARNING



INJURIES FROM ULTRA HIGH PRESSURE WATERBLASTING ARE VERY SERIOUS AND CAN RESULT IN A FATALITY. ALWAYS MAKE SURE ALL PERSONNEL ARE A SAFE DISTANCE FROM THE WORK AREA BEFORE THE PRESSURE PUMP IS ENGAGED. NEVER PUT HANDS, FEET OR ANY PART OF YOUR BODY IN OR NEAR THE HIGH PRESSURE STREAM.






Figure 21: Check for water dripping from weep holes just below the high pressure water hose connection.











DRAWN	DG	SIZE	DRAWING NO.	REV
CHECKED	DG	B	20025	A
ENG. APPR.	DG		SCALE: 1:3	
			WGT: 11.85 LBS	
				SHEET 3 OF 3

## 7.3 Caster Wheel Care – Hog Head Assembly

(MP4010 Caster Plate Assy. Diagram)

1. Grease wheels and caster bearings daily.
2. If necessary, remove bearing seal to clean bearings in casters. Use degreaser or brake cleaner to remove dirt and paint debris.
3. Replace worn wheels as wear will affect blasting and mobility of Hog Head.







### **7.4 Stripe Hog Dump Valve Assemblies & Diagrams**

**Tractor Dump Valve and Shut-off (diverter) Valve Repair**  
(Hydraulically operated)

1. Remove diffuser tube (2) with cartridge (3). Remove cartridge (3) from slotted end and replace with a new cartridge (3). Replace diffuser tube (2) into valve body (1).

This exploded view diagram illustrates the assembly of a hydraulic cylinder. The components are numbered as follows:

- 1**: The main body of the hydraulic cylinder, shown as a long vertical cylinder with a mounting flange at the top.
- 2**: A long threaded rod or piston rod, positioned below the main body.
- 3**: A small, coiled spring, positioned below the threaded rod.
- 4**: A hexagonal nut, positioned below the spring.
- 5**: A small cylindrical component, likely a seal or O-ring, positioned to the right of the main body.
- 6**: A larger cylindrical component, likely a seal or O-ring, positioned to the left of the main body.


11' x 17'

### **7.5 Shut-Off (Dump) Valve Repair**

(Truck Air Operated Diverter Valve Diagram)

1. Remove diffuser tube (1) with cartridge (2). Remove cartridge (2) from slotted end and replace with a new cartridge (2). Replace diffuser tube (1) into valve body (3).
2. Periodic maintenance of air actuator is necessary. Remove cap screws (8) to disassemble air cylinder (7). Clean thoroughly, check o-rings, apply silicone lubricant and reassemble.






## AIR-OPERATED DIVERTER VALVE Replacement Parts

Item	Part Number	Description
1	K51865	Diffuser
2	K53476	C-40 Cartridge
3	K53547	Body
4	K26454	Pin
5	K53425	Pusher
6	K53424	Mounting Plate
7	K27252	Air Cylinder
8	K27108	Capscrew
9	K25797	Hose Fitting


 **Waterblasting Technologies**  
3341 SE SLATER ST STUART, FL 34997  
(772) 223-7393

<small>PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF WATERBLASTING TECHNOLOGIES. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF WATERBLASTING TECHNOLOGIES IS PROHIBITED.</small>						DO NOT SCALE DRAWINGS							
						WATERBLASTING TECHNOLOGIES							
<small>3341 SE SLATER ST STUART, FL 34997 (772) 223-7393</small>				DESCRIPTION: AIR-OPERATED DIVERTER VALVE									
<table border="1"> <tr> <th>NAME</th> <th>SIGNATURE</th> <th>DATE</th> </tr> <tr> <td> </td> <td> </td> <td> </td> </tr> </table>				NAME	SIGNATURE	DATE				MATERIAL:			
NAME	SIGNATURE	DATE											
TOLERANCES UNLESS NOTED				PART NUMBER:									
.X    .XX    .XXX    ANGLES				SIZE 11"x17"									
± .025    ± .010    ± .005    ± .5				REV:									
DWG. NO. 1				DATE: Friday, April 14, 2006 5:29:19 PM									
SHEET 1 OF 1				SHEET 1 OF 1									

### 7.6 Manual Bypass Valve Repair

(Bypass Valve Assy. Diagram)

1. Remove outlet adapter (11). Pull cartridge (3) out. If cartridge (3) is stuck together and not releasing pull the pin and cartridge body apart to inspect the seats for cuts and other damage. Replace the cartridge as necessary.
2. Check diffuser (4) for damage or wear from bypass water.
3. Check all O-rings, replace any that are damaged. Lubricate all O-rings with silicone lubricant.
4. Replace cartridge (3) and reassemble to the bypass valve body (2) making sure to anti-seize all stainless steel threads.




## BYPASS VALVE Replacement Parts

Item #	Part Number	Description
1	K52145	Adjustment Knob
2	K53714	Body
3	K53726	Cartridge
4	K53727	Diffuser
5	K26453	O-Ring
6	K27642	O-Ring
7	K53725	Back-Up Ring
8	K25797	Hose Fitting
9	K50796	Locking Arm
10	K25594	Capscrew
11	K53720	Outlet Adapter
12	K27645	Nipple
13	K27646	Elbow
Not Shown	K25933	Outlet Hose (Order in Feet)




3341 SE SLATER ST STUART, FL 34997  
(772) 223-7393

<small>PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF WATERBLASTING TECHNOLOGIES. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF WATERBLASTING TECHNOLOGIES IS PROHIBITED.</small>						DO NOT SCALE DRAWINGS	
				3341 SE SLATER ST STUART, FL 34997 (772) 223-7393		WATERBLASTING TECHNOLOGIES	
MATERIAL:				DESCRIPTION: BYPASS VALVE			
TOLERANCES UNLESS NOTED .X    .XX    .XXX    ANGLES ± .025    ± .010    ± .005    ± .5				PART NUMBER:		SIZE 11"x17"	
DWD. NO. 1				DATE: Friday, April 14, 2006 5:29:49 PM		SHEET 1 OF 1	



## Drawings and Supplies

### FLUID END REPLACEMENT PARTS



Item	Part Number	Description	Item	Part Number	Description	Item	Part Number	Description
1	K53562	#6 Plunger	9a	K54144	Seal Kit	15a	K27503	O-Ring
	K53563	#7 Plunger		K28803	Retaining Ring		K53577	Base
	K53564	#8 Plunger		K53493	Spring Retainer		K53579	Hold-Down Ring
2	K54102	Gland Nut		K27510	Spring		K53680	Cap
	K26465	O-Ring	10	K53672	Adapter, Pump Discharge x 9/16" Type "M" Male	16	K53796	Water Lube Harness
3	K27480	#6 Guide Bushing		K53673	Adapter, Pump Discharge x 7/8" Type "M" Male		K26470	Hose (Order in Feet)
	K27481	#7 Guide Bushing		K53990	Adapter, Pump Discharge x 3/8" HP Female		K27476	Needle Valve
4	K27482	#8 Guide Bushing		K53989	Adapter, Pump Discharge x 9/16" HP Female	16c	K26466	Nipple
	K54117	#6 Packing	11	K53457	Manifold		K53793	Lube Manifold
5	K54118	#7 Packing		K27489	Gage, 0-60,000 PSI		K27102	Ball Valve
	K54119	#8 Packing	12	K28091	Anti-Vibration Gland Set	16e	K26875	Hose Fitting
6	K54097	#6 Sleeve		K53573	Adapter, Male Port x 9/16" HP Female		K51660	Trunnion
	K54098	#7 Sleeve	13	K53506	Rupture Disc Holder	16f	K50890	Pump Wrench
6a	K54099	#8 Sleeve					K28576	Disc, 35,000 PSI Burst
	K26522	O-Ring					K28577	Disc, 40,000 PSI Burst
7	K54100	Stuffing Box				19	K28616	Disc, 45,000 PSI Burst
8	K54126	Stuffing Box Seal					K27485	Disc, 50,000 PSI Burst
9	K53496	Uni-Valve					K27486	Disc, 58,000 PSI Burst



3341 SE SLATER ST. STUART, FL 34997  
(772) 223-7393

PROPRIETARY AND CONFIDENTIAL  
THE INFORMATION CONTAINED IN THIS  
DRAWING IS THE SOLE PROPERTY OF  
WATERBLASTING TECHNOLOGIES. ANY  
REPRODUCTION IN PART OR AS A WHOLE  
WITHOUT THE WRITTEN PERMISSION OF  
WATERBLASTING TECHNOLOGIES IS  
PROHIBITED.



3341 SE SLATER ST. STUART, FL 34997  
(772) 223-7393

DO NOT SCALE DRAWINGS

WATERBLASTING TECHNOLOGIES

DESCRIPTION:

FLUID END REPLACEMENT PARTS

PART NUMBER:

SIZE

11"x17"

REV.

DRAWN

CHECKED

ENG APPR

MFG APPR

NAME

SIGNATURE

DATE

MATERIAL:

TOLERANCES UNLESS NOTED

.X .XX .XXX ANGLES

± .025 ± .010 ± .005 ± .5

DWG. NO. 1

DATE:

Friday, April 14, 2006 5:29:19 PM

SHEET 1 OF 1



## Recommended Tools and Supplies

LOCATION	Number	Item
Truck	1	Metal Clip Board
Tool Box	1	4" Needle Nose Pliers
Tool Box	1	Screw Drive Set – All Sizes – Phillips and Flat Blade
Tool Box	1	Medium Vise Grip Pliers
Tool Box	1	¼ & 3/8 Drive SAE / Metric Socket Set
Tool Box	1	12" Channel Lock Pliers
Tool Box	1	12" Crescent Wrench
Tool Box	1	14" Crescent Wrench
Tool Box	1	2 lb Rubber Hammer
Tool Box	2	¾" Combination Wrench
Tool Box	1	Metric Allen Wrench Set
Tool Box	1	SAE Allen Wrench Set
Tool Box	1	Ball Peen Hammer
Storage	1	Bottle Hand Cleaner
Truck	2	Duck Tape
Truck	1	Fire Extinguisher
Truck	1	First Aid Kit
Storage	1	Funnel
Storage	1	Gallon Engine Coolant
Storage	1	Gallon Motor Oil
Storage	1	Gallon Transmission Fluid
Storage	2	Grease Guns (each loaded with different grease)
Storage	1	Shell Darina Micro Gel Grease
Storage	1	Ultra Duty EP NLFI 2 – Multi-Purpose Grease
Storage	1	Hydrant Wrench
Storage	1	Jet Stream Tool
Storage	1	Jumper Cables
Storage	1	Measuring Wheel
Tool Box	1	25' Measuring Tape
Truck	1	Paper Towels
Truck	1	Leather Gloves
Truck		Rain Coats for Crew
Truck	1	Road Atlas
Truck	20	Safety Ear Plugs
Truck	2	Pair Safety Glasses
Truck	2	Hard Hats
Truck	2	Safety Triangles
Truck	2	Safety Vests – DOT Class
Truck	1	Skip Counter
Truck	1	Tire Pressure Gauge
Truck	1	Window Cleaner
Storage	10	Zip Ties Large
Truck	2	Cans of Brake Cleaner

## Troubleshooting Guide

### Problem

#### HOG HEAD

##### Noises and Vibrations:

- Loose blower belts or pump belts - adjust or replace belts
- Blower or drive belts out of alignment - align and adjust belts
- Hog Head rotation extremely high - turn head rotation dial counterclockwise to reduce head speed

##### Hog Arm won't raise:

- Float mode activated - disengage float function
- Hydraulics not engaged - engage PTO to activate hydraulic system
- Hydraulic fluid low - add fluid to the hydraulic fluid reservoir
- Hose or fitting broken or leaking - tighten loose fitting or replace broken hose or fitting

##### Head doesn't spin or spins slowly

- Hydraulics not engaged - make sure PTO is engaged to activate hydraulic system
- Debris packed around thru-shaft or spray bar - clean thru-shaft or spray bar
- Blast head belt worn out - replace blast head belt
- Hog Head Shroud is concave and not convex - repair or replace shroud
- Flow control is shut off - turn on flow ball valve
- Electric connection is unplugged or no voltage to coil - check that LED light on coil is lit and repair circuit or replace coil as necessary

#### WATER LEAKS

##### Hose fitting indicator port leaking:

- Fitting Loose - tighten fitting or replace hose and fitting

##### Fluid end manifold leaking at rectangular hole in manifold block:

- Stuffing box seal is worn out - replace stuffing box ring seal

##### Fluid end manifold leaking at round hole on top of manifold block:

- Valve seals worn - replace valve seal or valve

##### Weep holes dripping at high pressure hose connection on thru-shaft motor:

- Loose swivel nut - hand tighten swivel nut
- Leaking swivel seal - remove spent seal, check shaft nipple, clean thoroughly and replace with new seal
- Cracked swivel or thru-shaft - remove shaft assembly and disassemble to inspect shaft and replace if damaged or cracked on nipple end



## Problem

### HIGH PRESSURE SYSTEM PROBLEMS

#### **Low inlet pressure - 25 PSI or less:**


- Dirty nominal and absolute filters are clogged with particulate - change filter bag and cartridge
- Low or no inlet water pressure - check to see that water charge pump is on and fresh water valve to charge pump is open
- Empty water tank - fill tank with water
- Clogged or damaged impeller on pump - disassemble pump face and clean impeller or replace with a new impeller
- Cracked water line allowing air to be sucked in - check and find any leaks and repair
- Low hydraulic fluid flow to charge pump - check hydraulic fluid level and flow
- Debris in water line from tank - flush or replace with new line

#### **Low outlet pressure - in High Pressure system:**

- Insufficient engine RPM - raise RPM of engine
- Worn or blown nozzles - change nozzles
- Oversized nozzles - refer to chart to correct nozzle pattern
- Leaks - hoses, fittings, nozzles, pump valves or seals - tighten or replace, check valves for heat indicating internal bypass
- Worn or missing button seal between spray bar and shaft - replace with new button seal
- Air lock in fluid end - remove rupture disc assembly or side port fitting, engage pump and run up to high RPM to remove air from the manifold
- Low inlet water pressure - change dirty water filters - cartridge & bag (also 20 micron in recycle mode)
- Low or no inlet water pressure - check to see that water charge pump is on and valve to charge pump is open
- 40K clutch slipping - check clutch oil level or repair clutch
- Leaking packing - determine which is leaking and change, flush and replace
- Leaking or cracked valves - check face of manifold for heat to find leaking valve and replace or rebuild
- Diverter valve (dump valve) cartridge leaking - remove return hose and check cartridge, if leaking remove diffuser tube and replace cartridge
- By-pass valve cartridge leaking - remove diffuser tube and replace cartridge
- Leaking swivel seal - remove spent seal, check shaft nipple, clean thoroughly and replace with new seal
- Cracked swivel or thru-shaft - remove shaft assembly and disassemble to inspect shaft and replace if damaged or cracked on nipple end

#### **Fluctuation or pulsing of 40K gauge or inlet pressure gauge:**

- Valve may be pitted or cracked - remove valve and check seats for damage - replace or rebuild
- Leaking packing - determine which is leaking and change, flush and replace
- 40K clutch slipping - check clutch oil level or repair clutch



*Troubleshooting WATER SYSTEM*

## Problem

### VACUUM SYSTEM PROBLEMS


#### **Vacuum Loss or Failure:**

- vacuum blower is not engaged - activate 40K switch to activate vacuum system
- Vacuum RPM not high enough - adjust RPM higher
- Vacuum filter dirty & clogged - rinse with hose or replace if too badly clogged
- Worn or improperly adjusted shroud brush - adjust or replace brush
- Broken vacuum hose or fitting - inspect hoses & fittings and replace any parts damaged
- Vacuum line plugged with debris - remove clogged hose, flush to remove blockage or replace with new hose if necessary
- Slipping or damaged vacuum belt - tighten belt or replace if worn badly
- Debris tank door leaking air or water - Compressor is not inflating seal - check compressor and repair if necessary. Seal is dirty - clean seal. Seal is damaged - replace damaged seal.
- Debris tank 4" dump valve open - clear valve of any debris and close tightly; if valve still leaks, it may be necessary to replace worn valve
- Relief valve stuck open - lubricate plate & stem and work it in and out to be sure it is free
- Vacuum filter canister door seal leaking - replace seal to eliminate vacuum leak
- Vacuum filter canister drain ball valve leaking or open - clean valve of any debris; if it is still leaking, it may be necessary to replace worn valve

#### **Relief valves stuck open & whistling:**

- A blockage in vacuum hose between the tank and the Hog Head - locate and remove blockage
- Clogged vacuum filter - Clean or replace vacuum filter and clean canister tank bottom
- High water/debris level lifting shut-off ball in debris tank - Empty water from debris tank and dump debris - clean shut-off ball to keep it from sticking shut, replace debris bag, clean door seal and close





THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

## SH8000 Specifications

LENGTH (varies slightly depending on truck chassis) \_\_\_\_\_ 37 ft / 11.3 m

WIDTH (varies slightly depending on truck chassis) \_\_\_\_\_ 10 Ft / 3 m

HEIGHT \_\_\_\_\_ 12.5 Ft / 3.8 m

EMPTY WEIGHT W/O tractor (estimated w/ fuel, water & vacuum tanks empty) \_\_\_\_\_ 38,000 lbs / 17,237 kg

WEIGHT W/O tractor (estimated W/ fuel, water & vacuum tanks full) \_\_\_\_\_ 68,000 lbs / 30,844 kg

VACUUM/DEBRIS TANK VOLUME \_\_\_\_\_ 1,500 gal / 5,678 ltr

CLEAN WATER TANK \_\_\_\_\_ 2700 gal / 10,221 ltr

BLOWER \_\_\_\_\_ Dresser Roots U-RAI 615

BLOWER CFM \_\_\_\_\_ 1389 cfm

MAXIMUM SYSTEM VACUUM \_\_\_\_\_ 13 INHG V UHP PUMP

UHP PUMP \_\_\_\_\_ Jetstream 4240

UHP PUMP GPM \_\_\_\_\_ 12 gpm / 45 ltr

MAXIMUM UHP Pressure \_\_\_\_\_ 40,000 PSI / 2,722 bar

BLOWER DRIVE BELT \_\_\_\_\_ Gates Poly Chain 14MGT-2520-37 (USA) - 14MGT-2660-37 International)

BLOWER DRIVE BELT TENSION (new) \_\_\_\_\_ 46 to 48 Hz (USA) - 47 to 49 Hz (International)

BLOWER DRIVE BELT TENSION (used - over 20 hours) \_\_\_\_\_ 39 to 41 Hz (USA) - 40 to 43 Hz (International)

UHP PUMP DRIVE BELT \_\_\_\_\_ Gates Poly Chain 14MGT-3500-90 (USA) - 14MGT-3850-90 (International)

UHP PUMP DRIVE BELT TENSION (new) \_\_\_\_\_ 61 to 63 Hz (USA) - 49 TO 52 Hz (International)

UHP PUMP DRIVE BELT TENSION (used) \_\_\_\_\_ 52 to 55 Hz (USA) - 42 to 45 Hz (International)



THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

### Pre-Start Inspection

1. Inspect all hoses for chaffing and signs of wear.
2. Check fuel level and make sure you have enough for the shift.
3. Check truck systems and fluid levels. Refer to the engine operating manual.
4. Check the fluid level and temperature in the hydraulic system.
5. Check all water blasting and vacuum components for oil leaks, damaged or loose bolts and parts.
6. Inspect the hog head for loose components and damage.
7. Check that all quick release pins on the ladders and ramps are in place, secure and in good condition.
8. Check vacuum canister for water and the vacuum filter. Drain water or clean filter as required.
9. Check the vacuum and UHP pump drive belt tension and alignment.
10. Check clean water tank level and fill if necessary.
11. Drain debris tank and check debris level. Empty if necessary.
12. Walk around truck and visually check all components and look for obvious problems.

#### **Notice:**

**If you operate at freezing temperatures or even temperatures below 60 degrees Fahrenheit (16° Celsius), it will be necessary to operate the system, including engaging the blower and high pressure pump, at IDLE speed only under load, until oil heats up above 60 degrees Fahrenheit (16° Celsius).**

## Warm Weather Shutdown

1. Turn high pressure OFF with joystick "Stop" switch.
2. Turn the 40K Clutch and Charge Water switches "OFF".
3. Allow the vacuum blower to operate for a couple of minutes after shutting down the high pressure and charge water pumps to clear waste water from hoses and dry out blower system.
4. Reduce the engine speed to idle.
5. Raise the Hog Head to the full "UP" and locked position. Make sure the locking lever is engaged and secure it with a plastic tie wrap to ensure the locking lever cannot accidentally be released during transportation.
6. Put the Truck Transmission in "N" (*NEUTRAL*).
7. Turn the PTO switch to "OFF". Listen for the PTO to disengage and then watch for the red light to turn OFF, the green light to turn ON.

**IT IS VERY IMPORTANT THAT THE PTO IS FULLY DISENGAGED TO INSURE THAT NONE OF THE FUNCTIONS WILL OPERATE ACCIDENTALLY.**

8. Drain waste water from the vacuum canister. Close the valve when draining is complete.
9. Turn the Mode switch to "OFF". It is VERY important that this switch is off to insure that the truck transmission will not go directly into 4th gear lock-up when put into DRIVE causing the truck to lunge forward.
10. Turn all other switches and dials on the control panels to "OFF" or "O".
11. When the truck is parked, set the parking brake and allow the engine to run for several minutes to cool internal components, then shut off the engine.



## Freezing Conditions Shutdown

1. Allow the vacuum blower to operate for a couple of minutes after shutting down the high pressure and charge water pumps to clear waste water from hoses and dry out blower system.
2. Make sure the clean water and debris tanks are drained immediately at the end of each shift.
3. All system hoses and the Hog Head assembly should be drained of all water and/or filled with an anti-freeze solution. (non alcohol)
4. For the 40K water blaster, refer to pump manufacturer's procedures for maintaining equipment in freezing climates.
5. Open the drain valve at the charge water pump and allow the hoses and pump to completely drain. With the valve still open, activate the pump briefly to pump out any remaining water, about a cupful. Then close the valve.
6. Pour 2 gallons of anti-freeze into the high pressure pump stuffing box sump so it will drain to the bilge pump sump system. Allow the bilge pump to run until anti-freeze is visible at the bilge pump hose fitting in the debris tank.
7. Drain the vacuum canister immediately at the end of each shift.

### Notice:

If you operate at freezing temperatures or even temperatures below 60 degrees Fahrenheit (16° Celsius), it will be necessary to operate the system, including engaging the blower and high pressure pump, at IDLE speed only under load, until oil heats up above 60 degrees Fahrenheit (16° Celsius).

THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

### Spray Bar Configuration and Nozzles



1) 8", 8 Nozzle - Most Aggressive set-up. | 5.39 GPM @ 36K psi | 5.69 GPM @ 40K psi

.....



2) 8", 8 Nozzle - Medium Aggressive set-up. | 4.73 GPM @ 36K psi | 5.0 GPM @ 40K psi

.....




3) 8", 8 Nozzle - Less Aggressive set-up. | 4.27 GPM @ 36K psi | 5.0 GPM @ 40K psi

.....





4) 8", 8 Nozzle -Least Aggressive set-up. | 3.71 GPM @ 36K psi | 3.93 GPM @ 40K psi



5) 8", 8 Nozzle - Concrete Prep/Curing Compound Removal - 25,000 - 35,000psi | 5.48 GPM @ 40K psi


## High Cohesive Nozzle Flow Chart

### FLOW - GPM @ Pressure Indicated


Orifice Dia./ins	20KPSI (1379 Bar)	26KPSI (1723 Bar)	30KPSI (2068 Bar)	36KPSI (2482 Bar)	40KPSI (2758 Bar)
0.005	0.08	0.09	0.09	0.10	0.11
0.006	0.11	0.12	0.13	0.15	0.15
0.007	0.15	0.17	0.18	0.20	0.21
0.008	0.19	0.22	0.24	0.26	0.28
0.009	0.25	0.28	0.30	0.33	0.35
0.010	0.30	0.35	0.37	0.41	0.43
0.011	0.37	0.42	0.45	0.49	0.52
0.012	0.44	0.50	0.54	0.59	0.62
0.013	0.51	0.59	0.63	0.69	0.73
0.014	0.60	0.68	0.73	0.80	0.84
0.015	0.68	0.78	0.84	0.92	0.97




6) 6" 14 Nozzle Spray Bar - 4" lines - Argessive. | 5.72 GPM @ 36K psi | 6.0 GPM @ 36K psi



7) 6", 14 Nozzle Spray Bar - 4" lines - Less Aggressive 4.48 GPM @ 36K psi / 4.74 GPM @ 40K psi




8) 8" - 10", 16 Nozzle - Most Aggressive set up. 5.4 GPM @ 36K psi / 5.72 @ 40K psi




9) 8" & 10", 16 Nozzle - Less Aggressive set-up. 5.4 GPM @ 36K psi / 5.72 @ 40K psi

---



10) 8" & 10", 16 Nozzle - Less Aggressive Set-up. 4.82 GPM @ 36K psi / 5.1 GPM @ 40K psi

---



11) 8" & 10", 16 Nozzle Concrete Prep - Curing Compound removal set-up - 25,000 35,000 psi

---





12) 14" Most Aggressive set-up. 5.83 GPM @ 36K psi / will not achieve 40K psi

.....



13) 14" Most Aggressive set-up. 5.66 GPM @ 36K psi / 5.98 GPM @ 40K psi

.....



14) 14" Less Aggressive set-up. 5.46 GPM @ 36K psi / 5.78 GPM @ 40K psi

.....



15) 14" Least Aggressive set-up. 4.81 GPM @ 36K psi / 5.09 GPM @ 40K psi

.....



16) 14" Concrete PRep - Curing Compound Removal. Will not achieve 40K psi

.....



14" Rubber Removal - 30,000K psi

.....

## Nozzle Calculation Sheet

### 36K Nozzle Calculation Sheet

Size	GPM	Quantity	Total GPM

Total Accumulative GPM

### 40K Nozzle Calculation Sheet

Size	GPM	Quantity	Total GPM

Total Accumulative GPM

Remember to multiply the total by two if you have a two head system. The total should not exceed 11.8 gpm. If it does, you will not achieve pressure.

***Remember that the total available gpm varies by 12% for individual machines.***



THIS PAGE WAS LEFT BLANK  
INTENTIONALLY

## Technical Support

### **24 / 7 CUSTOMER SERVICE**

- Waterblasting Technologies Customer Service Department stands ready to answer your questions and provide technical assistance 24 hours a day, 7 days a week.
- Customer Service can also assist you with part orders.
- Always contact Waterblasting Technologies Customer Service Department for assistance and cross reference specifications for parts you intend to purchase locally.

### **PARTS**

- All replacement parts are available directly through Waterblasting Technologies, Inc.
- Get the parts you need when you need them
- Next day delivery is available in most locations.
- Same day delivery available in some areas for parts ordered before 10AM Eastern Standard Time

**CUSTOMER SERVICE HOT LINE - 772-223-7393**  
**[www.waterblastingtechnologies.com](http://www.waterblastingtechnologies.com)**  
**[www.stripehogsupport.com](http://www.stripehogsupport.com)**

Waterblasting Technologies, INC will not be responsible for damages or loss caused by substituted parts purchased locally or from another vendor or manufacturer.



## **WARNING**



**NEVER ATTEMPT TO USE COMMONLY AVAILABLE PLUMBING PARTS, FITTINGS, AND HOSES IN HIGH PRESSURE SYSTEMS! ALL FITTINGS TO BE USED WITH HIGH PRESSURE OPERATIONS MUST BE PROPERLY DESIGNED, STAMPED, RATED AND APPROVED BY WATERBLASTING TECHNOLOGIES, INC! FAILURE TO HEED THIS WARNING MAY RESULT IN DAMAGE TO COMPONENTS AND SEVERE INJURY OR DEATH!**

## Stripe Hog Support Web Page



# Stripe Hog Support

[Home](#)
[Training](#)
[Ambassador Club](#)
[Marketing](#)
[Stripe Hog Store](#)
[Contacts](#)




You are here ➔ [Home](#)

[Mike](#) ➔ [Logout](#) ➔








 VIDEO HELP




### Typical Registration & Logon Window



**Welcome to the Stripe Hog Support Center!**  
 This resource is exclusive to Stripe Hog customers. In order to view the complete menu above and website you must be logged in. If you own or operate a Stripe Hog please login or register.

#### REGISTER

User Name:    
 First Name:    
 Last Name:    
 Display name:    
 Email Address:  

[REGISTER](#) 

#### LOG ON

User Name:    
 Password:  

[Login](#)

(001) 772-223-7393 This number that will find an available customer support representative 24/7.

We are excited to take your call any hour of the day. Please don't hesitate to call if we can help.

The "Ambassador Club" is added to the site - Tuesday, November 11, 2008

The Ambassador Club is a place for Waterblasting Technologies, Stripe Hog owners and operators to communicate so we all can benefit and become stronger. As an owner/operator of the Stripe Hog you are in an elite group. Welcome!

[Home](#) | [Stripe Hog Training](#) | [Ambassador club](#) | [Marketing](#) | [Stripe Hog Store](#) | [Contacts](#) |







3321 SE Slater Street  
Stuart, Florida 34992

(001) 772-223-7393 P | (001) 772-223-5461 F

[www.waterblastingtechnologies.com](http://www.waterblastingtechnologies.com)